

# Installation and User Guide Triton™ FH-Series Camera



© 2021 Teledyne FLIR LLC All rights reserved worldwide. No parts of this manual, in whole or in part, may be copied, photocopied, translated, or transmitted to any electronic medium or machine readable form without the prior written permission of Teledyne FLIR LLC.

Names and marks appearing on the products herein are either registered trademarks or trademarks of Teledyne FLIR LLC and/or its subsidiaries. All other trademarks, trade names, or company names referenced herein are used for identification only and are the property of their respective owners.

This product is protected by patents, design patents, patents pending, or design patents pending.

Photographs and images appearing in this manual may have been modified for illustrative purposes using commercial image editing software and may not always reflect an actual product configuration.

The contents of this document are subject to change without notice.

For additional information visit www.teledyneflir.com or write to Teledyne FLIR LLC

Teledyne FLIR LLC 6769 Hollister Avenue Goleta, CA 93117 Support: https://support.flir.com/

#### Important Instructions and Notices to the User:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Modification of this device without the express authorization of Teledyne FLIR LLC may void the user's authority under FCC rules to operate this device.

**Note 1:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense.

**Note 2:** If this equipment came with shielded cables, it was tested for compliance with the FCC limits for a Class A digital device using shielded cables and therefore shielded cables must be used with the device.

#### Industry Canada Notice:

This Class A digital apparatus complies with Canadian ICES-003.

#### Avis d'Industrie Canada:

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

#### Proper Disposal of Electrical and Electronic Equipment (EEE)



The European Union (EU) has enacted Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE), which aims to prevent EEE waste from arising; to encourage reuse, recycling, and recovery of EEE waste; and to promote environmental responsibility.

In accordance with these regulations, all EEE products labeled with the "crossed out wheeled bin" either on the product itself or in the product literature must not be disposed of in regular rubbish bins, mixed with regular household or other commercial waste, or by other regular municipal waste collection means. Instead, and in order to prevent possible harm to the environment or human health, all EEE products (including any cables that came with the product) should be

#### **Document History**

Revision	Date	Comment
100	September 2021	Initial Teledyne FLIR release
110	November 2021	Thermal video analytics color palette; Vehicle Detection Filter; Differential analytics item; external illumination support; camera web page improvements; installation and cleaning instructions improvements; operating temperature range, low-temperature, and other specifications; PoE 70W class 8 or 24V AC / DC recommendation

# **Product Registration and Warranty** Information

Register your Product with Teledyne FLIR at https://customer.flir.com.

For warranty information, see <u>https://www.teledyneflir.com/support-center/warranty/security/flir-security-product-warranties/</u>.

# **Table of Contents**

1. Cam	nera Overview	1
1.1	Accessing Product Information from the Teledyne FLIR Website	2
1.2	Camera Dimensions	3
1.3	Camera Specifications	4
2. Inst	allation	7
2.1	Supplied Components	8
2.2	Site Preparation	8
2.3	Supplying Power to the Camera	9
2.4	Additional Connections	10
2.5	Connect the Camera	11
2.6	Configure for Networking	14
2.7	Mount the Camera	16
2.8	Connect the Camera	16
2.9	Aim the Camera	17
2.10	Check the Boresight	17
2.11	Configure the Analytics	17
2.12	Additional Configuration	18
2.13	Attach the Camera to a Supported VMS	18
3. Ope	ration	19
<b>3. Ope</b> 3.1	Accessing the Camera	<b> 19</b> 19
<ol> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> </ol>	Accessing the Camera View Settings Home Page	<b> 19</b> 19 19
<ul><li>3. Ope</li><li>3.1</li><li>3.2</li><li>3.3</li></ul>	Accessing the Camera View Settings Home Page Making Changes to Settings	<b> 19</b> 19 19 20
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page	<b> 19</b> 19 19 20 22
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page	19 19 20 22 24
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page	<b>19</b> 19 20 22 22 24 28
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page	<b>19</b> 19 20 22 24 28 30
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page	<b>19</b> 19 20 22 22 24 28 30 30
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> </ul>	Accessing the Camera Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models)	<b>19</b> 19 20 22 24 28 30 30 31
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> </ul>	Accessing the Camera	<b>19</b> 19 20 22 24 28 30 30 31 33
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration	19 19 20 22 24 28 30 30 31 33 35
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.</li> <li>3.</li> </ul>	Accessing the Camera Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration 10.2 Create Analytics Regions	19 19 20 22 22 24 28 30 30 31 33 35 36
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.</li> <li>3.11</li> </ul>	Accessing the Camera Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration 10.2 Create Analytics Regions OSD Page	19 19 20 22 24 28 30 30 31 33 35 36 38
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.</li> <li>3.11</li> <li>3.12</li> </ul>	Accessing the Camera Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration 10.2 Create Analytics Regions OSD Page Georeference Page	19 19 20 22 24 28 30 30 31 33 35 36 38 39
<ol> <li>Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.10</li> <li>3.10</li> <li>3.11</li> <li>3.12</li> <li>Con</li> </ol>	Accessing the Camera Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Illumination Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration 10.2 Create Analytics Regions OSD Page Georeference Page	19 19 20 22 24 28 30 30 31 33 35 36 38 39 40
<ul> <li>3. Ope</li> <li>3.1</li> <li>3.2</li> <li>3.3</li> <li>3.4</li> <li>3.5</li> <li>3.6</li> <li>3.7</li> <li>3.8</li> <li>3.9</li> <li>3.10</li> <li>3.10</li> <li>3.10</li> <li>3.11</li> <li>3.12</li> <li>4. Con</li> <li>4.1</li> </ul>	Accessing the Camera View Settings Home Page Making Changes to Settings Video Page Visible Page Thermal Page Illumination Page Input/Output (I/O) Page Radiometry Page (R models) Video Analytics Page 10.1 Check the Analytics Calibration 10.2 Create Analytics Regions OSD Page Georeference Page	19 19 20 22 24 28 30 30 30 30 31 33 35 36 38 39 40 40

# **Table of Contents**

	4.3	Users F	age	. 42
	4.4	Alarm F	age	. 43
	4.4	1.1	Modifying or Defining Rule Triggers	. 44
	4.4	1.2	Modifying or Defining Rule Actions	. 45
	4.5	Audio P	'age	. 46
	4.6	I/O Dev	ices Page	. 47
	4.7	Messag	jing Page	. 49
	4.8	Heaters	s & Fans Page	. 49
	4.9	Cyber F	age	. 50
	4.9	9.1	Certificates	. 51
	4.9	9.2	802.1X	. 52
	4.9	9.3	TLS / HTTPS	. 52
	4.9	9.4	Services	. 53
	4.9	9.5	IP Filter	. 53
	4.10	ONVIF	Page	. 54
	4.11	Map Pa	ıge	. 54
	4.12	Boresig	ht Page	. 56
	4.13	Schedu	ler Page	. 60
	4.14	Recordi	ing Page	. 62
	4.15	Firmwa	re & Info Page	. 62
5.	Main	tenance	and Troubleshooting Tips	. 66
	5.1	Cleanin	g	. 66
	5.2	Trouble	shooting	. 66
6.	Арре	endix		. 69
	6.1	Configu	rring PTZ Hand-Off	. 69

# 1 Camera Overview

The Teledyne FLIR Triton<sup>®</sup> FH-Series are ruggedized, multispectral fixed cameras that integrate industryleading thermal imaging with 4K visible imaging to provide reliable intruder-detection capabilities for perimeter security. Built-in convolutional neural network (CNN) analytics accurately detect and classify human and vehicle threats moving at high or low speeds, minimizing false alarms and daily operations costs. Custom scheduling enables security operators to set intrusion analytics to run on visible streams during the day and on thermal streams throughout the night, establishing optimized coverage for any lighting condition.

Triton FH-Series R models provide radiometry and can generate alarms determined by detected surface temperature. During critical alarm events, use the visible imager to immediately assess the alarms and save valuable seconds.

When the camera is connected to an IP network, it functions as a server, providing services such as camera control, video streaming, and network communications. The server uses an open, standards-based communication protocol to communicate with Teledyne FLIR and third-party video management system (VMS) clients, including systems that are compatible with ONVIF<sup>®</sup>. These clients can be used to control the camera and stream video during day-to-day operations. For a list of supported VMS clients, see <u>the product page on the Teledyne FLIR website</u>. The camera streams digital video from the camera over an IP network using H.265, H.264, and MJPEG encoding, and provides analog video output.



If help is needed during the installation process, contact the local Teledyne FLIR service representative or call the support number that appears on the product's page at <u>https://support.flir.com/</u>. All installers and integrators are encouraged to take advantage of the training offered by Teledyne FLIR; visit <u>https://www.teledyneflir.com/support-center/training/</u> for more information.

For safety, and to achieve the highest levels of performance from the camera system, always follow the warnings and cautions in this manual when handling and operating the camera.

## **Related Documentation**

- Triton FH-Series Quick Install Guide
- FLIR Security Accessory Guide
- FLIR CGI Interface Description 2.1
- NEXUS<sup>®</sup> CGI WebSockets Manual
- FLIR Sensors SDK Programmer's Guide

# 1.1 Accessing Product Information from the Teledyne FLIR Website

Up-to-date resources for the camera, including the FLIR Discovery Network Assistant (DNA) software tool and this installation and user guide, are available from <u>the camera's product details and support</u> <u>pages on the Teledyne FLIR website</u>.

#### To access product information from the Teledyne FLIR website:

1. Open https://www.teledyneflir.com/browse/security/thermal-security-cameras/.



Thermal Security Cameras Page on the Teledyne FLIR Website

2. Find and click the appropriate model, Triton™ FH-Series ID or R. The product details page appears.



FH-Series ID Product Details Page

- 3. To see specifications and other resources, scroll down.
- 4. Open the camera's support page. Click Go to Product Support.



Product Support Page (FH-Series ID)

- 5. Select the relevant tab. For example, to download the DNA tool, open the Downloads tab.
- 6. To download the resource, click the corresponding **Download** link.

# 1.2 Camera Dimensions

The Triton FH-Series camera's dimensions are (with sunshield):



# 1.3 Camera Specifications

	Array Format (NTSC)	FH-3xx mo FH-6xx mo	odels: 320x256 odels: 640x512					
	Detector Type	Long-life,	uncooled VOx mic	robolometer				
	Pixel Pitch	17 µm						
	Thermal Frame Rate	NTSC: 30 < 9 Hz ava	Hz or PAL: 25 Hz ailable	- user switchabl	e			
		Model	FOV	Focal Length	F/#			
		369 R	69° × 56°	9 mm	F1.4			
		324 R	24° × 18°	13 mm	F1.0			
	Array Format (NTSC) $FH-3xx models: 320x256 FH-6xx models: 640x512 Detector Type Long-life, uncooled VOx microbolometer Pixel Pitch 17 \mumThermal Frame Rate NTSC: 30 Hz or PAL: 25 Hz - user switchable < 9 Hz availableModel FOV Focal Length 369 69^{\circ} \times 56^{\circ} 9 mm R 324 24^{\circ} \times 18^{\circ} 13 mm R 313 13^{\circ} \times 10^{\circ} 25 mm R 324 24^{\circ} \times 18^{\circ} 13 mm R 13 13^{\circ} \times 10^{\circ} 25 mm R 12 R 12 R 12 R 13 mm R 10 R 10 R 13 mm R 10 R 10 R 13 mm R 10 R$	F1.1						
Thermal Sensor & Optics Optical Charac		669 R / ID	69° × 56°	9 mm	F1.4			
	Optical Characteristics	644 R / ID	44° × 36°	13 mm	F1.0			
		625 R / ID	25° × 18°	25 mm	F1.1			
		617 R / ID	17° × 14°	35 mm	F1.1			
		612 ID	12° × 10°	50 mm	F1.2			
		610 ID	10° × 8.2°	60 mm	F1.2			
		608 ID	8.6° × 6.6°	75 mm	F1.1			
	Spectral Range	7.5 µm to	13.5 µm					
	Sensitivity (NEdT)	R models: <35mK @ 25°C (77°F) F1.0						
		ID models: <30mK @ 25°C (77°F) F1.0						
	Sensor Type	4K 2160p	(3820 x 2160)					
		Model	Default FOV	Focal Length	F/#			
		369	98° × 55°	3.6-10mm	F1.5-2.8			
		324	34° × 19°	9-22mm	F1.4-1.7			
		313	18° × 10°	13-55 mm	F1.6-2.2			
Visible Light		669	98° × 55°	3.6-10mm	F1.5-2.8			
Camera	Optical Characteristics	644	63° × 35°	3.6-10mm	F1.5-2.8			
		625	36° × 20°	9-22mm	F1.4-1.7			
		617	24° × 14°	13-55 mm	F1.6-2.2			
		612	1/ <sup>*</sup> ×10 <sup>*</sup>	13-55 mm	F1.6-2.2			
		010	14°× 8°	13-55 mm	F1.0-2.2			
		000	11 ^ 0	15-55 1111	11.0-2.2			

Temperature Measurement (R models only)	Measurement Accuracy	Larget below 100°C (212°F): ± 5°C (±9°F) accuracy         Target below 150°C (302°F): ± 5% accuracy         Target above 150°C (302°F): ± 15% accuracy         Measured at 25°C ambient temperature. Inaccuracy can be greater at extreme temperatures.         Utation of the temperature of temperature				
	Object Temperature Range	High Gain Mode: 0°C to +160°C Low Gain Mode:  0°C to +600°C				
	Video Type	IP or analog				
	Sensitivity	Color: 0.25 Lux (@ (f1.6 AGC On, 30FPS) B/W: 0.10 Lux (@ (f1.6 AGC On, 30FPS)				
	Visible Frame Rate	30Hz				
	IP Video Compression	H.264 / H.265 / M-JPEG Four independent streams; two visible and two thermal				
		Primary Stream				
		Thermal: VGA (640x512), QVGA (320 x256)				
Video	Streaming Decolutions	Visible: 4K (3840x2160) except M-JPEG, 1080p (1920x1080), 720p (1280x720), VGA 640x480				
1400	Streaming Resolutions	Secondary Stream				
		Thermal: VGA (640x512), QVGA (320 x256)				
		Visible: 1080p (1920x1080), 720p (1280x720), VGA 640x480				
	Thermal Image Settings	Auto AGC, Digital Detail Enhancement (DDE), brightness, contrast				
	Thermal AGC Region of Interest (ROI)	Default, presets, and user-definable to ensure optimal image quality on subjects of interest				
	Image Uniformity Optimization	Automatic flat-field correction (FFC) - thermal and temporal triggers				
	Ethernet	100/1000 Mbps				
	Network APIs	NEXUS SDK; NEXUS CGI; ONVIF Profiles S, G, T				
System Integration	Digital I/O	Input: two dry alarm contacts Output: two relay contacts 1A max at 24 VAC / 30 VDC Configurable between normally open and normally closed				
Network	Supported Protocols	IPv4, HTTP, HTTPS, UPnP, DNS, NTP, RTSP, TCP, UDP, ICMP, IGMP, DHCP, ARP, IEEE 802.1X				
General	Input Voltage	12 VDC (±10%) 24 VDC (±10%) 24 VAC (±10%) 802.3bt				
	Power Consumption	Nominal: 15W 12 VDC with heaters enabled: 48W All other input voltages with heaters enabled: 70W				
	IP Rating (Dust & Water Ingress)	IP66, IP67				
Environmental	Operating Temperature Range	-40°C to 70°C (PoE 70W class 8 or 24V AC / DC) -20°C to 70°C (PoE 70W class 6 or 12 VDC)				
	Storage Temperature Range	-55°C to 85°C				

	Corrosion	MIL-STD 810G, 1000hr salt spray
	Humidity	0-95% relative
	Shock	IEC 60068-2-27
	Vibration	IEC 60068-2-64
	Vandalism	IK10 (except windows)
	Surge Immunity on Power Lines	EN 55022: 2010 to 4.0kV on AC aux power lines; EN 50130-4:2011; IEC 62599-2:2010
	Surge Immunity on Signal Lines	EN 55022: 2010 to 4.0kV
	Surge / Lightning Protection	TVS 6000V lightning protection, surge protection, voltage transient protection
Compliance & Certifications	FCC Part 15 (Subpart E CE Marked RoHS IP66, IP67 WEEE IEC 62368 ONVIF Profile S, G, T	3, class A)
Video Analytics	Region entrance / intrus Tampering Loitering CNN classifier	sion detection
Cybersecurity	IEEE 802.1X TLS / HTTPS User authentication Access control via firew User credentials with po Digest authentication	all blicy enforcement

Specifications are subject to change without notice. For the most up-to-date specs, see the product's web page on the Teledyne FLIR website.

# 2 Installation

# **A** Caution

A qualified service person should install the camera.

Except as described in this manual, do not open the camera for any reason. Damage to the camera can occur as the result of careless handling or electrostatic discharge (ESD). Always handle the camera with care to avoid damage to electrostatic-sensitive components.

Prior to making any connections, ensure the power supply or circuit breaker is switched off. Be careful not to leave fingerprints on the camera's infrared optics.

Operating the camera outside of the specified input voltage range or the specified operating temperature range can cause permanent damage.

At the mounting location, secure the camera before supplying power to it.

This chapter includes information about:

- Supplied Components
- Site Preparation
- Supplying Power to the Camera
- Additional Connections

To install the camera, Teledyne FLIR recommends connecting the camera on a bench or in a lab and configuring it for networking before mounting and aiming it:

- 1. Connect the Camera
- 2. Configure for Networking
- 3. Mount the Camera
- 4. Connect the Camera
- 5. Aim the Camera
- 6. Check the Boresight
- 7. Configure the Analytics
- 8. Additional Configuration
- 9. Attach the Camera to a Supported VMS

However, circumstances can dictate adjusting the sequence of the steps. For example, you can mount the camera before configuring it for networking, or connect the camera before mounting it.

# 2.1 Supplied Components

The Triton FH-Series camera kit includes these items:

## Camera Body with Sun Shield Attached



Teledyne FLIR ships the cameras with watertight cable glands and seal plugs attached to the rear cable ingress holes.

In addition, the camera kit includes a bag with the following parts:

- a T10 Torx wrench
- two 10-pin terminal block, for I/O connectors
- one three-pin terminal block, for 12 VDC input connector
- three two-pin terminal blocks, for 24 VAC output / input connectors

For information about the camera's connectors, see Connect the Camera.

# 2.2 Site Preparation

Select a suitable location to mount the camera.

Triton FH-Series cameras are intended to be mounted on a medium-duty fixed pedestal mount or wall mount commonly used in the CCTV industry, at an installation height of at least 4 m (13 ft). Cables exit from the back of the camera housing. The mount must support up to 30 lbs (15 kg). For the full list of mounting and other accessories available for the camera from Teledyne FLIR, see the *FLIR Security Cameras - Accessory Guide*.

Mount the camera in a location that allows access for regular periodic cleaning (fresh water rinse), inspection of mounting integrity and mechanical soundness, and preventive maintenance. Ensure the camera and the camera mount are routinely inspected on a periodic basis.

If you are powering the camera with PoE 70W class 8 or 24V AC / DC, verify that the operating temperature is -40°C to 70°C (-40°F to 158°F) with cold start at -40°C (-40°F), 0-95% relative humidity. For other power sources, see <u>Supplying Power to the Camera</u>.

Consider cable lengths and cable routing. Make sure the cables are long enough, given the proposed mounting locations and cable routing requirements; do not exceed their specifications; adhere to all local and industry standards, codes, and best practices; have sufficient dimensions to ensure safety (for power cables); and adequate signal strength (for video and communications). Before you mount the camera and fit the mounting hardware, route the cables.

In addition, prior to installing the unit and for proper installation and operation, the following requirements need to be properly addressed:

- Ambient Environment Conditions: Avoid positioning the unit near heaters or heating system outputs. Use proper maintenance to ensure that the unit is free from dust, dirt, smoke, particles, chemicals, smoke, water or water condensation, and exposure to EMI.
- Accessibility: The location used should allow easy access to unit connections and cables.
- **Safety**: Cables and electrical cords should be routed in a manner that prevents safety hazards, such as from tripping, wire fraying, overheating, etc. Ensure that nothing rests on the unit's cables or power cords.
- Ample Air Circulation: Leave enough space around the unit to allow free air circulation.
- Cabling Considerations: Units should be placed in locations that are optimal for the type of video cabling used between the unit and the cameras and external devices. Using a cable longer than the manufacturer's specifications for optimal video signal may result in degradation of color and video parameters.
- **Physical Security:** To ensure the unit cannot be disabled or tampered with, it should be installed with security measures regarding physical access by trusted and non-trusted parties.
- Network Security: The unit transmits over IP to security personnel for video surveillance. Proper network security measures should be in place to assure networks remain operating and free from malicious interference. Install the unit on the backbone of a trusted network.
- Electrostatic Safeguards: The unit and other equipment connected to it (audio and alarm inputs and outputs, racks, carpeting, etc.) shall be properly grounded to prevent electrostatic discharge.

# A Warning

Before drilling into surfaces for camera mounting, verify that electrical or other utility service lines are not present. Serious injury or death may result from failure to heed this warning.

The physical installation of the unit is one phase of making the unit operational in a security plan. The goal is to physically place the unit, connect it to other devices in the system, and to establish network connectivity. In addition to physical installation, installation also consists of setup and configuration.

# 2.3 Supplying Power to the Camera

The camera itself does not have an on/off switch. Generally, the Triton FH-Series camera will be connected to a circuit breaker and the circuit breaker will be used to apply or remove power to the camera. If power is supplied to it, the camera will be in one of two modes: Booting Up or Powered On.

The power cable supplied by the installer must use wires that are sufficient size gauge (16 AWG recommended) for the supply voltage and length of the cable run, to ensure adequate current carrying capacity. Always follow local building codes.

Ensure the camera is properly grounded. Typical to good grounding practices, the camera chassis ground should be connected to the lowest resistance path possible. Anchor a grounding strap to the grounding lug inside the camera housing (see <u>Connect the Camera</u>) and connect it to the nearest earth-grounding point.

The camera can be powered by:

- 12 VDC (±10%)
- 24 VDC (±10%)
- 24 VAC (±10%)—for example, Teledyne FLIR part number 4124857
- PoE IEEE 802.3bt 50W class 6 or 70W class 8

Teledyne FLIR recommends using PoE 70W class 8 or 24V AC / DC. Other power sources limit low-temperature operation:

	12V	24V	PoE 50W class 6	PoE 70W class 8
Lowest operating temperature	-20°C	-40°C	-40°C	-40°C
Cold start	•	•	•	•
De-icing		•		•
De-fogging		•	•	•
Fog prevention	•	•	•	•

If using PoE, make sure the PoE switch or injector is a Power Sourcing Equipment (PSE) device. If using an external AC or DC power supply, make sure to connect the power supply to the appropriate <u>connector</u> <u>and connection</u>. The AC / DC power connectors included in the camera kit accept 16 AWG maximum wire size.

Nominal power consumption is 15W; 48W on 12 VDC with heaters enabled; and 70W on all other input voltages with heaters enabled.

# A Warnings

- Make sure the camera's power cable is properly connected. All electrical work must be performed in accordance with local regulatory requirements.
- Use a UL Listed Power Adapter that meets LPS (Limited Power Source) requirements.

## Heaters

Onboard heaters de-fog and de-ice the camera's lenses and other components in the event of, for example:

- A power interruption that disables the camera for an extended period
- Freezing rain that covers the lenses and obstructs the images

By default, the heaters automatically turn on and off at certain temperatures. Camera web page users assigned the role of admin or expert can change the temperature mode for these components, manually turn the heaters on and off, and monitor the temperature of the components on the <u>Heaters & Fans Page</u>.

# 2.4 Additional Connections

## **Ethernet Connection**

The Triton FH-Series camera produces digital (IP) and analog video output. An Ethernet connection is required for IP video streaming, configuration, and communication.

The camera's cable gland seals are designed for shielded Category 6 Ethernet cable.

FLIR IP cameras support FLIR UVMS video management systems, along with third-party VMSs. These systems tend to evolve and change over time. Therefore, for up-to-date information, contact the local Teledyne FLIR representative or <u>Teledyne FLIR Support</u>.

## **Analog Video Connections**

There are two BNC connectors for analog video connections: one for thermal camera video and the other provides user-configurable analog visible or thermal video output. Analog video requires a connection to a video monitor or to an analog video matrix switch. To ensure a quality video signal, use cable rated RG59U or better.

The camera can output analog video in either NTSC or PAL.

#### Alarm I/O Connections

The camera provides two alarm input connections and two sets of output connections. The output pins support a normally open or normally closed idle state; that is, when there is no alarm and when power is not being supplied to the camera.

## Audio I/O Connections

The camera provides a line-level analog audio input, analog-to-digital encoding, and a digital audio output.

## Power to External IR LED Illuminators

The camera provides two 24 VAC output connections for external IR LED illuminators. For information about the Raytec IR LED illuminators FH-Series cameras support, see the *FLIR Security - Accessory Guide*.

# 2.5 Connect the Camera

Teledyne FLIR recommends connecting the camera on a bench or in a lab and configuring it for networking before mounting and aiming it.

The camera's interfaces and connections are inside the camera body. A microSD card slot and reset / default button are located on a panel on the side of the camera. To access the side panel, loosen and remove the screws that attach the access cover to the camera. An anti-drop strap prevents the access cover from falling. Before closing and locking the access cover, make sure to store the anti-drop strap inside the camera to ensure that the camera remains waterproof.



		Side Panel
1	<b>LED status indicator</b> —Solid green indicates the camera is powered and operating.	• To reboot and reset the camera to its previously saved settings, press the button for between 1-3 seconds. The LED flashes red and green, becomes solid red, and then becomes solid green. To
2	Recessed Default / Reset button—To press the button, Teledyne FLIR recommends using a cell phone SIM or memory card tray eject tool or something similar.	<ul> <li>make sure all of the camera's systems properly boot up, wait a couple of minutes before performing any other operation.</li> <li>To reboot and reset the camera to its factory default settings, press the button for at least 10 seconds. While you are pressing the button, the LED flashes green and red. When the LED flashes only red, release the button and the camera reboots.</li> </ul>
3	microSD card slot	
Tł	ne USB port is reserved for future	use.

# **A** Important

Use a preformatted microSD card, or format it using the camera's web page or a PC. You can configure onboard storage or other storage on the edge (SoE) using FLIR UVMS, an approved third-party VMS, or another ONVIF-compliant client. For more information about using the camera's web page to format a microSD card, see <u>Recording Page</u>.



<u>Access the camera's web page</u>, open the <u>Recording Page</u>, and make sure the camera recognizes the microSD card.

#### To open the camera's top cover:

1. Through slots in the sunshield, use the Torx wrench supplied with the camera to loosen and remove the two screws that secure the camera's top cover that are closest to the hinges. Then, loosen and remove the other two screws.

You do not need to remove the sunshield to open the cover. Nonetheless, if you want to remove the sunshield, loosen and remove the screws that attach it to the camera body. Then, carefully remove the sunshield.

2. Open the camera cover to expose the inside of the camera body and the following connections.



	Connection	Description								
1	LAN (56V-1.6A) PoE 802.3bt	Attach 100/1 A soli indica	n a C 000 I d gre tes c	at 6 cable from Mbps Ethernet a en LED indicate lata traffic betw	the ne and Po es an a een th	where the state of				
2	BNC x 2	T/V—User-configurable analog visible or thermal video output; supports OSD You c				h analog video cables rated RG59U or higher ese connectors. can enable on-screen display (OSD) on the				
3	T/V THERMAL ANALOG VIDEO OUTPUT	Analo outpu	g the t; no	ermal video OSD	exper conne	t ca ector	n specify the vic on the Firmwa	leo 1 leo 1 re &	format of the T/V Info Page.	
4	10-pin terminal block x 2									
虈		Conn IR LE	ect w D illu	ires from an ex minators, to the	ternal e appro	pow opria	er supply, alarn ate pins on the a	n or appr	audio I/O devices, or opriate connector.	
5	DC12V (IN)	DC12V (IN)					terminal blocks power supply to	the	AC24V / DC24V IN	
6	ILLUMINATION POWER OUT 1 AC24V		• [ s	o not use the I ame time.	DC12V	and	1 AC24V / DC24	ŧ∨ Iľ	N connections at the	
7	POWER INPUT 24V AC / DC 7.2A		The ILLUMINATION POWER OUT 1 + 2 AC24V connections can supply a maximum 4.2A total to external illuminators. They must be connected to equipment with fireproof enclosures. FH-Series							
8	ILLUMINATION POWER OUT 2 AC24V		cameras support Raytec Long-Range Infra-Red illuminator model VAR2-i6-1, VAR2-i6-2, VAR2-i8-1, VAR2-i8-2, and VAR2-i16-1. For information about which Raytec illuminator each FH-Series							
			model supports, see the FLIK Security - Accessory Guide.					ssory Guide.		
		Ancho	Anchor a ground strap to this grounding lug and connect it to the nearest							
9			Ma	ake sure the ca	mera i	s pro	operly grounded	l. Fa	ilure to properly	
			<u> </u>	ound the camer	a can	perr	manentiy damag	ge tr	e camera.	
			10-	Pin Terminal E	Block		Pin		Pin	
						1		1	ALARM IN 1	
						2		2		
						3		3		
						4		4		
D					معر	5		5		
	1 2	3				7	RS 485 TY P	7		
	Pin - NC	+	Dim			7 8	RS-485-RX-P	7 8		
			FIII	12345678	9 10	9	RS-485-RX-N	9	ALARM OUT 2 COM	
						10	GND	10	ALARM OUT 2 NC	
						To	use the camera	's e>	ternal IR illumination	
						feat the	ture to turn illum m to ALARM OU	inat JT 2	ors on and off, connect	

# 2.6 Configure for Networking

You can discover and configure the camera for networking using version 2.3.0.20 or higher of the FLIR Discovery Network Assistant (DNA) software tool; the camera's web page; or a supported VMS. Using the DNA tool or the camera's web page requires using the default admin user or any user assigned the admin or expert role.

Task	DNA Tool	Camera's Web Page
Discover camera IP address	•	
Configure IP address, mask, and gateway	•	•
Configure IP address, mask, and gateway for more than one camera at the same time	٠	
Configure DNS settings, MTU, and Ethernet speed		•

# Notes

- Teledyne FLIR recommends using the DNA tool to discover the camera on the network (version 2.3.0.20 or higher). It does not require a license to use and is a free download from <u>the product's</u> web page on the <u>Teledyne FLIR website</u>. For more information about using the DNA tool, including how to configure more than one camera at the same time, see the *DNA User Guide*. While the software is open, click the Help icon **2**.
- For more information about using a supported VMS to configure one or more cameras at the same time, see the VMS documentation.

By default, DHCP is enabled on the camera and a DHCP server on the network assigns the camera an IP address. If the camera cannot connect to a DHCP server, the camera's default IP address is 192.168.0.250.

- If the camera is managed by FLIR Horizon or Meridian VMS and the VMS is configured as a DHCP server, the VMS automatically assigns the camera an IP address.
- If the camera is managed by FLIR Latitude VMS or is on a network with static IP addressing, you can manually specify the camera's IP address using the DNA tool or the camera's web page.

## To configure the camera for networking using the DNA tool:

1. Run the DNA tool (DNA.exe; version 2.3.0.20 or higher) by double-clicking . The Discover List appears, showing compatible devices on the VLAN and their current IP addresses.

C Discovery	Network A	Assistant (DN	A) - v2.	3.0.20										- 0		×
R Setup	O-	<b>B</b> Firmware	Admir	<b>, *</b>	: Properti	ies Exp	port 🗸						4	¢FLIF	Z [	0
C Refre	sh	Add Device	Manual	y Se	elect All					Filter :	Device Type	$\sim$		Apply	Cle	ear
Device Type	Mode	el name		Status	b	ogin statu	s		IP address		Name		Firmware version	MA	C addr	e ^
Camera	DM-6	12		Online	N	ot authen	ticated		172.20.70.24		DM-612 999991			00	:1B:D8:	9
🕞 camera	DX-3	12		Online	N	lot authen	ticated		172.20.70.28		DX-312 123456			00	:40:18:	1
🗊 camera	FH-3	13		Online	N	lot authen	ticated		172.20.70.126		FH-313 ENG000			00	:18:D8:	2
🖙 camera	FR-3	45-EST		Online	N	lot authen	ticated		172.20.70.90		FR-345-EST 9110	0213		00	:1B:D8:	7
🖙 camera	FR-3	45-EST		Online	N	lot authen	ticated		172.20.70.91		FR-345-EST 9110	0212		00	:1B:D8:	7
🖙 camera	FR-3	45-EST		Online	N	lot authen	ticated		172.20.70.92		FR-345-EST 9110	0230		00	:1B:D8:	7 🗸
<															>	
							Num	ber of d	evices : 50							

In the DNA Discover List, verify that the camera's status is Online.

If this is the first time you are configuring the camera or if it is the first time after resetting the camera to its factory defaults, DNA automatically authenticates the camera with the default password for the camera's admin user (*admin*).

If the admin user password has been changed, you need to authenticate the camera.

In the DNA Discover List, right-click the camera and select **Login**. In the **DNA - Login** window, type the password for the admin user. If you do not know the admin user password, contact the person who configured the camera's users and passwords.

u≓ camera	DX-312	Online	Not authenticated	17	2.20.	Login credentials :			
🖉 camera	FH-313	Or	IP Setup		.20.	User Name	admin	F	Password :
camera	FR-345-EST	Or	Login		.20.3	ober Hame I			
🖉 camera	FR-345-EST	Or	Login		.20.1				
🗩 camera	FR-345-EST	Or	Firmware Update		.20.1	Status	Model Name	Name	IP
🗩 camera	FR-345-EST	Or	Admin	>	.20.3		FH-313	FH-313 ENG000	172.20.70.126
🗈 camera	trk101	Or	Admin	,	.20.3				
🗈 camera	trk101	Or	Device Properties		.20.3				
🗈 camera	trk101	Or	Change Video Format		.20.3				
🗈 camera	trk101	Or	Wab		.20.3				
P camera	trk101	Or	Web		.20.3				
🗈 camera	trk101	Or	Update Credentials		.20.3				
🗈 camera	trk101	Or	Export	>	.20.3				
🗈 camera	trk101P	Or	Refresh		.20.3				
Camera	trk101P	Otume	Automacateu	1/	2.20.3				

Click **Login**, wait for **V** Ok status to appear, and then click **Close**.

In the DNA Discover List, verify that the camera's status is Online and Authenticated.

3. Change the camera's IP address.

Right-click the camera and select IP Setup.

In the **DNA - IP Setup** window, clear *Use DHCP* and specify the camera's *IP address*. You can also specify the *Mask* (default: 255.255.255.0) and *Gateway*. Then, click **Update**, wait for  $\checkmark$  Ok status to appear, and then click **Close**.

DNA - IP Setu	p (1 Device Sel	ected )						×
Use DHCP								
	IP Address :	10 .	70.	20	. 235	]		
	Mask :	255 .	255 .	255	. 0	]		
	Gateway :	10 .	70.	20	. 1			
Status	Model name		Name			_	Current IP	Previous I
🗸 Ok	FH-313		FH-31	3 ENG	5000		172.20.70.17 (DHCP)	10.70.20.
4								>
							Undate	Close

## To manually specify the camera's IP address using the camera's web page:

- 1. Access the camera's web page.
- 2. On the <u>View Settings Home Page</u>, click **System Settings**, and make sure the <u>Network Page</u> appears.
- 4. Click **Static** IP addressing and then manually specify the camera's *Hostname*, *IP address*, *Netmask*, and *Gateway*.

You can also specify the DNS Mode, Name Servers, MTU (maximum transmission unit), and Ethernet Speed.

5. Click Save. Applying any changes on the Network page requires rebooting the camera.

#### **Close the Cover**

Disconnect the camera.

To prevent damaging the camera's internal components while moving it from the bench or lab to its mounting location, securely close the camera cover. If you removed the sunshield, either re-attach it or bring it to the mounting location.

At the mounting location, to connect the camera, open the cover again. If necessary, remove the sunshield.

# 2.7 Mount the Camera

Mount	Wall	Large pole ⌀ 150-230 mm (6-9")	Small pole ⌀ 65-110 mm (2.6-4.3")	Corner	Pedestal	
	Illuminator bracket kit (future release)					
	W					
Accessories		500-1116-00 Large pole adapter assembly	500-1121-00 Small pole adapter assembly	500-1119-00 Corner mount assembly	500-1120-00 Pedestal mount assembly	

Teledyne FLIR offers accessories to mount the camera as such:

Be sure to have the required accessories and tools available.

Install the mounting hardware for the camera according to the instructions for the hardware. If relevant, route power, network, and other cables into the mounting hardware so that they are accessible when the camera is mounted.

Typically, point the camera towards the ground while ensuring that the field of view includes as little of the skyline as possible. Teledyne FLIR recommends mounting the camera with zero horizontal rotation; that is, a 0° installation roll angle. For accurate video analytics, mount the camera with an installation roll angle within  $\pm 5^{\circ}$ .

Attach the camera to the mounting surface using four 1/4"-20 UNC SUS 19mm screws, each with a metal flat washer, a spin washer, and a a 1/4"-20 UNC nut.



Attaching the Camera to a Bracket (Example)

# 2.8 Connect the Camera

# **A** Caution

Carefully following these instructions makes sure water does not enter the camera and ensures its long-term reliability. Teledyne FLIR is not responsible for damage to the camera due to not adhering to these instructions.

Cables enter the camera body through liquid-tight 3/4" NPT compression glands, each with a gland seal insert and plugs for unused holes. To ensure watertight seals, the cable outer diameter must be between 0.23"-0.29". If you are using other, non-standard cable diameters, you might need to locate or fabricate an insert to fit the cable. Teledyne FLIR does not provide cable gland inserts other than those supplied with the camera.

Carefully loosen and remove the gland nuts. Remove the appropriate number of cable gland seal plugs. However, make sure seal plugs are securely in place for all unused gland seal holes.

Route the cables through the gland seals before terminating and connecting them. In general, terminated connectors do not fit through the cable gland. If you need to route a terminated cable through the cable gland, make a clean, singular cut in the gland seal. Then, route the cable through it. Leave the gland nuts loose until you have finished routing and connecting all of the cables.

Allow enough space for cable egress through the gland. The typical cable bend radius is 50-75 mm (2-3 in). Observe the cable manufacturers' recommendations regarding bend radius.

According to the information in <u>Connect the Camera</u>, terminate the cables and then connect them.

To ensure a watertight seal, fully tighten the gland nuts.

## **Close and Secure the Cover**

Using the Torx wrench, alternately tighten the four screws that secure the cover to the camera; torque to 8+0.5 kgf-cm.



Seal plugs

Cable Glands (Seal Inserts Not Shown)

Cable Egress Space (75 mm / 3 in Bend Radius)

# Caution

To ensure the camera's IP66 and IP67 dust and water ingress ratings, properly and securely close the camera cover and tighten the screws. Failure to do so can void the camera's warranty.

Gland

nut

Re-attach the sunshield, if relevant.

# 2.9 Aim the Camera

The camera itself is stationary and does not provide physical aiming adjustment. For information about how to adjust mounting hardware to aim the camera, refer to the instructions for the mounting hardware.



- Aim the camera while you or someone else is monitoring the camera's live video on the camera web page or in a video stream.
- Aim the camera while supporting the camera's weight with your hand or with the help of someone else.

# 2.10 Check the Boresight

At the factory, the visible video image was aligned with the thermal video image. Users assigned the role of admin or expert can fine tune the camera's boresight to the scene using the camera's web page. For more information, see <u>Boresight Page</u>.

# 2.11 Configure the Analytics

Using the <u>Video Analytics Page</u>, calibrate and then configure the camera's onboard video analytics.

# 2.12 Additional Configuration

Depending on how you are installing and using the Triton FH-Series camera, and the network and VMS to which it is connected, initial configuration can also consist of enabling, disabling, or configuring the following settings using the camera's web page:

Settings	User Role
<ul> <li>Live video and video streams</li> <li><u>Visible imager</u></li> <li><u>Thermal imager</u></li> <li><u>External IR illumination (when enabled)</u></li> <li><u>Current and idle I/O states</u></li> <li><u>Temperature measurement (R models)</u></li> <li><u>On-screen display (OSD)</u></li> <li><u>Georeference</u></li> </ul>	Any user
<ul> <li><u>Date and time</u></li> <li><u>Alarms</u></li> <li><u>Audio</u></li> <li><u>Enabling and configuring external I/O devices</u></li> <li><u>Notification emails</u></li> <li><u>Onboard de-icing heaters and cooling fan</u></li> <li><u>Cybersecurity</u></li> <li><u>ONVIF auxiliary commands and output actions</u></li> <li><u>Map</u></li> <li><u>Scheduled tasks</u></li> <li><u>Format a microSD card</u></li> <li><u>Firmware, factory defaults, external IR</u></li> <li><u>illumination, and other system settings</u></li> </ul>	Default admin user / user assigned the admin or expert role
Users, roles, and passwords	User assigned the admin role
PTZ hand-off	N/A

Some of these configuration tasks can be performed before or after mounting the camera, but others can or should be performed only after mounting and connecting the camera.

# 2.13 Attach the Camera to a Supported VMS

After you have mounted the camera and discovered or defined its IP address, you can use VMS Discovery / Attach procedures to attach the camera to a supported VMS.

# 3 Operation

This chapter includes information about how to <u>access the camera</u> and how to operate it using the <u>View</u> <u>Settings Home Page</u>.

# 3.1 Accessing the Camera

To operate the camera, you first need to access it. You can access the camera by logging in to the camera's web page. The camera's web page supports Google Chrome® and other popular web browsers.

## To log in to the camera's web page:

- 1. Do one of the following:
  - In the FLIR Discovery Network Assistant (DNA) tool version 2.3.0.20 or higher double-click the camera in the Discover List.

The DNA tool does not require a license to use and version 2.3.0.20 or higher is a free download from the product's web page on the Teledyne FLIR website. Download the DNA tool; unzip the

file; and then double-click **to** run the tool (DNA.exe). The Discover List appears, showing compatible devices on the VLAN.

- Type the camera's IP address in a browser's address bar (when the PC and the camera are on the same network). If you do not know the camera's IP address, you can use the DNA tool to discover it.
- 2. On the login screen, type a user name and the password.

When logging in to the camera for the first time or for the first time after resetting the camera to its factory defaults, you need to log in with the camera's default credentials:

#### User name-admin

#### Password—admin

If you do not know the user name or password, contact the person who configured the camera's users and passwords.

3. When logging in to the camera for the first time or for the first time after resetting the camera to its factory defaults, specify a new password for the admin user and then log back in using the new password.

Use a strong password consisting of at least 12 characters and at least one uppercase letter, one lowercase letter, and one number. Passwords can include the following special characters: | @#~!\$&<>+\_-.,\*?= .

The camera's View Settings Home Page appears.

# 3.2 View Settings Home Page

The View Settings home page displays live video images of the selected view. When a user assigned the expert or admin role logs in to the camera's web page, the page also displays View Settings menus along the left side banner and other options.





View Settings Home Page - FH-xxx R models - Users Assigned the Admin or Expert Role Visible Video Images Selected - Default Settings

## **System Settings**

Users assigned the admin or expert role can click **System Settings** to configure the camera. For more information, see <u>Configuration</u>.

#### Live Video

You can select to view visible (V) or thermal (T) live video images. The live video on the camera's web page is not the actual video stream. Changes to the <u>video stream</u>, <u>analytics tracking overlay</u>, or <u>on-screen display (OSD)</u> settings might not affect the live video.

You can also set the Live Video Refresh Rate between 1-10 image frames per second (FPS).

The view selected and the Live Video Refresh Rate setting only affect the live video; they do not affect the camera's video streams nor its analog video output.

If the camera is currently detecting and classifying objects, and generating any alarms, they appear on the View Settings home page, as well.

#### **Other Options**

Additional choices are for Help and Logout.

# 3.3 Making Changes to Settings

The camera's configuration files store the following sets of settings:

- Factory default settings—The settings when you first connect the camera to power, and when resetting the camera to its factory default settings (see <u>Firmware & Info Page</u>). A partial factory reset restores all factory default settings except the settings on the <u>Network Page</u>.
- **Saved settings**—The settings you save as you operate and configure the camera. When the camera reboots, it restores these settings. Changes made to any page since saving changes are lost.



# 🛞 Тір

Whenever possible, Teledyne FLIR recommends testing new settings before saving them because saving changes overwrites the previously saved settings.

## **View Settings**

 $\langle \mathbb{Q} \rangle$ 

Tip

When you make a change to most View Settings, the Reset and Save buttons become enabled. For some View Settings, the camera immediately applies the changes, but does not save them; for example, on the Visible Page and on the Thermal Page. For others, the camera does not apply changes until you save them.

Regardless of whether the camera has already applied changes, to save all changes since the last time these settings were saved, click Save. This can include earlier changes that were not saved.

If you try to navigate to a different page before saving changes, a confirmation message appears. In most cases, you can click **Continue**,

discarding the changes or saving them by clicking the close icon X.

which allows you to navigate to other pages and test the setting changes.

Then, you can return to the page and save the new settings. Or, you can discard the changes; save them; or close the confirmation message without

To restore previously saved settings or the factory default

settings, click Reset. To close the message and return to the page without restoring settings, click the close icon X.



When you make a change to most System Settings, the **Discard Changes** link and the **Save** button become enabled. For some System Settings, the camera immediately applies the changes, but does not save them; for example, on the

Alarm Page and on the Audio Page. For others, the camera does not apply changes until you save them.

Regardless of whether the camera has already applied changes, to save changes, click Save. To discard changes and restore previously saved settings or the factory default settings, click **Discard Changes**.

Changes to some System Settings require the camera to reboot; for example, on the Network Page and on the Date & Time Page. After clicking Save, a confirmation message appears. To save the changes, and reboot the camera with the changes applied, click Accept. To close the confirmation message and remain on th Cancel or c

remain on the page — without discarding the changes or saving them — click <b>Cancel</b> or click the close icon <b>X</b> .	Accept Cancel
Тір	
If you try to navigate away from the page before saving changes, a	Confirmation Required ×
and restore previously saved settings, click <b>Yes</b> . To close the confirmation message and remain on the page — without discarding	There are unsaved changes. Do you want to leave this page?
the changes or saving them — click <b>No</b> or click the close icon $\mathbf{X}$ .	Yes No





DISCARD CHANGES

Confirmation Required

There are changes not saved as

default. Please select how to proceed





# 3.4 Video Page

The camera provides four IP video streams: two visible streams (V1 and V2) and two thermal streams (T1 and T2). In general, modifying the default IP video settings is not necessary. In some cases, such as when a stream is sent over a wireless network, fine-tuning the streams can help reduce the bandwidth requirements.

To change the settings for a particular video stream, click the relevant button (V1, V2, T1, or T2).



- Use the default values initially. Then, incrementally modify and test individual parameters to determine when bandwidth and quality requirements are met.
- On the camera web page and in the camera's cloud web application, the live video is not an actual video stream. Changes to stream settings might not affect the live video. Before saving changes, Teledyne FLIR recommends checking them using a FLIR UVMS, client program, or third-party ONVIF system.

## V1 / V2

Codec options for the visible streams are H.264, H.265, or MJPEG.

Resolution options are 3840x2160 (4K), only available for V1 with H.264 or H.265; 1920x1080 (1080p); 1280x720 (720p); and 640x480 (480p). The Frame Rate range is 5-30 FPS (frames per second).

## T1 / T2

Codec options are H.264 or MJPEG.

Resolution options are 640x512 and 320x256 and the Frame Rate range is 5-30 FPS. 320x256 is the native resolution of the thermal imager in FH-3xx cameras. If you select 640x512, the FH-3xx camera upscales the thermal image stream to 640x512.

## Codecs, Quality, and Bandwidth

The codec determines which settings are available. The values of those settings can have a significant impact on the quality and bandwidth requirements of the video stream.

With the H.264 and H.265 codecs, you can set the:

#### • Profile:

- High Profile (default for H.264 and the only profile available for H.265)—Designed for HD TV applications, provides the best trade-off between storage size and video latency. Compared to Main Profile, it requires 10-12% less storage, but can experience increased latency, depending on the stream structure.
- Main Profile—Designed for SD TV applications, provides good picture quality over lower bandwidth.



- Rate Control:
  - CBR (constant bit rate)—The Bit Rate parameter defines the target bit rate; the camera attempts to keep the video at or near the target bit rate.
  - VBR (variable bit rate)—The Bit Rate parameter defines the average bit rate.
- I-frame Interval—Controls the number of P-frames used between I-frames. I-frames are full frames of video and the P-frames contain the changes that occurred since the last I-frame. A smaller I-Frame Interval results in higher bandwidth (more full frames sent) and better video quality. A higher I-frame Interval means fewer I-frames are sent and therefore can result in lower bandwidth and possibly lower quality.

With the MJPEG codec, you can set the Quality between 10-80. Setting a higher value can increase the video stream's bandwidth requirements.

#### Enable Multicast

By default, multicast is enabled. Multicast video packets are shared by streaming clients. Additional clients do not cause bandwidth to increase as dramatically as with unicast. Video stream requests for ch0/stream1 are unicast. Client-specific multicast requests vary according to the client.

Enable Multicast	Enable Multicast	Enable Multicast	Enable Multicast
Yes No	Yes No	Yes No	Yes No
Destination Address	Destination Address	Destination Address	Destination Address
224.1.1.1	224.1.1.2	224.1.1.3	224.1.1.4
Destination Port	Destination Port	Destination Port	Destination Port
50000	50002	50004	50006
TTL	TTL	TTL	TTL
3	3	3	3
Visible 1	Visible 2	Thermal 1	Thermal 2

If more than one camera is providing multicast streams on the network, make sure the Destination Network IP address is unique for each camera (the Destination Port can be reused). By default, the port assignment is unique per stream.

The time-to-live field controls the ability of IP packets to traverse network boundaries. A value of 1 restricts the stream to the same subnet. Greater values allow increasing access between networks.

The video streaming uses a protocol generally referred to as RTP, the real-time transport protocol, although there are actually a number of protocols involved, including the Real-Time Streaming Protocol (RTSP). The video stream URLs incorporate the IP address of the camera. Using the camera's default IP address, the complete URLs are:

- V1—rtsp://192.168.0.250:554/stream1
- V2—rtsp://192.168.0.250:554/stream2
- T1-rtsp://192.168.0.250:554/stream3
- T2-rtsp://192.168.0.250:554/stream4

To maintain compatibility with legacy systems, the stream names are aliased as: ch0 = stream1, ch1 = stream2, ch2 = stream3; and ch3 = stream4.

By default, RTSP authentication is enabled. To access any of the camera's video streams, you can use the name and password for any of the camera's users. Users assigned the role of admin or expert can disable RTSP authentication on the <u>Services</u>.

# 3.5 Visible Page



You can adjust the following visible video settings:

- Brightness
- Contrast (Max Gain)
- Hue
- Saturation
- Sharpness
- Focus
- Autofocus Push—Activates a one-time autofocus.

#### **Advanced Settings**

- Night Mode—Set the visible video to:
  - o Color (day mode)
  - o **B/W** (night mode)
  - Auto (default)—Automatically switches the visible video mode according to light level. When Night Mode is set to Auto, you can set the thresholds at which the visible video switches from black and white to color (Night to Day Threshold) and vice versa (Day to Night Threshold). Specify a value between 0-100, where 0 switches modes at a lower light level (darker) and 100 switches modes at a higher light level (brighter). You can also specify a Switch Time, the transition time between modes, to Slow, Normal, or Fast.

#### • Wide Dynamic Range

WDR improves the image quality and amount of detail in high contrast scenes. High contrast scenes consist of areas with different lighting conditions; some areas are bright and others are dark. Without WDR, either the bright areas would be overexposed (too bright) or the darker areas would be completely dark. WDR can produce more detail in both the dark and the bright areas of the image.

This setting enables and determines the level of digital Wide Dynamic Range (dWDR): Off, Low, Mid, or High. When dWDR is enabled, the camera digitally enhances the details in each frame. You can



increase the dWDR setting as the level of scene contrast increases. To enable and configure Shutter (True) WDR, see Exposure Mode below.

- White Balance—Set according to operating environment:
  - Auto (default)—Computes the white balance value output using color information from the entire screen. It is suitable for an environment with a light source color temperature in the range of approximately 2,700 ~ 7,500K.
  - ATW (Auto Tracking White Balance)—Automatically adjusts the white balance in a scene while temperature color is changing. It is suitable for an environment with a light source color temperature in the range of approximately 2,500 ~ 10,000K.
  - Manual—To activate the factory-optimized white balance setting, click One Push Trigger . Define the Rgain and Bgain between 0-100 to increase the red and blue luminance. This setting might not be ideal for every lighting environment.

White Balance	
Auto	~
Color Noise Reduction	
Off	~
2D Noise Reduction (D-100)	
	50
3D Noise Reduction (D-10D)	50
	50

#### Noise reduction settings

Noise reduction settings are used to reduce or eliminate artifacts that can limit the ability to positively identify an object. There are two types of noise: luminance and color (chroma) noise. 3D noise reduction and 2D noise reduction settings reduce luminance noise: dots of varying brightness levels (black, white, and gray). It is not recommended to completely eliminate luminance noise, which can result in unnatural images. The 3D Noise Reduction and 2D Noise Reduction settings should be configured after configuring Color Noise Reduction.

- Color Noise Reduction—Controls the noise appearing as red, green and blue dots between light and dark areas. Four settings are available: Off, Low, Mid, High. High maximizes the blending of the color noise with the image, effectively removing the dots, while Low minimizes the blending.
- 2D Noise Reduction—Analyzes individual frames pixel by pixel and frame by frame to eliminate environmental noise and deliver optimized image quality, especially in low-light conditions. 2D noise reduction tends to produce superior results for moving objects when applied to areas in the field of view where movement is present. However, it is less precise than 3D noise reduction. Specify a value between 0-100, where 0 provides no 2D noise reduction and 100 provides the maximum level of 2D noise reduction.
- 3D Noise Reduction—Provides superior noise reduction and is recommended for use in extra low-light conditions. It is especially useful for reducing blur with moving objects. 3D noise reduction reduces image noise/snow in low-light conditions by comparing adjacent frames. Specify a value between 0-100, where 0 provides no 3D noise reduction and 100 provides the maximum level of 3D noise reduction. Increasing the level 3D noise reduction can create more motion blur than 2D noise reduction on moving objects.
- **Backlight Compensation** (BLC)— By default, BLC is disabled and the camera's auto exposure algorithm considers the entire image. For images with a bright light source that puts the subject of interest in shadow or silhouette, enabling BLC and selecting the region of interest (ROI) can improve the image. With BLC enabled, the auto exposure algorithm considers only the selected ROI. You can select one of the following ROIs: Upper, Lower, Center 1/3, Center 1/6, Left, or Right.

When the Shutter WDR exposure mode is enabled, BLC cannot be enabled.

~
~



• **Gamma—**Ensures faithful reproduction of an image. Select 0.45 (default) or 1. When set to 1, the image displayed on your screen is the same as the original image.

#### • Exposure Mode

- **Auto Shutter**—A standard exposure mode that produces a natural image. Select a minimum and a maximum shutter speed.
  - Minimum Shutter Speed—Specify the slowest shutter speed based on the amount of light in the scene, speed of moving objects, and noise. If the scene includes fast-moving objects, Teledyne FLIR recommends specifying a minimum shutter speed faster than 1/25 or 1/30 seconds. The video format determines the minimum shutter speeds available, as shown, in fractions of a second:



Mode Settings

Minimum Shutter Speed - Auto Shutter Mode						
	NTSC			PAL		
1	1/200	1/4000	1	1/200	1/4000	
1/2	1/250	1/5000	1/2	1/250	1/5000	
1/4	1/400	1/8000	1/4	1/400	1/8000	
1/7.5	1/500	1/10000	1/6.25	1/500	1/10000	
1/15	1/800	1/12500	1/12.5	1/800	1/12500	
1/30	1/1000	1/16000	1/25	1/1000	1/16000	
1/60	1/2000	1/20000	1/50	1/2000	1/20000	
1/120	1/2500	1/25000	1/100	1/2500	1/25000	

• **Maximum Shutter Speed**—Select the fastest shutter speed based on the amount of light in the scene. A faster shutter speed decreases the amount of light entering the sensor and results in a darker image. The video format determines the maximum shutter speeds available, in fractions of a second:

Maximum Shutter Speed - Auto Shutter Mode					
	NTSC			PAL	
1/120	1/1000	1/10000	1/100	1/1000	1/10000

Maximum Shutter Speed - Auto Shutter Mode					
	NTSC			PAL	
1/200	1/2000	1/12500	1/200	1/2000	1/12500
1/250	1/2500	1/16000	1/250	1/2500	1/16000
1/400	1/4000	1/20000	1/400	1/4000	1/20000
1/500	1/5000	1/25000	1/500	1/5000	1/25000
1/800	1/8000	1/32000	1/800	1/8000	1/32000

• Shutter Priority—Specify a fixed shutter speed.

- Flickerless (default)—Eliminates flicker caused by fluorescent lighting in the screening area. Specify the mode.
  - Mode—Specify the power used for lighting the scene, 50Hz or 60Hz.
- Manual—Specify a fixed shutter speed and the gain.
  - Gain—A higher value increases the sensitivity of the image sensor, which brightens the image and adds details, but also increases the noise level. Specify a value between 0-100.

Shutter Speed - Shutter Priority and Manual Exposure Modes					
	NTSC			PAL	
1/7.5	1/500	1/10000	1	1/250	1/8000
1/15	1/800	1/12500	1/2	1/400	1/10000
1/30	1/1000	1/16000	1/4	1/500	1/12500
1/60	1/2000	1/20000	1/6.25	1/800	1/16000
1/120	1/2500	1/25000	1/12.5	1/1000	1/20000
1/200	1/4000	1/32000	1/25	1/2000	1/25000
1/250	1/5000		1/50	1/2500	1/32000
1/400	1/8000		1/100	1/4000	
			1/200	1/5000	

 Shutter WDR—Enables True WDR. The camera analyzes the exposure and level of detail in multiple frames taken at multiple exposure settings and shutter speeds; determines the optimal combination of regions within the scene; and generates a single, composite frame with wide dynamic range. When Shutter WDR is not enabled, the camera operates in linear mode; that is, the camera streams every visible frame it takes.

When you change the Shutter Mode, the camera immediately applies the new setting. When you change the Shutter Mode to or from Shutter WDR, it can take a few seconds for the camera to apply the new setting.



Shutter WDR Exposure Mode Settings

#### • Enhanced WDR Level

• 2x (default)—For each frame the camera streams, it analyzes and combines two frames.

- **3x**—For each frame the camera streams, it analyzes and combines three frames. The camera can stream up to 15 fps, regardless of the Frame Rate setting on the Video page.
- Exposure Comp. (compensation; not available in Manual exposure mode)—0 (no compensation) by default. You can specify whether the camera's auto exposure algorithm produces a brighter or darker image by digitally adjusting the camera's F/# and shutter speed. You can specify a value between -2 (darkest) and +2 (brightest), in 1/3 increments.

# 3.6 Thermal Page

In most installations, changing the default settings of the thermal imager is not necessary. However, in some situations and depending on scene, modifying one or more parameters can improve the image. Be aware that, when conditions change, you might need to adjust the parameters again. Teledyne FLIR recommends knowing how to restore the factory default settings (see <u>Firmware & Info Page</u>).



## AGC ROI

By default, **Show AGC ROI** is selected. The AGC ROI (region of interest) overlay appears in the live video on the camera web page. In video streams, the overlay does not appear. By default, the ROI is full screen; the AGC algorithm considers the entire image. In some cases, defining an ROI that excludes a portion of the screen can improve the image. For example, you can define an AGC ROI that excludes the sky, which is cold and can strongly affect the overall image.

# Caution

The camera's thermal video analytics rely on accurate and useful AGC settings. Changes to the ROI can affect those analytics.

## Defining a custom AGC ROI

To change the size of the ROI: Hover over the handle in the bottom-right corner of the ROI, and then click and drag it.

To move the entire ROI: Hover over the ROI, and then click and drag it.



#### AGC Image Settings

In some cases, changing the AGC image settings can provide a better image, depending on personal preferences, display devices, and so on.

- **Brightness** (Gamma)—Determines the allocation of the 256 "shades of gray" produced by the AGC. Values above 50 allocate more shades of gray to hotter objects, while values below 50 allocate more shades of gray to lower temperature objects. Range 0 to 100.
- **Contrast** (Max Gain)—Increasing contrast can provide a better image, especially for scenes with little temperature variation. (It might also increase noise due to the increased gain.) Range 0 to 100.



Changes to the default contrast setting affect scenes with little temperature variation more than they affect scenes with greater temperature variation.

- **Sharpness** (DDE Gain)—Enhances image details and/or suppresses fixed pattern noise. Range 0 to 100.
- AGC Filter—Determines how quickly a scene adjusts when a hot object appears (or disappears) within the AGC ROI. If set to a low value, when a hot object enters the ROI, the AGC will adjust more slowly to the hot object, resulting in a more gradual transition. Range 0 to 100.
- **Palette**—Select the color palette the camera uses to indicate detected levels of thermal energy. WhiteHot and BlackHot are gray-scale palettes; other palettes assign different colors to different temperatures. When video analytics are enabled for thermal video on the <u>Video Analytics Page</u>, use the WhiteHot color palette.

#### FFC (Flat-Field Correction)

At regular intervals or when the ambient temperature changes, the camera automatically performs FFC (also known as Non-Uniformity Correction or NUC). However, you can also manually trigger FFC by clicking **Perform FFC**. The shutter for the thermal imager closes and provides a target of uniform temperature, allowing the thermal imager to correct for ambient temperature changes and provide the best possible image. The thermal image momentarily freezes.

# 3.7 Illumination Page

When external illumination is enabled, the Illumination page is available. Users assigned the admin or expert role can enable external illumination on the <u>Firmware & Info Page</u>.

By default, infrared illumination is set to Auto; when the scene becomes dark enough, the visible camera video changes from day mode (color) to night mode (black and white) and turns on the external infrared illumination, using the ALARM OUT 2 connection (see <u>Connect the Camera</u>). Likewise, when the scene becomes light enough, the visible camera video changes from night mode to day mode and turns off the external infrared illumination. You can specify the visible camera's Night Mode setting and adjust the night-to-day and day-to-night thresholds on the Visible Page.



You can set the external infrared illumination to Off. Doing so does not affect the visible camera's Night Mode setting.

# 3.8 Input/Output (I/O) Page

On the I/O page, you can:

• Enable, disable, and configure the camera's local I/O pins.



Keep in mind that, when enabled, the camera's external illumination setting controls output 2.

For information about the local I/O connector, see <u>Connect the Camera</u>.



• Enable and disable the camera's external I/O output pins.

On the <u>I/O Devices Page</u> in System Settings, users assigned the admin or expert role can configure the camera's external I/O connections and the device managing those connections with the camera.



# 3.9 Radiometry Page (R models)

FH-Series R models detect, measure, and monitor surface temperatures. Because using a thermal camera for reasonably accurate and precise temperature measurements requires at least a minimum level of expertise in thermography, Teledyne FLIR recommends training. The Infrared Training Center (<u>http://www.infraredtraining.com/</u>) offers training (including online training) and certification in all aspects of thermography.

On the Radiometry page, you can create up to four radiometric items. Each item can:

- detect the surface temperature in a specific spot in the camera's field of view
- detect temperatures over a defined area (box)
- · detect the difference in temperatures between two spot or box items

For each item, you can enable and disable temperature measurement and alarms, and specify the alarm condition and threshold. Users assigned the admin or expert role can create and configure alarm rules and actions triggered by these alarm conditions. For more information about creating and configuring alarms, see <u>Alarm Page</u>.

		hable radioffied y	
	Enable	FH-644 R QA644	Stream: <b>Thermal</b>
	Yes No		TT-
	Units		-
	Vehicle Detection Filter	and the second	
Radiometry	On Off		
	Radiometric Data 🔿	A1-V	
	Name Min Max Avg		
	Refresh	- A Day of the second s	
	Radiometric Items		12
	Ф 🛄 А-В		
	Click to create a		
	radiometric item		STP.

## Click to enable radiometry
Enable the camera's radiometry features and then select the temperature units (Kelvin, Celsius, or Fahrenheit).

#### **Vehicle Detection Filter**

The vehicle detection filter prevents vehicles from triggering false radiometric alarms. It requires vehicle classification to be enabled on one or more loitering regions on the thermal video. Defining loitering regions makes sure the camera's video analytics continue to track moving vehicles that become stationary. Also, make sure that the loitering regions match the radiometric boxes. See <u>Video Analytics Page</u>.

### To create, enable, and configure radiometric items:

1. Under Radiometric Items, click the spot icon ↔, the box icon □, or the differential item icon A-B.

The item appears in the Radiometric Items list. Spot and box items appear in the center of the live thermal video image.

2. Move spot and box items to the desired location. Hover over the item, and then click and drag it.

To change the size or shape of a box, click one of the corners and then drag it.

3. For differential items, the Add Radiometric Diff screen appears. Select the spots or boxes to compare.

For boxes, select the type of temperature measurement to compare (Minimum, Maximum, or Average), and then click **Save**. The differential item appears in the Radiometric Items list.

- 4. With the item selected, you can edit the name of the item, delete it, or configure it.
- 5. Enable temperature measurement for the item. Radiometric data appears.

For spots, the surface temperature detected at the spot appears under Avg. For boxes, the minimum, maximum, and average temperatures detected in the box appear. For differential items, the difference in detected temperatures appears.

In the Radiometric Items list, a red check icon indicates that temperature measurement is enabled for the item. To toggle temperature measurement for an item, click the check icon.

## **Alarm Settings**

For each item, you can configure the following alarm settings:

- Enable—Enables alarms for the item.
- **Result**—Determines the data that triggers an alarm. For a spot, the alarm result is the Value of the temperature detected at the spot. For a box, select one of the following:
  - Avg—The average of the temperatures detected in the box.
  - Min—The minimum temperature detected in the box.
  - Max—The maximum temperature detected in the box.

Add Radiometric Diff	×
First Element	
Box 1 🗸	
Measure	
Minimum Temperature 🗸 🗸	
Minimum Temperature	
Average Temperature	
Measure	
Minimum Temperature 🗸 🗸	
	-1
Save	



- **Condition**—You can select whether a detected temperature Above, Below, or Matches the alarm threshold value triggers an alarm.
- **Threshold**—Specify a temperature value in degrees Kelvin, Celsius, or Fahrenheit, depending on the setting above.
- **Hysteresis**—Specify the number of degrees above or below the Threshold within which the camera does not clear the alarm. For example, the Condition is set to Above, the Threshold is set to 30°C, and the hysteresis is set at 2°C. When the detected temperature rises above 30°C, the camera triggers an alarm until the detected temperature drops below 28°C.

Likewise, if the Condition is set to Below, the Threshold is set to 30°C, the hysteresis is set at 2°C, and the temperature drops below 30°C, the camera triggers an alarm until the detected temperature rises above 32°C.

• **Hysteresis Time**—Specify the amount of time in seconds that must pass before the camera triggers an alarm, after the alarm condition and threshold have been met. This can be a powerful tool for avoiding false alarms.

## 3.10 Video Analytics Page

The camera's advanced onboard video analytics:

- Incorporate convolutional neural networks (CNN) technology
- Intrusion and loitering detection
- Classify detected objects as human or vehicle
- Can be configured separately for the visible video and for the thermal video

	< Enable	FH-644 QAdvt	Stream: Visible	Overlay Settings <
	Yes No		and the second s	Overlay Enable
	Auto Mode		T T	Yes No
_	On Off		All a state of the	Zones
	Mode			Yes No
Video Analytics	Visible Thermal			Human Tracks
-	Visible Thermal		The second s	Yes No
				Vehicle Tracks
	Calibration	and a second strend prove a second		Yes No
	Installation Height and Tilt angle must be configured in Georeference			Show Class
	Bisplay Target		and a special second seco	Yes No
	Display larger			Show Lines
	Add Region			Yes No
	🕶 🎞 📜	0		Show Boxes
				Yes No
				Show Triggered
				Yes No
				Streams
	Overlay Settings $\vee$			V1 V2 V1 T1 T2

On the Video Analytics page, you can:

- Enable or disable the analytics—By default, analytics are disabled. When enabling video analytics for thermal video, use the WhiteHot color palette (see <u>Thermal Page</u>).
- Turn the Auto mode on or off—When enabled, the camera's onboard analytics automatically switch between the visible video (day mode) and the thermal video (night mode), according to the amount of light in the field of view.
- Enable the video analytics on only the visible video or only on the thermal video.
- Check the analytics calibration on both the visible and the thermal video.

- For both the visible and thermal video, <u>create and configure tripwires</u>, <u>intrusion detection or loitering</u> <u>regions</u>, <u>and masking regions</u>. By default, tripwires or regions have not been defined, and <u>alarm rules</u> are disabled.
- Enable and configure the analytics tracking overlay.

The camera immediately applies and saves changes to settings on the Video Analytics page, affecting the live video images, video streams, and analog video output.

### **Detection and Classification**

The camera's video analytics detect intrusion or loitering and classify detected objects separately for each region. In the analytics tracking overlay, H indicates a detected and classified human; V indicates a vehicle.

### **Overlay Settings**

Enable and configure the video analytics tracking overlay in the video streams. You can enable or disable the following:

Overlay Setting	Description		Comments	
Enable	Globally enable overlay.	or disable the analytics	Enable one or more individual video streams.	
Zones	Show intrusion i and tripwires.	regions, loitering regions,		
Human Tracks	Show detected humans.	objects classified as	Enable Show Class, Show Lines, or	
Vehicle Tracks	Show detected vehicles.	objects classified as	Show Boxes.	
Show Class	Show Class When tracks are enabled, show the classification of the detected objects: human (H) or vehicle (V).			
Show Lines	When tracks are enabled, show the lines for the detected objects according to positions from prior frames; helps visually represent speed and direction.		Enable Human Tracks or Vehicle Tracks.	
Show Boxes	w Boxes When tracks are enabled, show a box around the track.			
Show Triggered Show tracks only when they are active; that is, when they are triggering a tripwire, intrusion, or loitering alarm.		Enable Human Tracks or Vehicle Tracks. Enable Show Class, Show Lines, or Show Boxes.		
Streams V1 V2 V T1 V T2		Enable the analytics tracking overlay for individual video streams.	<ul> <li>Does not override the global analytics overlay Enable setting above. For the overlay to appear in a stream, the global setting and the stream must be enabled.</li> <li>The live video on the camera's web page is not the actual video stream. Therefore, enabling the tracking overlay for a stream might not affect the live video.</li> </ul>	

### To configure the camera's video analytics:

- 1. Make sure the camera is mounted in its final location and properly aimed.
- 2. On the Georeference Page, specify the camera's installation height, tilt angle, and roll angle.
- 3. Enable the analytics overlay.
- 4. Check the Analytics Calibration.
- 5. Create Analytics Regions.

Users assigned the expert or admin role can enable, modify, or define alarm rules on the Alarm Page.

## 3.10.1 Check the Analytics Calibration

Before you can check the camera's video analytics calibration, you need to specify the camera's installation height, tilt angle, and roll angle on the <u>Georeference Page</u>.

- 1. Make sure that a person about 1.8m (5" 11') tall is in the camera's field of view.
- 2. On the Visible tab of the Video Analytics page, make sure analytics are enabled.
- 3. Expand Overlay Settings, and make sure Overlay Enable is **On**.
- 4. Click **Display Target**. A box simulating a 1.8m (5" 11') human appears in the live video for about 10 seconds and then automatically disappears. Make sure the height of the box corresponds to the size of the person standing in the camera's field of view.



Checking Calibration - Visible

# 😨 Tip

If the height of the box does not correspond to the size of the person:

- On the <u>Georeference Page</u>, verify the camera's installation height, tilt angle, and roll angle.
- On the <u>Boresight Page</u>, verify the visible and thermal video vertical fields of view are properly aligned.
- 5. Open the Thermal tab, make sure the analytics are enabled, and repeat the previous steps.

## 3.10.2 Create Analytics Regions

Create separate analytics regions for the visible video and for the thermal video; for example, to define separate regions according to the time of day. You can also create a masking region; a region that does not generate intrusion alarms.

The mode and tab selected determine the tripwires, regions, and labels that appear in the live video. The tab selected determines the live video, the regions that you can create and modify, and the labels that appear in the live video (when the analytics overlay is enabled).

	Tab &	Tripwires and Regions						
Mode Live		Visible		Thermal				
	Video	Create / Modify	Labels	Create / Modify	Labels			
Visible	Visible	Vaa	Yes	N	/Α			
Thermal	Visible	Tes	No	No	Yes			
Thermal	Thermal	N	/A	Vaa	Yes			
Visible	Thermal	No	Yes	res	No			

When the analytics overlay is enabled for the Video Analytics page live video, tripwires and analytics regions are labeled according to analytics region type, T = Tripwire or A = Area (intrusion / loitering); unique region ID number; and video image type, T = thermal or V = visible. For example, T1-T = Tripwire 1 on the thermal video and A3-V = Area 3 on the visible video.

### To create a region:

- 1. Select either the Visible or the Thermal tab.
- 2. Under Add Region, click the appropriate icon to create a tripwire; an intrusion or loitering detection area; or a masking region.



When creating a tripwire, draw it from left to right; this ensures the one-way arrows on the Direction buttons and in the analytics overlay visible.

- 3. Specify each point of the region by clicking and releasing on the live video image. Do not click and drag. Also, do not draw one region line or border over another. For tripwires, the maximum number of points is 16.
- 4. To finish creating the region, double-click on the last point.



Creating a Tripwire on the Visible Video

# Tips

- Remember to create analytics regions for both the visible and thermal video images, if desired.
- To cancel creating a region, press Esc.
- To modify the settings for or to delete an existing region, click the region either in the region list or in the live video image.
  - To move or adjust the region points, tripwires, or an entire region, click on a point, line, or border, and drag.
  - $\circ$  To delete a region, click the trash icon  $\Box$ .



After creating a region, you can configure the following:

Region type	Direction	Human and Vehicle Classification	Loitering Time
Tripwires	•	•	
Intrusion		•	
Loitering		•	•
Masking		N/A	



Configuring a Region

After drawing at least two tripwires or detection areas for either the visible or the thermal video images, you can establish dependency between them.

**Tripwires**—The direction over a tripwire is controlled by the configured direction, and also by the direction in which the tripwire line was drawn. A direction to the right is to the right of a person moving from the first point to the second point of the line, and so on.

**Masking regions**—The region of the video image that does not generate alarms. For example, to eliminate alarms from trees or bushes moving in the wind. You can create a total of two masking regions for both the visible and thermal video; that is, you can create one masking region for each or two for either the visible or the thermal video.



The camera provides intrusion detection masking, not privacy masking. Analytics are disabled for masking regions, and the camera does not generate alarms. However, the region itself appears in the video image.

#### To establish dependency between two regions:

- 1. Select a region and then click **Set Dependency**.
- 2. Select the region dependent on the previously selected region.
- 3. Define the amount of time during which an object triggers an alarm if it is detected by both regions.
- 4. Click Save.

### To remove a dependency:

Click the link icon corresponding to the dependent region.

	Dependency	×	]
	Region dependent on Area 2	Tripwire 1	
	Time interval (sec.) (	0	
	Save	Cancel	
Tripwire 1 Area 2 Loitering 4 Masking 1	Ū 00	Click t depen	o remove dency

## 3.11 OSD Page

For each IP video stream (V1, V2, T1, and T2) and for the analog video output (AV), you can:

- Enable or disable the camera's on-screen display (OSD)
- Enable or disable the camera name
- Enable or disable the date & time

You can also specify:

- Text Color—Black or white, with or without a background
- Font Size—Small, medium, big, or giant
- Position Camera Name—Top or bottom; left, center, or right
- Position Date & Time—Top or bottom; left, center, or right
- Bold text

When OSD is enabled for the V1 or T1 stream, the OSD appears in the live video on the camera web page. Enabling OSD on the V2 or T2 stream, or on the analog video, does not affect the live video on the camera web page.



## 3.12 Georeference Page

You can specify the camera's geographical location and mounting position:

- Latitude, in degrees North or South
- Longitude, in degrees East or West

To obtain the camera's latitude and longitude, use a map or a mobile GPS device.

- Ground Altitude, in meters above or below sea level
- Installation Height, in meters above the ground (must be greater than zero)

	Latitudo			<
	34	N	~	
	Longitude			
	0	Е	~	
	Ground Altitude (meters)			
	0			
	Installation Height (meters)			
Georeference	4			
	Installation Tilt (degrees)			
	-15			
	Installation Roll (degrees)			
	0			
	Orientation (degrees)			
	0			
	Gyroscope			
	Installation Tilt (degrees) -1.	3		
	Installation Roll (degrees) 0.2	21		
	Сору			

Installation Tilt	Installation Roll	Orientation
The vertical angle of the camera; when a camera is pointing down (below horizontal), the tilt angle is negative.	The horizontal rotation angle of the camera; facing a camera leaning to the right, the roll angle is negative. Teledyne FLIR recommends mounting the camera with a 0° installation roll angle. For accurate video analytics, mount the camera with an installation roll angle within $\pm 5^{\circ}$ .	The direction the camera is pointing, between 0-360 degrees from North.
0° ¢FLIR		N - 0° W - 270° E - 90° S - 180°

• **Gyroscope**—You can copy the camera's installation tilt and installation roll angles from the camera's onboard gyroscope.



The camera's configuration files do not store factory default Georeference settings. To restore Georeference settings to the camera's factory condition, manually change them to zero (0).

# 4 Configuration

Users assigned the admin or expert role can click **System Settings** on the <u>View Settings Home Page</u> to access the following configuration pages:

- Network Page
- Date & Time Page
- Users Page
- Alarm Page
- <u>Audio Page</u>
- I/O Devices Page
- <u>Messaging Page</u>
- Heaters & Fans Page

- Cyber Page
- ONVIF Page
- Map Page
- Boresight Page
- <u>Scheduler Page</u>
- <u>Recording Page</u>
- Firmware & Info Page

In addition, Triton FH-Series cameras can hand-off detection events to a supported PTZ camera using an ioi PTZ Tracker (trk-101-P). For information about how to configure the PTZ Tracker for this hand-off, see <u>Configuring PTZ Hand-Off</u>.

For information about making, apply, and saving changes on System Settings pages, see <u>Making</u> <u>Changes to Settings</u>.

## 4.1 Network Page

When a user assigned the expert or admin role clicks **System Settings**, the Network page appears.

NETWORK		
DHCP Static		
Hostname Mode		
Static	~	
Hostname		
IP		
Netmask		
Gateway		
DNS Mode		
DHCP	·	
Name Server 1		
Name Server 2		
MTU		
1500		
Ethernet Speed		
100Mbps	~	
< BACK TO VIEW SETTINGS -	-View Settings	DISCARD CHANGES SAVE

If you do not know how to configure these settings, contact your network administrator.

The DHCP (default) and Static buttons at the top of the Network page specify the IP address mode. If the IP address mode is set to DHCP but a DHCP server is not available on the network, the camera's IP address defaults to 192.168.0.250.

If the IP address mode selected is Static, specify:

• IP—The camera's IP address.

# **A** Caution

After changing the camera's IP address, the PC you are using to access the camera's web page might no longer be on the same network as the camera and can no longer access the camera's web page. To access the camera web page again, change the PC's IP address to be on the same network as the camera.

- Netmask—The default value is 255.255.255.0.
- Gateway

The Hostname Mode can be set to DHCP or Static (default); if set to Static, specify the hostname for the camera's server.

• **DNS Mode**—When the IP address mode is DHCP, you can set the DNS Mode to DHCP or Static. When the IP address mode is Static, the DNS Mode is also Static.

When the DNS Mode is set to Static, specify:

- o Name Server 1—The primary domain name server that translates host names into IP addresses.
- Name Server 2—A secondary domain name server that backs up the primary DNS.

You can also specify the:

- **MTU**—Maximum transmission unit, the largest amount of data that can be transferred in one physical frame on the network. For Ethernet, the MTU is 1500 bytes (the default setting). For PPPoE, the MTU is 1492. Valid values are 1000-1500.
- Ethernet Speed—When set to 100Mbps (default), the camera supports 100Mbps. When set to Auto, the camera supports 100/1000 Mbps.

## 4.2 Date & Time Page

The camera can obtain the date, time, and time zone from an NTP server.



When DHCP IP addressing is enabled on the <u>Network Page</u>, you can configure the camera to obtain the NTP server information from the DHCP server.

To manually specify one or more NTP server addresses, under NTP Server, click **Manual** and specify the address(es). Use a comma to separate more than one addresses.

#### To manually configure the camera's time zone, time, and date:

- 1. At the top of the page, click Manual.
- 2. Specify the time zone and whether it is currently daylight saving time.
- 3. Copy the local PC's time or specify the hour, minute, second, AM or PM, and date.

Manual configuration		Copy PC time						C time
NTP Manual		OPY	РСТІМ	E	PC	Time	: 10:42:0	02 AM 02/15/2021
Time Zone	Time							
Asia/Jerusalem (UTC+02:00)	10		26	55	AM		РМ	
Daylight Saving	Date					S	ele	ct date pop-u
On Off	02/	15/20	021			~		
	0		Feb	ruary	2021		0	
Current time: 10:26:58 AM	Su	Mo	ти	We	Th	Fr	Sa	
			1 2	3	4	5	6	
	7		8 9	10	11	12	13	
	14	1	5 16	17	18	19	20	
	21	2	2 23	24	25	26	27	
	28							

Tip

Email notifications and other camera features require configuring the camera's system time to be the current time. You can configure email notifications on the <u>Messaging Page</u>.

## 4.3 Users Page

Only users assigned the admin role can add users and change or set all passwords.

-	USERS	_	
User Name	Role	Actions	
admin	admin	Ø Ū	—Delete user
ADD USER -	Add user	Edituser	

Users assigned the expert role only see the user currently logged in, and cannot add, edit, or delete a user.

To maintain security of the system, set up user names and passwords for each required login account.

The camera limits user name length to 29 characters. Passwords must be at least 12 characters; must contain at least one number, one lowercase letter, and one uppercase letter; and can include the following special characters:  $|@#~!$&<>+_-,*?=$ .

Assign one of the following roles, according to the level of access the user requires:

Role	user	expert	admin
Access	<ul> <li>Can:</li> <li>View live video</li> <li>Switch between visible and thermal live video</li> <li>View the Help page</li> <li>Log out</li> </ul>	Can access and use all View Settings and System Settings pages, menus, controls, and settings, except the Users page.	Can access and use all of the radar's web pages, including the Users page (but cannot delete the default admin user).
	When the camera's video streat password for any camera user	ams require RTSP authenticatio . All roles have access the came	n, you can use the name and era's video streams.





To keep the existing password, leave the password fields empty.



User Name	Role	Actions		
admin	admin	0 1		
expert	expert	Ø Ū	Click trach can icon	You are deleting a user
user	user	00	Click trash can icon	Are you sure you want to delete darose?
darose	user	~ <u>B</u>	Click to confirm ——	Delete user No
ADD USER				

## 4.4 Alarm Page

You can define camera alarms to be triggered by the following:

- The camera's onboard video analytics
- The camera's radiometry (R models)
- Video analytics from a supported remote camera or other device
- A supported radar
- Local or external I/O connections

For each alarm, you can specify one or more of the following actions:

- Record a snapshot of the video
- Send a notification email
- Arm/disarm the camera's video analytics (available when analytics are not a rule trigger)
- Change the state of local or external I/O connections

By default, the following rules are defined and disabled:

• **0. Video analytics trigger email**—The camera's video analytics trigger a notification email. Set up and configure the messaging settings on the <u>Messaging Page</u>.

ALARM	1
Click to edit	Click to toggle
0. Video analytics trigger email	DISABLED
1. Video analytics change output state	DISABLED
2. Input arms / disarms analytics	DISABLED
3. Undefined 1	DISABLED
4. Undefined 2	DISABLED
5. Undefined 3	DISABLED

- 1. Video analytics change output state—The camera's video analytics trigger a change to the state of an local alarm output connector. If the idle state of the connector is Closed, the alarm changes the state to Open. Likewise, if the idle state is Open, the alarm changes the state to Closed. For information about configuring the idle state of the camera's local I/O connector pins, see <u>Input/Output</u> (I/O) Page.
- 2. Input arms / disarms analytics—The camera enables or disables the onboard video analytics according to the state of the local alarm input connector.

You can modify the name, trigger, and action for the default rules. For example, you can modify the **Video analytics changes output state** rule so that it changes the state of an external output connected VMS system, instead of the state of an alarm out local I/O connector.

You can also define and enable three additional rules (**3. Undefined 1**, **4. Undefined 2**, and **5. Undefined 3**).

You can use the ID number identifying each rule (0-5) to schedule a task that switches alarm rules on or off. For more information, see <u>Scheduler Page</u>.

### To modify an existing alarm rule or define an alarm rule:

- 1. Click the alarm name. The rule trigger settings appear.
- 2. Modifying or Defining Rule Triggers
- 3. Modifying or Defining Rule Actions

Enable or disable a rule by clicking **Enabled** or **Disabled**.

## 4.4.1 Modifying or Defining Rule Triggers

Rule Name Undefined 1		×
Trigger		Action
e Local	O Remote	
● Video Analytics ○ I/O		
Choose VA trigger		
Area 1 (Visible)		
Select all	Clear	
		Next

## To modify or define alarm rule triggers:

- 1. Modify or define the rule name.
- 2. Select whether the triggers are local (onboard the camera) or remote (external):

		L	Local Triggers
Video Analytics	This FH-Series camera's onboard video analytics trigger this rule's action.	a. b.	On the <u>Video Analytics Page</u> , make sure tripwires and intrusion detection / loitering regions have been defined. Select the tripwires or regions that trigger this rule's action.
<b>Radiometry</b> (R models)	This camera's radiometry triggers this rule's action.	a. b.	On the <u>Radiometry Page (R models)</u> , make sure at least one measurement item has been defined. Select one or more measurement items that trigger this rule's action.

		Local Triggers	
	<b>Local</b> —This camera's local I/O connections trigger this rule's action.	<ul> <li>a. On the <u>Input/Output (I/O) Page</u>, make sure local I/O connectors have been properly configured.</li> <li>b. Select one or more local I/O connections that trigger th rule's action. Keep in mind that, when enabled, the camera's external illumination setting controls Out2.</li> </ul>	this
I/O	<b>External—</b> This camera's external I/O connections trigger this rule's action.	<ul> <li>a. On the <u>Input/Output (I/O) Page</u> and on the <u>I/O Devices</u> <u>Page</u>, make sure the external I/O connections and the device managing those connections with the camera have been properly configured.</li> <li>b. Select one or more external I/O connections that trigge this rule's action.</li> </ul>	e ger



Specifying a trigger for an alarm rule and enabling the rule does *not* enable alarms for the trigger. Make sure video analytics have been enabled.

- For Video Analytics triggers, make sure video analytics are enabled.
- For Radiometry triggers, make sure radiometry is enabled, temperature measurement for the trigger is enabled, and that alarms for it are enabled.

## **Remote Triggers**

<ul> <li>a. Under Discovered Devices, select the remote came menu of supported devices on the same network as Or, you can manually specify the remote device IP a menu of discovered devices, click <b>Refresh</b>. For exa to the same network as the camera.</li> <li>b. Select Video Analytics or Radar.</li> </ul>	ra, radar, or other device from the drop-down the camera; its IP address and port appear. address and port. To refresh the drop-down mple, if you just connected the remote device				
Video Analytics—Video analytics from a remote camera or other device triggers an alarm.	Radar—A remote radar triggers an alarm.				
<ul> <li>a. On the remote device, make sure video analytics are enabled and that tripwires, intrusion detection / loitering regions, and other analytics items have been defined.</li> <li>b. Select the video analytics items that trigger this rule's action.</li> </ul>	<ul> <li>a. On the radar, make sure alarm areas and tripwires, and other analytics areas, have been defined.</li> <li>b. Select the radar areas that trigger this rule's action.</li> </ul>				

- 3. Click **Next**. The rule action settings appear.
- 4. Continue with Modifying or Defining Rule Actions.

## 4.4.2 Modifying or Defining Rule Actions

Rule Name Undefined 1		×
Trigger		Action
Action Type UO Email Snapshot	I/D List	
	Uvisible) Bound	
Beck		Done

**427-0102-00-10 - Revision 110 - November 2021** This document does not contain any export-controlled information.

## To modify or define alarm rule actions:

1. For the alarm rule you are modifying or defining, select an action type:

	Action Type
	Under I/O List, select Local or External.
	<ul> <li>Local—This rule changes the state of local I/O connectors.</li> <li>a. On the <u>Input/Output (I/O) Page</u>, make sure local I/O connectors have been properly configured.</li> <li>b. For each trigger defined for the alarm rule, select the local output that changes. Keep in mind that, when enabled, the camera's external illumination setting controls Out2.</li> </ul>
I/O	<ul> <li>External—This rule changes the state of external I/O connections.</li> <li>a. On the <u>Input/Output (I/O) Page</u> and on the <u>I/O Devices Page</u> pages, make sure the external I/O connections and the device managing those connections with the camera have been properly configured.</li> <li>b. For every trigger defined for the alarm rule, select the external I/O connection that changes.</li> </ul>
	Тір
	You can map individual local or remote triggers to specific local or external outputs.
Bound	When selected, the camera changes the state of the output when the alarm is triggered and when it is cleared. When not selected, the camera changes the state of the output when the alarm is triggered. However, the output state remains changed until it is reset according to the configured Reset Interval or by a command from the network. You can configure the Reset Interval for the local outputs on the <u>Input/Output (I/O) Page</u> and for the external outputs on the <u>I/O Devices Page</u> .
Arm/Disa this rule to	<b>Irm Analytics</b> (not available when this rule's trigger is Video Analytics)—When triggered, oggles the camera's onboard video analytics from enabled to disabled or vice versa.
Email—W Messagin email. If y camera se snapshot	/hen triggered, this rule sends a notification email according to the settings on the <u>g Page</u> . Specify a subject for the email and whether the camera attaches a snapshot to the ou select Attach Snapshot, and if a thermal and a visible VA trigger are selected, the ends two emails: one with the snapshot from the thermal video and another with the from the visible video.
Snapsho recording see the de	t—When triggered, this rule records a snapshot image of live video according to the settings configured by an ONVIF client. For information about configuring those settings, ocumentation for the ONVIF client.

## 2. Click Done.

## 4.5 Audio Page

The Audio page provides configuration settings for and information about the camera's audio input and output features.

On Off		
Audio in		Cashia Multiana
Gain (0-100)	80	
Encoding	90	on on
G.711	~	
Bit Rate (Kbps)		
64	~	
Sample rate (kHz)		
8	~	
Audio out		Found

The On/Off buttons affect all audio input and output. For example, turning audio off immediately turns off all camera audio.

### Audio In

When audio is On, the following audio input settings appear:

- Gain—You can adjust the audio input gain from 0-100 percent. The default is 90 percent.
- Encoding—G.711.
- Bit Rate—The camera supports an audio input bit rate of 64 kilobits per second (kbps).
- Sampling Rate—The camera supports a sample rate of 8 kHz.
- Enable Multicast—Can be set to On or Off (default). When On, specify the destination address and port, and the time-to-live (TTL).

#### Audio Out

When audio is On, you can adjust the audio line output gain from 0-100 percent. The default is 80 percent.



- Test whether the camera's audio output is functioning properly by clicking Play.
- If you are monitoring the audio IP output with a video stream and change any of the audio configuration settings except gain, restart the stream. For example, if you are monitoring a video stream and turn audio on, you need to restart the stream to hear the audio with the stream.

## 4.6 I/O Devices Page

On the I/O Devices page, you can configure the camera's external I/O connections and the device managing those connections with the camera.

			_	I/O D	EVICES					
Enabled	led			I/O pir	IS					
Device IP				Numbe	ir of input p	ins 3	~	Numbe	r of output pins	3 ~
Address	Port									Refres
127.0.0.1	502			1/0	Туре	State	Idle State	Alarm Auto Ack	Enabled	Reset interval (seconds)
Input base address 0		Output base address 0		0	Input	Off	Oper Y	NO Y	YES 🗸	
			1	Input	Off	Oper 🗸	NO Y	YES 🗸		
			2	Input	Off	Oper Y	NO Y	YES ¥		
				3	Output	Off	Opei Y	NO Y	YES ¥	0
				4	Output	Off	Oper Y	NO Y	YES ¥	0
									NED	0

You can configure the following for the device managing the external I/O connections are available:

- Enabled or Disabled
- Device IP address and port
- Input and output base addresses
- The number of input and output pins the device manages

For each pin, the following information appears and you can confgure:

- I/O pin number
- Type—Input or Output
- State-the pin's current state: Open or Closed
- Idle State—Normally Open or Normally Closed
- Alarm Auto Ack-Yes or No
- Enabled—Yes or No
- Reset Interval (for output pins only)—between 0-600 seconds; to disable auto reset for an output pin, select 0

For more information about how to configure the device managing the external I/O connections, refer to the device's documentation.

## 4.7 Messaging Page

As <u>an action for an alarm rule</u>, the camera can send a notification email using the mail server settings you can configure on the Messaging page.

	MESSAGING	5	
Email	Mail Server Configuration		
	Email notifications require config Server IP Address	uring the came	ra's system time to be the current time on the Date & Time Page User Name
	smtp.example.com		user@example.com
	Server SMTP Port 587		Password
	Authentication		From Address
	Yes	~	from_address@example.com
	TLS Authentication		
	Yes	~	
	Notification List		
	Email Addresses		Test
	to_address@example.com		Send

Specify the settings for the SMTP server in the appropriate fields. Settings include the SMTP server's IP address; port (the default port is 587); user name and password for the account on the mail server; whether the mail server requires authentication or TLS authentication; and the email address from which the camera sends the notification emails (also known as the reply-to address). If you do not know the mail server's settings, contact your mail server administrator.

Under Notification List, specify one or more email addresses, separated by commas, to receive the notifications.

# **Tip** For the camera to properly send email, the camera's date and time must be correctly configured on the Date & Time Page.

## 4.8 Heaters & Fans Page

The Heaters & Fans page provides configuration settings for the camera's defogging, deicing, and automatic background heating features; temperature information for camera components; and status information for the camera's onboard heaters and cooling fan.

		HEATERS & FANS	
emperature Units			Power Source: PoE (30 W for heaters) Current Operation Status: Off
Celsius Y			current operation status. on
friggered by user			Thermometers
Duration (hours)			TempO (Visible sensor): 43.88 °C
1	~		Temp1 (CPU): 40.94 °C
			Temp2 (Visible window): 33.25 °C
Operation			Temp3 (Thermal window): 33.44 °C
Derog Derce			Temp4 (Front side center): 33.69 °C
Start Operation			Heaters
Thermal Visible B	oth Stop		HeaterO (Main): State Off
Packaround Heater Contro			Heater1 (Thermal window): State Off
Mode			Heater? [Visible window]: State Off
Off Off Auto			Heater2 (Thermal side): State Off
Thermal Power Level	Visible Power Level		Heaters (Minible side): State Off
10	× 10	~	neater+ (visible side). State un
10			Fans
ow Threshold ("C)	High Threshold (°C)		FanO (Fan): State Off
15	30		

Select the units of temperature that appear on the page: Celsius, Fahrenheit, or Kelvin. On R models, note that this setting is independent of the Units setting on the <u>Radiometry Page (R models)</u>.

### To manually activate defogging or deicing on one of the camera's sensors or on both of them:

- 1. Under Triggered by user, select the Duration (0.5, 1, or 2 hours).
- 2. Select the Operation.
- 3. Click Thermal, Visible, or Both. The status of the heater(s) changes from Off to On.

To deactivate the operation, click Stop.

### To enable automatic background heater control:

- 1. Under Background Heater Control, select Auto.
- 2. Specify the thermal and visible sensor heater power levels (0-15). Keep in mind the amount of power available to the heaters.
- 3. Specify the temperatures at which the heaters activate (Low Threshold) and deactivate (High Threshold).
- 4. Click Apply.

### **Status Information**

Down the right side of the Heaters & Fans page, the following status information appears:

- Power Source—PoE, 12 VDC, 24 VDC, or 24 VAC (the amount of power available to the heaters)
- Thermometers—Temperatures for camera components
- Heaters—Status of the camera's heaters (On or Off)
- Fans—Status of the camera's cooling fan (On or Off)

## 4.9 Cyber Page

The Cyber page provides security configuration settings for:

- <u>Certificates</u>
- <u>802.1X</u>
- TLS / HTTPS
- <u>Services</u>
- IP Filter

If you do not know how to configure these settings, contact your network administrator.

## 4.9.1 Certificates

Certificates	Certification area		
802.1X	TLS/HTTPS 80	12.1X	
TI S/UTTDS	Self-Signed	Upload Certi	ficate
	Country Code		Province Name
Services			
	City Name		Common Name
IP Filter			
	Organization Name		Organization Unit Name
	Email Address		Expiration Time (months)

Before you can enable TLS/HTTPS or 802.1X, you need to generate or upload a valid certificate. You can use the camera's web page to generate a self-signed certificate; upload a self-signed certificate; or upload a certificate signed by a third-party. If you do not know how to configure these settings, contact your network administrator.

Certificates and keys must be in PEM format. Common file extensions for TLS files in PEM format are:

- For certificate and public key files: \*.crt, \*.cer, \*.cert, \*.pem
- For private key files: \*.key

From the Certificates section of the Cyber page, you can download certificates and keys previously uploaded to or generated by the camera. If the certificate saved on the camera is self-signed, you can download the private and public key files. If the certificate was signed by a third-party CA, you can download the CA Certificate and the private and public key files.

#### To generate and install a self-signed certificate for TLS/HTTPS:

- 1. In the Certificates section and Certification area, select TLS/HTTPS and Self-Signed.
- 2. Enter information such as country code, city name, and organization name.
- 3. Click Create Certificate.
- 4. Allow 15 seconds for the camera to generate the certificate, at which point a confirmation appears.

#### To upload a self-signed or third-party CA signed certificate for TLS/HTTPS or for 802.1X:

1. In the Certification area, click **TLS/HTTPS** and then select **Upload Certificates**, or click **802.1X**.

Certification area		
Self-Signed	Upload Certificate	Certification area TLS/HTTPS 802.1X
Public Key (PEM format: *.crt, *.cer, *.cert, *.p	Private Key (*.key) nem) Upload file ث	Public Key (PEM format: *.crt, *.cer, *.cert, *.pem) Private Key (*.key) Upload file ① ①
Upload file Upload file CA Certificate	تُ. Upload file	Uplead file Uplead file Uplead file CA Certificate (PEM format: *.cer, *.cert, *.pem) Uplead file \$\screwtyle{2}\$,
(PEM format: *.crt, *.cer, *.cert, *.p Upload file Upload file	iem) ث	To Upload a Certificate for 802.1X

To Upload a Certificate for TLS/HTTPS

- 2. If you are uploading a self-signed certificate, under Public Key and then under Private Key:
  - a. Click Upload file 🗘 .
  - b. Select the appropriate key file.
  - c. Click Upload file

If you are uploading a third-party CA signed certificate, select and upload the Public Key, Private Key, and CA Certificate.

3. Verify that the camera certificate files are valid and make sure *Certificates are OK* appears under the certificate information, under Download certificate.

Certificates are OK		
🗄 PUBLIC KEY	🗄 PRIVATE KEY	🗠 CA CERT

Note that you can download keys and certificates from the camera.

## 4.9.2 802.1X

802.1X	Enable Disable	
	Identity	Private Key Password

Enable or disable IEEE 802.1X-compliant TLS communication. The default is disabled.

Provide an Identity and Private Key Password.

If you do not know how to configure these settings, contact your network administrator.

## 4.9.3 TLS / HTTPS

	Control On Off	HTTPS Redirect
TLS/HTTPS		

Enable or disable camera control using Transport Layer Security (TLS) / secure HTTP (HTTPS).

Enable or disable HTTPS redirect.

For both, the default is disabled.

If you do not know how to configure these settings, contact your network administrator.

## 4.9.4 Services



Enable or disable digest authentication for the FLIR CGI control interface. The default setting is On (enabled).

Enable or disable RTSP authentication. The default setting is On (enabled). When disabled, accessing the camera's video streams does not require authentication.

### **Firewall Settings**

For enhanced security, the camera has a firewall that is disabled by default. You can enable it by clicking **On**. By default, when you enable the firewall, the following services are set to **Allow**, which means they remain available and their default ports remain open:

- RTSP
- Nexus SDKTRK
- UPNP
- Nexus Discovery
   ICMP

To disable a service and its default port, click **Block**.



If you do not know how to configure these settings, contact your network administrator.

## 4.9.5 IP Filter

The camera's IP filter denies or allows access according to specific IPv4 addresses that you can define.

	Mode Off Allow Deny				
		Add		Add	
IP Filter					
			Clear		Clear

By default, the IP filter mode is Off.

To define specific IP addresses that can access the camera, click **Allow**. The camera will deny access to all other IP addresses.

To define specific IP addresses that cannot access the camera, click **Deny**. The camera will allow access to all other IP addresses.

To add an IP address to a list, either under Allowed IP Addresses or under Denied IP Addresses, specify an IPv4 address and then click **Add**. You can specify up to 256 IP addresses.

To remove an IP address from a list, click the corresponding trash icon  $\Box$ .

## 4.10 ONVIF Page

The ONVIF	page provides	settinas fo	r auxiliarv	commands an	d for out	put actions.
	page provideo	ootanigo io	i aaxiiiai y	oonninanao an	a loi out	par aonono.

	ONVIF	_		
Auxiliary Commands	Output	Actions		
Number of Auxiliary Commands	Number 4	of Dutput Actions		
Index Auxiliary Commands Name Action	Index	Action for DN	Action for OF	F
D AUX_NAME_0 Thermal Polarity Toggle ~	D	Thermal Polarity Toggle	✓ None	~
1 AUX_NAME_1 Thermal FFC ~	1	Thermal Scene Preset Toggle	✓ None	~
	2	Thermal FFC	~ None	~
	з	Thermal Sharpness Toggle	✓ None	~

### To configure the ONVIF interface:

- 1. Select the number of auxiliary commands (up to seven) and the number of output actions (also up to seven).
- 2. For each auxiliary command action, specify the ONVIF command name.
- 3. For each auxiliary command action, and separately for each ON and OFF output action, select one of the following:
  - $\circ~\text{None}$
  - Thermal Polarity Toggle—Toggles the thermal video polarity (see <u>Thermal Page</u>). For example, toggles the colorization from WhiteHot to BlackHot or vice versa; RedHot to RedHotInverse or vice versa; and so on.
  - o Thermal FFC—Initiates flat-field correction on the thermal sensor.
  - Thermal Palette Toggle—Toggles through the thermal video colorization options.



Index numbering starts with 0 (zero). In the ONVIF Device Manager, index numbering starts with 1 (one).

## 4.11 Map Page

On the Map page, you can upload a reference map image upon which the radar overlays its display and calibrate the radar to the map.

Map Display					
Warning: for proper ca orthogonal and north-	libration the map image must aligned	st be			
Find file		<u>土</u>			
UPLOAD	DOWNLOAD				
Celibration					
The calibration points	should be near opposite corn	ners,			
enner top-ient / bottor	v	I-IBIC			
-1 A					
Lat	L an				
Lat	LUII				
2 X	Y				
Lat	Lon				
Map is not calibrated					

## To upload a reference map image and calibrate the radar to the map:

1. Using an online map or GPS service such as Google Maps, download a reference map image.

## 🐑 Tips

- When you take the screenshot, make sure that north is straight up in the map image and that the map is flat (2D).
- Use a large, high-resolution screen or display in its native resolution with no zoom. You might get better results taking the screenshot with the map source in full screen (in Google Chrome, press F11). Also, in Google Maps, for example, it might help to turn off labels.
- Keep in mind where the radar is or will be mounted and oriented, and take a screenshot that covers an area a little larger than the radar's maximum detection range (R-290, 300 meters; R-190, 400 meters).
- The quality and resolution of the map image should be high enough so that the reference map is useful when you zoom in on the radar display.
- To move the radar display, and to zoom in and out, you can use the mouse. To move the radar display, click on the radar display, hold, and drag. To zoom in or out, use the mouse scroll wheel.
- It might take a few attempts at different settings to achieve the best result.
- 2. Identify two calibration points for which you can obtain accurate and exact latitude and longitude coordinates. For example, intersections of two roads or highways.

For optimal calibration, the two calibration points should be as far apart as possible and on opposite sides of the map image. For example, at top-right and at lower-left.

3. Under Map Display, click Find file, and then click Upload.

If the map successfully uploads, a confirmation message appears.

Map Display Find file	ĉ	
UPLOAD	DOWNLOAD	
Calibration		
Р1 Х	Y	
Lat		SUCCESS ×
		File uploaded successfully
P2 X	Y	Accept
Lat		
Map is not calibrated		
Find file		
UPLOAD	DOWNLOAD	

### 4. Click Accept.

If a map does not successfully upload, try again. Try changing the quality or compression of the map image. Higher quality or lower compression increases the map file size.





What's here? in Google Maps

- 5. Right-click on the first calibration point, and then select Calibration point 1.
- 6. Enter the latitude (Lat) and longitude (Lon) coordinates for the first calibration point (P1). You can obtain the coordinates from the online map or GPS service.

For example, in Google Maps, right-click on a point and select **What's here?** The point's latitude and longitude coordinates appear. Click the coordinate link, and then copy and paste the coordinates.

7. Repeat steps 4 and 5 for the second calibration point (P2).

The calibration points appear in the map as crosshairs icons.

8. Click Save.

The radar calibrates the map. When a map is not calibrated, a message appears onscreen.

If you have not yet configured the radar's georeference settings, you can do so on the <u>Georeference</u> <u>Page</u>.

## 4.12 Boresight Page

At the factory, the camera's visible video image was aligned with the thermal video image. On the Boresight page, you can fine tune the video image alignment to the scene using the Auto boresight feature or by manually adjusting it.



• A minor image misalignment is normal. Fine-tuning the boresight settings enables drawing the analytics regions on thermal and visible images when analytics is enabled on only one of the image source.

# Tips

- With the lenses physically separated, even slightly, the most accurate alignment is at a specific distance from the camera. The alignment shifts slightly for objects closer or further away from that distance. When making the fine-tuning boresight adjustments, align the images on objects that are the same distance from the camera.
- On the <u>Firmware & Info Page</u>, resetting the camera to its factory settings resets the factory boresight settings. On the <u>Firmware & Info Page</u>, you can back up and restore the camera's configuration settings, including the customized boresight settings.

# **A** Caution

When adjusting the camera's boresight, exercise extreme caution.

## **A** Important

- Changes to zoom settings affect the camera's video analytics. If you have previously configured the video analytics, after changing the zoom settings, adjust the detection regions accordingly.
- On each FH-Series model, the visible imager lens has a different optical zoom range and default field of view. For information about your model's optical zoom range and default field of view, see <u>Camera</u> <u>Specifications</u>.

Before you boresight the camera, make sure video analytics are disabled.

## To use Auto boresight:

- 1. Make sure the visible image is focused. Changes to the camera's focus slightly affect the FOV.
- 2. Select the Auto tab.

When using the Auto boresght feature, the images on the Boresight page are not live video images; they are snapshots. To monitor Auto boresight changes in real-time, view the live video streams on a FLIR UVMS, client program, or third-party ONVIF system.



3. Hover over a point in one of the images that you want in the field of view. Right-click, and then click **Add Point**.

The calibration point appears in the image.

4. To move a point, hover over it, click it, and drag it.





- 5. Hover over the same point in the other image, right-click, and then click **Add Point**.
- 6. Add more pairs of calibration points by repeating the previous steps.
- 7. Click Calibrate.
- 8. The camera aligns the images according to calibrations points by adjusting each imager's zoom, offsets, and so on.

If the camera detects a significant error in the calibration points, a message appears. Adjust the calibration points until the camera can align the images.

9. Click Refresh Snapshots and make sure the Auto boresight corrected the misalignment.

## To manually boresight the camera:

1. Select the Manual tab.



2. Use the controls and advanced settings on the Boresight page to align the visible and thermal video images and their fields of view.



If the digital zoom magnification is 1x, you cannot adjust the visible imager's offset. To be able to adjust the offset, specify a magnification greater than 1x. Increasing the digital zoom increases the offset adjustment range.



### **Advanced Settings**

131515		
Digital Magnification (1x-	-2x]	
•	1.05	Adjusts the visible imager's digital zoom magnification
Optical Zoom (0-100)	35.5	Adjusts the visible imager's optical zoom
Autofocus Push	73	Visible imager focus controls Manual and One-Time Auto

# 

For accurate video analytics, the VFOVs must be properly aligned. Teledyne FLIR recommends setting the vertical FOV of visible image slightly wider than the thermal image vertical FOV of thermal.





If you select **Overlap Thermal Image**, you can specify the opacity of the thermal image over the visible image.



## 4.13 Scheduler Page

You can define one-time or recurring tasks, including their start and stop times. For example, you can:

- Enable the camera's video analytics during certain times of the day.
- Schedule periodic uploads of snapshots of live video images to an FTP/SFTP server.

Ø Note			
You cannot use the schedul	er to define a task tl	hat records live video.	
	Click to edit	Click to toggle	
	Tasks Send Snapshot to FTP		
	Add		

Scheduler Page with a Task Defined and Enabled

By default, no tasks are defined.

## To define a task:

- 1. Click Add. A new task appears. By default, it is enabled.
- 2. Click New Task. The task action settings appear.



- 3. Define the task name.
- 4. Select one or more of the predefined actions:

Predefined Actions				
	Select whether the task disables the camera's onboard video analytics (off) enables it (on).			
Switch Analytics	Switch Analytics     →       Video Snapshots     off       Send Status Email     off       Switch Alarm Rules     off			
Video Snapshots	Records live video snapshots according to settings configured using FLIR UVMS, an approved third-party VMS, or another ONVIF-compliant client.			

60

Predefined Actions						
Send Status Email	Sends an email with informative settings on the Messaging F	Sends an email with information about the camera's status, according to the ettings on the Messaging Page.				
	a. Select whether the task disables (off) or enables (on) alarm rules.					
Switch Alarm Rules	Switch Analytics Video Snapshots Send Status Email Switch Alarm Rules Click on Action Name to see more options	switch off ids □ 0 □ 1 □ 2	~			
	b. Select the alarm rules the determine the rule ID, ch	e task affects, according to rule neck the Alarm Page.	<sub>Clear</sub> ID number. To			

- 5. Click **Next**. The task schedule settings appear.
- 6. From the drop-down list, select the first schedule for the task.

Schedule					
Custom	Define the task interval in days, hours, minutes, and seconds. For example, to schedule a task to run every three and a half days, select 03 from the Days drop-down list and 12 from the h (hours) drop-down list:				
	Custom V T Interval 03 V Days 12 V h 00 V m 00 V s				
Hourly	Define the time, in minutes and seconds past the hour, for the task to run every hour. For example, to schedule a task to run at :15 every hour, select 15 from the h (hours) drop-down list.				
Daily	Define the time of the day for the task to run. Define the hour according to the 24-hour clock, and the minute and second past the hour.				
Weekly	<ol> <li>Define the time of the day for the task to run.</li> <li>Either select the day of the week for the task to run, or select All days.</li> </ol>				
Monthly	Define the day of the month and the time of day for the task to run.				
Yearly	Define the month, day of the month, and time of day for the task to run.				



You can define more than one schedule for a task. For example, if you want to schedule an action for every Monday at 08:00 and for midnight on the first of every month:

- a. Define the 08:00 Mondays weekly schedule.
- b. Click Add.
- c. Define the first-of-every-month monthly schedule.
- 7. Click Done.



When you click **Done**, new tasks and changes to tasks immediately take effect. Unless you have made other changes on the Alarm page, clicking **Save** is not necessary.

Enable or disable a task by clicking **Enabled** or **Disabled**. To delete a task, click the corresponding trash icon **1**.

## 4.14 Recording Page

If a microSD card has been properly inserted in <u>the camera's microSD slot</u>, you can format it on the Recording page. In a future release, the camera will fully support all of the features on the Recording page. To configure onboard storage or other storage on the edge (SoE), use FLIR UVMS, an approved third-party VMS, or another ONVIF-compliant client.

	RECORDING
SD Card	
FORMAT	REFRESH INFO
Status <b>DK</b> Capa	ity 58.29GIB Used space 3.04GIB Free space 55.25GIB
Recording Pag	e with microSD Card Inserted and Formatted

# Notes

- Format the microSD card when using it for the first time, or when the card has been used with another camera and transferred to this camera.
- The card must be preformatted as a single partition.

## **A** Caution

Formatting a microSD card deletes all data on the card, regardless of whether it has been encrypted.

SD Format—To format a microSD card before using it, click Format.

## 4.15 Firmware & Info Page

On the Firmware & Info page, you can:

- · See the currently installed firmware version and other information about the camera
- Specify a unique name for the camera
- Upgrade the camera's firmware
- Reset the camera's settings to their factory defaults
- · Reboot the camera
- Enable logs, define a log level, and download system information
- Upload and download a configuration backup file
- Configure camera's analog video output
- Enable the camera's external illumination feature

Firmware Version v2.0.0.34		Name FH-644 QA644
Before upgrading, make sure the device has been recently rebooted		Temperature 38.94 °C
Upgrade Firmware		Serial Number QA644
Find file	<u>ث</u>	Model FH-644
UPGRADE		MAC Address 46:57:ED:06:74:64
Factory Default Reset and Camera Reboot		Up Time 0 day(s) 00:46:59
FULL RESET PARTIAL RESET	REBOOT	
Support System Info		Video Format
		Analon Video Source
Off ~		Visible ~
Configuration Reskup		External Illumination Installed
configuration Backup		No 🗸

### Name

Specify a unique, friendly name for the camera, using only alphanumeric characters. The default name for the camera is the camera model followed by the camera's serial number.

FH-313	— Camera name		
Enter camera name			
Firmware Version	Name FH-313		

### To upgrade the camera's firmware:

- 1. Make sure the camera has been recently rebooted.
- 2. Under Upgrade Firmware, click Find file.
- 3. On your computer or network, browse to and select the firmware file.

## **A** Caution

Only upgrade with firmware developed for Triton FH-Series cameras.

4. Click Upgrade.

The camera uploads and installs the firmware, which takes a minute or two. After installing firmware, the camera requires a reboot. When prompted, confirm rebooting the camera.

#### **Factory Defaults**

To reset the camera to its factory default settings, click **Full Reset**, and then confirm. The camera reboots.

To reset the camera to its factory default settings but retain previously saved Network page settings, click **Partial Reset**, and then confirm. The camera reboots.

# **A** Caution

After confirming a reset, do not click on the camera web page. Wait until the camera reboots and the login screen appears. Then, according to the instructions in <u>Accessing the Camera</u>, log back in to the camera web page using the camera's default admin user.

To reboot the camera and reset the camera to previously saved settings, click **Reboot**, and then confirm. If you reboot the camera before saving changes on the Firmware & Info page or on any other page, the camera does not save those changes.



You can also reboot and reset the camera to its factory default settings return the camera to its original factory configuration by pressing the camera's physical Default / Reset button for at least 10 seconds; for example, if you are unable to access the camera via its web page or other communication method. The Default / Reset button is located on the camera's side panel.

## Support System Info

To retrieve the camera's log files, click Download.

Set the logging detail up to four levels; higher log levels increase the size of the log file.

### **Configuration Backup**

You can back up the camera's saved settings or upload a configuration backup file; for example, when you replace a camera.

## To upload a configuration backup file:

- 1. Click Find file.
- 2. On your computer or network, browse to and select the configuration backup file.



Make sure to upload a configuration backup file that was downloaded from another FH-Series camera that is the exact same model.

3. Click Upload.

The camera uploads the backup file and requires a reboot. Confirm rebooting the camera.

## To download the camera's saved settings:

- 1. Click Download.
- 2. On your computer or network, browse to and select the location where you want to save the backup file.

**backup.tar.gz** is the default backup file name. You can change the backup file name, but do not change the **.tar.gz**.

#### **Other Settings**

**Video Format**—The visible imager shutter speed can be synchronized to the 50 Hz or 60 Hz power used for lighting the scene. If lighting is connected to 50 Hz power, the PAL setting might provide better video. Under 60 Hz lighting, NTSC might provide better video.

**Analog Video Source**—Specify the source for the camera's T/V analog video output:

- None—Disables the camera's T/V analog video output.
- Visible
- Thermal

**External Illumination Setting**—Enables the View Settings <u>Illumination Page</u>, where you can disable and enable automatic external IR illumination.

# **5** Maintenance and Troubleshooting Tips

If help is needed during installation, operation, or configuration, contact the local Teledyne FLIR representative, or visit the Teledyne FLIR Support Center at: <u>https://support.flir.com/</u>. Teledyne FLIR LLC offers a comprehensive selection of training courses to help get the best performance and value from the thermal imaging camera.

Find out more at the Teledyne FLIR training web page: <u>https://www.teledyneflir.com/support-center/training/</u>.

## 5.1 Cleaning

The camera's housing and lens windows are designed for harsh outdoor environments and the lens windows are coated for durability and anti-reflection. Nonetheless, they can require occasional cleaning.

## **A** Caution

- Use great care with your camera's optics. They are delicate and improper cleaning can damage them.
- Do not use abrasive materials, such as paper or scrub brushes, which can scratch and damage the lens windows.
- Only wipe a lens window clean when you can visually see contamination on the surface.

## To clean the camera housing and lens windows:

- 1. Use a compressed air gun to remove dust, dirt, and other contaminants.
- 2. Check surfaces for any remaining contaminants.
- 3. If necessary, moisten a clean, soft cotton cloth with alcohol and wipe the surface clean.

## 5.2 Troubleshooting

## **Unable to Communicate over Ethernet**

First check to ensure the physical connections are intact and that the camera is powered on.

By default, the camera broadcasts a discovery packet twice per second. Use version 2.3.0.20 or higher of the Teledyne FLIR Discovery Network Assistant (DNA) tool or a packet sniffer utility such as Wireshark and confirm the packets are being received by the PC from the camera.

## Unable to View IP Video Stream

If the IP video stream from the camera is not displayed, the firewall might be blocking packets, or there could be a conflict with video codecs installed for other video programs.

When displaying video on a VMS for the first time, the Windows Personal Firewall might ask for permission to allow the video player to communicate on the network. Select the appropriate type of network(s) (domain, private, or public).

If necessary, make sure the video from the camera can be viewed by a generic video player such as VLC media player (<u>http://www.videolan.org/vlc/</u>). To view the video stream, specify RTSP port 554 and the appropriate stream name. For example, using the camera's default IP address when there is no DHCP server on the network (192.168.0.250):

rtsp://192.168.0.250:554/stream1 for Visible 1 rtsp://192.168.0.250:554/stream2 for Visible 2 rtsp://192.168.0.250:554/stream3 for Thermal 1 rtsp://192.168.0.250:554/stream4 for Thermal 2 By default, RTSP authentication is enabled. To access any of the camera's video streams, you can use the name and password for any of the camera's users. See <u>Users Page</u>. Users assigned the role of admin or expert can disable RTSP authentication in the <u>Services</u> section of the Cyber page.

For more information on RTSP settings and stream names, see Video Page.

### No IP or Analog Video

If the camera is not producing an image, check the connections at the camera and at the display. If the connections appear to be properly made but the camera still does not produce an image, ensure that power has been properly applied to the camera and the circuit breaker is set properly. If a fuse was used, be sure the fuse is not blown.

If the camera still does not produce an image, contact the Teledyne FLIR dealer or reseller who provided the camera, or contact Teledyne FLIR directly.

#### **Noisy Image**

A noisy image is usually attributed to a cable problem (too long or inferior quality) or the cable is picking up electromagnetic interference (EMI) from another device. Although coax cable has built-in loss, the longer the cable, or the smaller the wire gauge, the more severe the loss becomes. Also, the higher the signal frequency, the more pronounced the loss. Unfortunately, this is one of the most common and unnecessary problems that plagues video systems in general.

A number of factors (core material, dielectric material, and shield construction, among others) determine cable characteristics. Carefully match cable to the specific application. Moreover, the physical environment through which the cable is run and the method of installation influences the transmission characteristics of the cable.

Check cable connector terminations. Inferior connections might use multiple adapters, which can cause unacceptable noise. When splitting the signal to multiple monitors, use a high-quality video distribution amplifier.

#### **Thermal Image Freezes Momentarily**

By design, the camera image momentarily freezes during Flat-Field Correction (FFC, and also known as Non-Uniformity Correction or NUC). At regular intervals or when the ambient temperature changes, the camera automatically performs FFC. You can also manually trigger FFC on the <u>Thermal Page</u>. The shutter for the thermal imager closes and provides a target of uniform temperature, allowing the thermal imager to correct for ambient temperature changes and provide the best possible image.

#### Performance of Thermal Imager Varies with Time of Day

The diurnal cycle of the sun can cause difference thermal imager performance at different times of the day. The thermal imager produces an image based on temperature differences. At certain times of the day, such as just before dawn, all of the objects in the scene could be the same temperature. Compare that type of scene to right after sunset, when objects in the scene might be radiating heat energy absorbed during the day. As temperature differences in the scene increase, the thermal imager can produce higher-contrast images.

When objects in the scene are wet rather than dry, performance also can be affected. For example, on a foggy day or early in the morning, when surfaces might be coated with dew. Under such conditions, the thermal imager might not be able to accurately detect the temperature of the object itself; instead, it detects the temperature of the surface water.

## Thermal Image Too Dark or Too Light

By default, the camera's thermal imager uses an Automatic Gain Control (AGC) setting that has proven to be superior for most applications, and the camera automatically responds to varying conditions. Keep in mind that the sky is quite cold and can strongly affect the overall image. To avoid issues, it might be possible to slightly move the camera up or down to include (or exclude) hot or cold areas that influence the overall image. For example, a very cold background (such as the sky) can cause the camera to detect and display a wider temperature range than appropriate.
### Eastern or Western Exposure

Once installed, the camera might point directly east or west, which can cause the sun to be in the field of view during certain portions of the day. Teledyne FLIR does not recommend intentionally pointing the camera at the sun. The sun can introduce image artifacts that the imager eventually corrects. However, recovery can take some time. The amount of time depends on how long the thermal imager was exposed to the sun. The longer the exposure, the longer the recovery time needed. Nonetheless, it does not permanently damage the imager. At the same time, in back-lit scenes, the thermal imager often provides a considerable advantage over a visible imager.

Camera Pointing the Sun



Visible Imager

Thermal Imager

# 6 Appendix

# 6.1 Configuring PTZ Hand-Off

Triton FH-Series cameras can hand-off detection events to a supported PTZ camera using an ioi PTZ Tracker (trk-101-P). Hand-off requires using the PTZ Tracker's web page or FLIR UVMS to bind the FH-Series camera to the PTZ tracker. When the FH-Series camera detects an event, the camera communicates the object's location to the trk-101-P, which then controls and moves the PTZ camera to track and zoom in on the object.

An overview of using the PTZ Tracker's web page to bind the FH-Series camera to the PTZ tracker appears below. For the full procedure, see the *ioi HTML Edition Units User Guide*; you can download it from the product's web page on the Teledyne FLIR website.

For information about using FLIR UVMS to bind the camera to the PTZ tracker, see the UVMS documentation.

## To configure PTZ hand-off using the tracker's web page:

- 1. Make sure the FH-Series camera's analytics <u>have been calibrated</u> and that <u>analytics regions have</u> <u>been created</u> on the <u>Video Analytics Page</u>.
- 2. Disable the FH-Series camera's analytics.
- 3. Log in to the PTZ tracker's web page.

Login to ioibox trk101-P			
Login name:	admin		
Password:	•••••		
Remember my password on this computer			
Language:	English		
	Login Cancel		
🗌 Login as guest			
<b>\$FLIR</b>			

4. On the Live View screen (workspace), click Setup.



Channel name:	ioibox trk101-P	
Camera Type		
○ Fixed		
Pan/Tilt/Zoom	(PTZ)	
Comoro Model		
Manufacturer:	E1 10	
Madal		
Model:	FLIR Analog XPVA X36 PAL	
Max zoom:	36	
Communication		
Port:	Port #1 (RS485)	
Protocol:	RS485	
Device ID:	1	
Baud rate:	9600	speed speed
Parity:	None	
Start bits:	8	Image Quality Enhancer
Stop bits:	1	💭 🔿 Automatic 🚇 Manual
		Brightness: 0 0 100 0
IP:	Port:	Contract: 0.0
User:	Password::	
		Saturation: 0 0 100 0

 On the Camera > Type & Model screen, make sure that the Camera Type selected is Pan/Tilt/Zoom (PTZ).

6. Click Start PTZ Setup. The Detection and Tracking screen appears.



7. Select Detection from another camera with Automatic PTZ tracking. Click **Next**. The Calibration screen appears.

Camera > PTZ Setup > Calibration	Units: Feet
Camera Height  Unknown  Set camera height: University of the set Calibration  Before calibration:  Set PTZ camera to full zoom-out. Set tilt angle to 30-50 degrees below the horizon  Hotoon line University of the set of	
Calibration status: Camera is already calibrated. Calibrate	speed QQ
Delection & Tracking Calibration PTZ Synchronization	Tracking Parameters Previous Next

8. Follow the on-screen instructions. When the PTZ camera has been calibrated, click **Next**. The PTZ Synchronization screen appears.



Click to create a correlation point

For each camera, define eight correlation points

- 9. On the PTZ Synchronization screen, perform Step 3: PTZ Synchronization with Fixed Cameras of Using the PTZ Camera Definition Wizard in the *ioi HTML Edition Units User Guide*.
- 10. For each camera, create eight correlation points.
- 11. After defining all of the correlation points for both cameras, click **Test**. When the test succeeds, click **Link**.

For more information about defining correlation points, in the *ioi HTML Edition Units User Guide*, see To set correlation points in a preset.

- 12. Click Next and then click Finish.
- 13. Return to Live View and click Arm.

14. On the <u>Video Analytics Page</u>, enable the FH-Series camera's analytics.



Americas 27700 SW Parkway Ave. Wilsonville, OR 97070 USA

6769 Hollister Ave Goleta, CA 93117 USA

Support: https://support.flir.com/

Document: 427-0102-00-10 Revision: 110 Date: November 2021