


Piranha4

Camera User's Manual

Color 8k

sensors | **cameras** | frame grabbers | processors | software | vision solutions



© 2013 Teledyne DALSA, Inc. All information provided in this manual is believed to be accurate and reliable. No responsibility is assumed by Teledyne DALSA for its use. Teledyne DALSA reserves the right to make changes to this information without notice. Reproduction of this manual in whole or in part, by any means, is prohibited without prior permission having been obtained from Teledyne DALSA.

About Teledyne Technologies and Teledyne DALSA, Inc.

Teledyne Technologies is a leading provider of sophisticated electronic subsystems, instrumentation and communication products, engineered systems, aerospace engines, and energy and power generation systems. Teledyne Technologies' operations are primarily located in the United States, the United Kingdom and Mexico. For more information, visit Teledyne Technologies' website at www.teledyne.com.

Teledyne DALSA, a Teledyne Technologies company, is an international leader in high performance digital imaging and semiconductors with approximately 1,000 employees worldwide, headquartered in Waterloo, Ontario, Canada. Established in 1980, the company designs, develops, manufactures and markets digital imaging products and solutions, in addition to providing MEMS products and services. For more information, visit Teledyne DALSA's website at www.teledynedalsa.com.

Support

For further information not included in this manual, or for information on Teledyne DALSA's extensive line of image sensing products, please contact:

North America

700 Technology Park Drive
Billerica, MA
USA, 01821
Tel: 978-670-2000
Fax: 978-670-2010
Email: Sales.Americas@teledynedalsa.com

Europe

Felix-Wankel-Str. 1
82152 Krailling
Germany
Tel: +49 89 89 54 57 3-80
Fax: +49 89 89 54 57 3-46
Email: Sales.Europe@teledynedalsa.com

Asia Pacific

Ikebukuro East 13F
3-4-3 Higashi Ikebukuro, Toshima-ku,
Tokyo
Japan
Tel: +81 3 5960 6353
Fax: +81 3 5960 6354
Email: Sales.Asia@teledynedalsa.com

Contents

System Precautions.....	5
1. The Piranha4 Color Camera	6
Camera Highlights.....	6
Camera Performance Specifications	7
Certifications.....	8
Supported Industry Standards.....	8
Responsivity.....	9
FPN Characteristics with Temperature	11
Mechanicals.....	15
2. Quick, Simple Steps to Acquire an Image	17
3. Software and Hardware Setup	18
Setup Steps: Overview	18
Step 1. Install and configure the frame grabber, and software (including GUI)	19
Step 2. Connect Data, Trigger, and Power Cables	20
Step 3. Establish Communication with the Camera	30
Using Sapera CamExpert with Piranha4 Cameras	33
4. Camera Operation	37
Factory Settings	37
Check Camera and Sensor Information.....	37
Verify Temperature and Voltage	38
Saving and Restoring Camera Settings	38
Camera Link Configuration	40
Trigger Modes.....	40
Exposure Controls	40
Exposure Modes in Detail	41
Set Line Rate	44
Set Exposure Time	48
Control Gain and Black Level	48
Set Image Size.....	48
Set Baud Rate	49
Pixel Format	49
Camera Direction Control	50
Pixel Readout Direction (Mirroring Mode).....	50
Resetting the Camera	50
Calibrating the Camera	51
Appendix A: GenICam Commands	55
Camera Information Category.....	55
Camera Control Category	59
Flat Field Category	63
Image Format Control Category.....	65
Area of Interest (AOI) Setup.....	67
Instructions on using the camera scan direction to control camera parameters.....	70

Transport Layer Control Category	73
Acquisition and Transfer Control Category	75
Serial Port Control Category.....	76
File Access Control Category	77
Appendix B: ASCII Commands	81
Appendix C: Quick Setup and Image Acquisition	94
Appendix D: The Sensor Window	97
EMC Declaration of Conformity	99
Revision History	100
Index	101

System Precautions

Precautions

Read these precautions and this manual carefully before using the camera.

Confirm that the camera's packaging is undamaged before opening it. If the packaging is damaged please contact the related logistics personnel.

Do not open the housing of the camera. The warranty is voided if the housing is opened.

Keep the camera housing temperature in a range of 0 °C to 50 °C during operation.

Do not operate the camera in the vicinity of strong electromagnetic fields. In addition, avoid electrostatic charging, violent vibration, and excess moisture.

To clean the device, avoid electrostatic charging by using a dry, clean absorbent cotton cloth dampened with a small quantity of pure alcohol. Do not use methylated alcohol. To clean the surface of the camera housing, use a soft, dry cloth. To remove severe stains use a soft cloth dampened with a small quantity of neutral detergent and then wipe dry. Do not use volatile solvents such as benzene and thinners, as they can damage the surface finish. Further cleaning instructions are below.

Though this camera supports hot plugging, it is recommended that you power down and disconnect power to the camera before you add or replace system components.

Electrostatic Discharge and the CMOS Sensor

Image sensors and the camera bodies housing are susceptible to damage from electrostatic discharge (ESD). Electrostatic charge introduced to the sensor window surface can induce charge buildup on the underside of the window that cannot be readily dissipated by the dry nitrogen gas in the sensor package cavity. The charge normally dissipates within 24 hours and the sensor returns to normal operation.

Additional information on cleaning the sensor window and protecting it against dust, oil, blemishes, and scratches can be found here, [Appendix D: The Sensor Window](#).

1. The Piranha4 Color Camera

Camera Highlights

Based on Teledyne DALSA's unique CMOS color line scan sensor architecture, the new Piranha4 8k bilinear color camera provides outstanding signal-to-noise for high speed imaging.

The P4-8k has 8k resolution with a $7\ \mu\text{m} \times 7\ \mu\text{m}$ pixel size for optimized optical design. The camera delivers a max line rate of 50 kHz in a high responsivity summing mode.

Precise sensor alignment simplifies multiple camera calibration at the system level. GenICam™ or ASCII command-compliant interfaces make the camera easier to setup, control, and integrate. Programmability includes exposure control, flat field correction, and gain settings.

The Piranha4 8k camera is ideal for printing inspection, printed circuit board, solar cell, film, and large format web inspection.

Key Features

- CMOS color bilinear line scan
- 8k pixel resolution
- Line rates up to 50 kHz, 70 kHz with AOI applied
- Exposure control
- 100x antiblooming
- RGB, BGR, RG / BG, or G outputs
- Camera Link interface
- GenICam or ASCII command-compliant interfaces

Programmability

- Save up to eight sets of correction coefficients
- Adjustable gain and offset
- White balance and color correction
- Lens and shading correction with defocusing cap ability
- Test pattern and diagnostics
- Multi-AOI output allows faster line rates

Applications

- Printing inspection
- High performance document scanning
- Electronics
- Film inspection
- High throughput applications

Models

The camera is available in the following configurations:

Table 1: Camera Models Overview

Model Number	Description
P4-CC-08K050-00-R	8k resolution, 50 kHz line rate, Camera Link interface.

Table 2: Software

Software	Product Number / Version Number
Camera firm ware	Embedded within camera
GenICam™ support (XML camera description file)	Embedded within camera
Sapera LT, including CamExpert GUI application and GenICam for Camera Link imaging driver	Version 7.30 or later

Camera Performance Specifications

Table 3: Camera Performance Specifications

Specifications	Performance
Imager Format	CMOS bilinear color line scan
Resolution	8192 x 2 pixel lines: 8192 x 1 pixel line Green, and 8192 x 1 pixel line alternating Red-Blue
Pixel Size	7.04 μm x 7.04 μm
Full Well Capacity	20k e ⁻ @ minimum gain of 1x
Line Rate	0 kHz minimum to 50 kHz maximum (Deca RGBG8), 34 kHz maximum (Deca RGB8), 20 kHz maximum (Medium), 10 kHz maximum (Base RGB8)
Exposure Time	8 μs minimum to 3,000 μs maximum
Bit Depth	8 bits
Connectors and Mechanicals	
Control & Data Interface	Base, Medium, or Deca* Camera Link configurations—MDR26
Power Connector	Hirose 6-pin circular
Power Supply	+ 12 V to + 24 V DC
Maximum Current Draw	17W/ (Applied voltage at camera connector)
Power Dissipation	17 W
Size	80 mm (W) x 130 mm (H) x 57 mm (D) Without heat sinks: 80 mm (W) x 80 mm (H) x 57 mm (D)
Mass	< 700 g, including heat sinks (< 530 g without heat sinks)
Operating Temp	0 °C to 50 °C, front plate temperature
Optical Interface	
Lens Mount	M72 x 0.75, F-mount**
Sensor to Camera Front Distance	12 mm
Sensor Alignment (aligned to sides of camera)	
Flatness	50 μm
⊙ y (parallelism)	0.08° or 81 μm
x	± 80 μm
y	± 80 μm
z	± 250 μm
⊙ z	± 0.2°

Compliance	
Regulatory Compliance	CE and RoHS; GenICam

*At the time of this release, CamExpert does not accommodate color Deca 9.1 mode. Contact Customer Support if you are interested in evaluating a camera using this mode.

** F-mount lenses are optimized for a maximum image circle of 43.2 mm. However, the P4-8k sensor is 57.67mm long. Using an F-mount lens will generate a good image for the center 6008 pixels. However pixels beyond this range may suffer from optical distortion caused by the lens. If an application requires the use of an F-mount lens with P4-8K cameras, contact Customer Support for additional details regarding the use of F-mount lenses and for access to a suitable F-mount-to-M72 adapter.

Operating Ranges	Performance		
	Red	Green	Blue
Dynamic Range	62.5 dB	62.5 dB	62.5 dB
Random Noise	0.186 DN ** rms	0.186 DN ** rms	0.186 DN ** rms
Broadband Responsivity	3.2 DN/ (nJ/ cm ²)	4.4 DN/ (nJ/ cm ²)	2.2 DN/ (nJ/ cm ²)
Gain	1x to 10x Nominal Range (not including individual RGB gains for white balance)		
DC Offset	<1 DN	<1 DN	<1 DN
PRNU	<2% @50% Sat	<2% @50% Sat	<2% @50% Sat
FPN	< 0.3 DN	< 0.3 DN	< 0.3 DN
SEE	78 nJ/ cm ²	56 nJ/ cm ²	113 nJ/ cm ²
NEE	58 pJ/ cm ²	42 pJ/ cm ²	84 pJ/ cm ²
Antiblooming	> 100 x Saturation		
Integral non-linearity	< 2% DN		

**DN = digital number

Test Conditions:

- Values measured using 8-bit, 1x gain.
- 10 kHz line rate
- Light source: white LED
- No white balancing
- Front plate temperature: 45° C

Certifications

Compliance
EN 55011, FCC Part 15, CISPR 11, and ICES-003 Class A Radiated Emissions Requirements.
EN 55024, and EN 61326-1 Immunity to Disturbance.
RoHS per EU Directive 2002/ 95/ EC and WEEE per EU Directive 2002/ 96/ EC and China Electronic Industry Standard SJ/ T11364-2006
GenICam XML Description File, Superset of the GenICam™ Standard Features Naming Convention specification V1.5, Camera Link Serial Communication: GenICam™ Generic Control Protocol (GenCP V1.0)

Supported Industry Standards

GenICam™

Piranha4 cameras are GenICam compliant. They implement a superset of the GenICam™ Standard Features Naming Convention specification V1.5. This description takes the form of an XML device description file respecting the syntax defined by the GenApi module of the GenICam™ specification. The

camera uses the GenICam™ Generic Control Protocol (GenCP V1.0) to communicate over the Camera Link serial port. For more information see www.genicam.org.

Responsivity

The responsivity graph describes the sensor response to different wavelengths of light (excluding lens and light source characteristics).

Note: The responsivity of a color camera will measure approximately 1/ 6th that of a similar monochrome camera model as a result of the effect the color filter has on the sensor and also due to the color camera not incorporating a high-sensitivity mode (dual line summing).




Figure 1: Spectral Responsivity vs. Wavelength




Figure 2: Spectral Quantum Efficiency vs. Wavelength

FPN Characteristics with Temperature




Figure 3: FPN Derating Chart

[ADD GRAPH]

Figure 4: Calibration Source Relative Intensity vs. Wavelength

Spatial Correction and Bilinear Sensor Design

The Piranha4 bilinear color camera is based on Teledyne DALSA's bilinear CMOS sensor and designed such that the first line of this two line sensor has red (R) and blue (B) alternating pixels, while the second line has all green (G) pixels. The sensor has a 100% fill factor with zero gap between the two lines, which minimizes any artefact due to spatial correction. The G channel can be used as a monochrome output.




Figure 5: Piranha4 Color Bilinear Sensor Block Diagram

Note: The interpolation procedure does not work on the first and last pixels. As a result, the number of effective full color (RGB) pixels is reduced by 2 to 8190 pixels.


There is no spacing between the sensor lines. When the image passes the two lines of pixels, the red/ blue and green components for the same image location are captured at a different time as dictated by the line spacing. The camera automatically corrects for the line spacing to ensure that the red/ blue and green components of the image pixel are all aligned when output. However, this is only correct when the object pixel size is square; i.e., the distance moved by the object for one EXSYNC period is equal to the width of the object pixel. In some applications it may not be possible to achieve a 'square' object pixel as fine adjustment of the lens magnification and/ or the distance moved for each EXSYNC period is not possible. This scenario may be especially apparent when trying to integrate the camera into an existing system.

When it is not possible to generate a square object pixel, color artefacts will occur in the scan direction and is particularly noticeable at sharp edge transitions. The size of the edge artefact is proportional to how far the pixel is from square. To correct for this, the camera has a feature, Line Spatial Correction (or three letter command ssa), which allows fine adjustment of the compensation mechanism the camera uses to correct for the line spacing.

The default setting for this feature is 1, which is set for square object pixels. The setting can be adjusted from 0 to 3 to compensate for rectangular pixels—whether they are too long or too short.


The following examples of image artefacts show black to white image transitions and the associated corrected image after applying a specific ssa setting.

Example 1. Target speed adjusted for square pixels



Line Spatial Correction = 1 (ssa = 1).
This is the default condition.


Example 2. Target running slower than example 1. same EXSYNC (trigger) frequency



Line Spatial Correction = 1 (ssa = 1)

Line Spatial Correction = 2 (ssa = 2)

Example 3. Target running faster than example 1. same EXSYNC (trigger) frequency



Sensor Shift Direction Example

When in high sensitivity mode, you can select either forward or reverse sensor direction. See [Camera Direction Control](#) for details. Selectable direction accommodates object direction change on a web and allows you to mount the camera “upside down”.

Note: The example here assumes the use of a lens (which inverts the image).




Figure 6: Object Movement and Camera Direction Example, with a Lens

Mechanicals

[ADD MECHANICAL FROM PDF]

Figure 7: Camera Mechanical

[ADD MECHANICAL FROM PDF]

Figure 8: Camera Mechanical with External Heat Sink

Camera Mounting and Heat Sink Considerations

The Piranha4 cameras ships with two heat sinks installed and ideally positioned to allow close spacing of the cameras. These heat sinks are designed to provide adequate convection cooling when not obstructed by enclosures or mounting assemblies.

Teledyne DALSA recognises that each customer's application can be unique. In consideration, the P4 camera heat sinks have been designed in such a way that they can be repositioned on the different faces of the camera or removed entirely, depending on the mounting configuration and its heat sinking potential.

Repositioning or removal of the heat sinks must be performed with care in order to avoid temperature issues. The camera has the ability to measure its internal temperature. Use this feature to record the internal temperature of the camera when it is mounted in your system and operating under the worst case conditions. The camera will stop outputting data if its internal temperature reaches 75 °C.

2. Quick, Simple Steps to Acquire an Image

For users who are familiar with Camera Link cameras, have a basic understanding of their imaging requirements, and who are primarily interested in evaluating the Piranha4 camera, an overview of the steps required to get this camera operational and acquiring images quickly can be found in [Appendix C: Quick Setup and Image Acquisition](#).

3. Software and Hardware Setup

Recommended System Requirements

To achieve best system performance, the following minimum requirements are recommended:

- High bandwidth frame grabber, e.g. Xcelera-CL PX4 Full Camera Link frame grabber (Part # OR-X4CO-XPFO0).
- Operating system: Windows XP 32-bit.

Setup Steps: Overview

Take the following steps in order to setup and run your camera system. They are described briefly below and in more detail in the sections that follow.

1. Install and Configure Frame Grabber and Software (including GUI)

We recommend the Xcelera-CL PX4 Full frame grabber or equivalent, described in detail on the teledynedalsa.com site [here](#). If your host computer does not have a PX4 full Camera Link frame grabber then you will need to install one. Follow the manufacturer's installation instructions.

A GenICam™ compliant XML device description file is embedded within the camera firmware allowing GenICam™ compliant application to know the camera's capabilities immediately after connection. Installing SperaLT gives you access to the CamExpert GUI, a GenICam™ compliant application.

2. Connect Camera Link and Power Cables

- Connect the Camera Link cables from the camera to the computer.
- Connect a power cable from the camera to a +12 VDC to +24 VDC power supply.

3. Establish communicating with the camera

Start the GUI and establish communication with the camera. Refer to Step 2: Connect Camera Link and Power Cables for a description on communicating with the camera.

ASCII Commands

As an alternative to the CamExpert (or equivalent) GUI, you can communicate with this camera using ASCII-based commands. A complete list of the commands can be found in the appendix: ASCII User Command Reference.

4. Operate the Camera

At this point you will be ready to start operating the camera in order to acquire images, set camera functions, and save settings.

Step 1. Install and configure the frame grabber, and software (including GUI)

Install Frame Grabber

Install a Full configuration Camera Link frame grabber according to the manufacturer's description.

We recommend the Xcelera-CL PX4 frame grabber or equivalent, described in detail on the teledynedalsa.com site [here](#).

Install Sopera LT and CamExpert GUI

Communicate with the camera using a Camera Link-compliant interface. We recommend you use CamExpert. CamExpert is the camera interfacing tool supported by the Sopera library and comes bundled with SoperaLT. Using CamExpert is the simplest and quickest way to send commands to and receive information from the camera.

Camera Link Environment

These cameras implement the Camera link specification, which defines the device capabilities. The Camera link XML device description file is embedded within the camera firmware allowing Camera link-compliant applications to recognize the cameras' capabilities immediately after connection.

Step 2. Connect Data, Trigger, and Power Cables

Note: the use of cables types and lengths other than those specified may result in increased emission or decreased immunity and performance of the camera.




Figure 9: Input and Output, trigger, and Power Connectors



WARNING! Grounding Instructions

Static electricity can damage electronic components. It's critical that you discharge any static electrical charge by touching a grounded surface, such as the metal computer chassis, before handling the camera hardware.

Data Connector: Camera Link

The camera uses two Camera Link MDR26 cables transmitting the Camera Link Base, Medium, Deca configuration. The figure below shows the MDR26 Camera Link Connector and the tables that follow list the Camera Link Base, Medium, and Deca configurations.

For detailed information on Camera Link please refer to the Camera Link Road Map available from the [Knowledge Center](#) on the Teledyne DALSA Web site.




Figure 10. MDR26 Camera Link Connector

Data 2			Control / Data 1		
Camera Connector	Right Angle Frame Grabber Connector	Channel Link Signal	Camera Connector	Right Angle Frame Grabber Connector	Channel Link Signal
1	1	inner shield	1	1	inner shield
14	14	inner shield	14	14	inner shield
2	25	Y0-	2	25	X0-
15	12	Y0+	15	12	X0+
3	24	Y1-	3	24	X1-
16	11	Y1+	16	11	X1+
4	23	Y2-	4	23	X2-
17	10	Y2+	17	10	X2+
5	22	Yclk-	5	22	Xclk-
18	9	Yclk+	18	9	Xclk+
6	21	Y3-	6	21	X3-
19	8	Y3+	19	8	X3+
7	20	100 ohm	7	20	SerTC+
20	7	terminated	20	7	SerTC-
8	19	Z0-	8	19	SerTFG-
21	6	Z0+	21	6	SerTFG+
9	18	Z1-	9	18	CC1-
22	5	Z1+	22	5	CC1+
10	17	Z2-	10	17	CC2+
23	4	Z2+	23	4	CC2-
11	16	Zclk-	11	16	CC3-
24	3	Zclk+	24	3	CC3+
12	15	Z3-	12	15	CC4+
25	2	Z3+	25	2	CC4-
13	13	inner shield	13	13	inner shield
26	26	inner shield	26	26	inner shield

Note:

*Exterior Overshield is connected to the shells of the connectors on both ends. Unused pairs should be terminated in 100 ohms at both ends of the cable. Inner shield is connected to signal ground inside camera


Camera Link Bit Definitions

Signal	Configuration
CC1	EXSYNC
CC2	Spare
CC3	Direction
CC4	Spare

Table 4: Camera Control Configuration

For additional Camera Link documentation refer to the Teledyne DALSA Web site's [Knowledge Center application notes](#).


RGB 8 bit CL Base, max line rate 10 kHz without AOI and 85 MHz CL Clock



This timing can be used for applications that require line rates only up to 10 kHz and therefore can use Camera Link Base mode with only one cable.

The RGB output format is compatible with the Camera Link specification for Base RGB. Values for red even numbered pixels are interpolated from the neighbouring red odd numbered pixels. Values for blue odd numbered pixels are interpolated from the neighbouring blue even numbered pixels. Line rates up to 70 kHz can be achieved by using the Area of Interest (AOI) feature; where the smaller the AOI, the greater the potential line rate.

RGB 8 bit CL Medium, max line rate 20 kHz without AOI and 85 MHz CL clock




This timing can be used for applications that require line rates up to 20 kHz and therefore must use Camera Link Medium mode and two cables.

The RGB output format is compatible with the Camera Link specification for Medium RGB. Values for red even numbered pixels are interpolated from the neighbouring red odd numbered pixels. Values for blue odd numbered pixels are interpolated from the neighbouring blue even numbered pixels. Line rates up to 70 kHz can be achieved by using the Area of Interest (AOI) feature; where the smaller the AOI, the greater the potential line rate.

RGB 8 bit CL Deca, max line rate 34 kHz without AOI and 85 MHz CL clock

Note: The inserted dummy pixels at the end




This timing can be used for applications that require line rates up to 34 kHz and therefore must use Camera Link Deca mode and two cables.

The RGB output format is not defined in the Camera Link specification Deca. The RGB format is such that when using a Camera Link frame grabber compatible with the Deca format configured for the mono standard, the R, G and then B pixels will be written sequentially into the frame grabber buffer. This process simplifies the extraction of the RGB data from the frame grabber buffer by the host application. Values for red even numbered pixels are interpolated from the neighbouring red odd numbered pixels. Values for blue odd numbered pixels are interpolated from the neighbouring blue even numbered pixels. Line rates up to 70 kHz can be achieved by using the Area of Interest (AOI) feature; where the smaller the AOI, the greater the potential line rate.

RGBG 8 bit CL Deca, max line rate 51 kHz without AOI and 85 MHz CL clock

Note: only 8190 pixels transmitted, no color interpolation




This timing can be used for applications that require line rates up to 51 kHz and therefore must use Camera Link Deca mode and two cables.

Due to the bandwidth limitation of Camera Link Deca, it is only possible to output the two lines of the color sensor—where one 8K line is green and the other 8K line is alternating red and blue pixels—as 4K of each. This is defined as the RGBG format. The RGBG output format is not defined in the Camera Link specification for Deca. The RGBG format is such that when using a Camera Link frame grabber compatible with the Deca format configured for the mono standard, the R, G, B and then G pixels will be written sequentially into the frame grabber buffer. This process simplifies the extraction of the RGBG data from the frame grabber buffer by the host application. However, the frame grabber or host application will need to perform the necessary red and blue interpolation to generate RGB pixel data. This interpolation operation will increase the amount of pixel data by 50%. Line rates up to 70 kHz can be achieved by using the Area of Interest (AOI) feature, where the smaller the AOI results in increased potential line rates.

Note: when using an AOI with this RGBG mode, you must consider the available (i.e. potential lack of) red and blue pixel data at the AOI boundaries when they are performing interpolation.

When using the AOI feature, there are specific AOI rules with respect to AOI sizes and boundaries that must be adhered to, see below.

Green Only Output



AOI Rules

Custom AOI Rules

- 1) The sensor has pixels 0 to 8191. In RGBG mode, red pixels are 0, 2, 4... Blue pixels are 1, 3, 5...
- 2) Custom AOIs are not supported in GREEN_ONLY mode.
- 3) Three values (red, blue, green) are output per pixel in RGB mode.
 - 4.1) Two values (red / blue, green) are output per pixel in RGBG mode.
 - 4.2) In RGBG non-mirrored mode, the first pixel of an AOI is always red / green.
 - 4.3) In RGBG mirrored mode, the first pixel of an AOI is always blue / green.
- 4) Whether mirroring is on or off, 0 is the leftmost pixel.
- 5) Whether mirroring is on or off, AOI 1 is readout first.
- 6) In normal mode, AOI 1 is closest to the sensor's left edge.
- 7) In mirror mode, AOI 1 is closest to the sensor's right edge.

Base and Medium Modes

- 1) The total number of pixels within each AOI must be a multiple of 8 and must be greater than or equal to 40.
- 2) In normal mode, the first pixel of each AOI (AOI left edge) must have the location $8i$, where $i = 0, 1, 2 \dots, 1023$ (i.e. 8, 960, 7680 are allowed, 12 is not allowed).
- 3) In mirror mode, the first pixel of each AOI (AOI right edge) must have the location $8i + 7$, where $i = 0, 1, 2 \dots, 1023$ (i.e. 7, 15, 4095 are allowed, 8 is not allowed).

Deca RGB Mode

- 1) The total number of pixels within each AOI must be a multiple of 40 and must be greater than or equal to 40.
- 2) In normal mode, the first pixel of each AOI (AOI left edge) must have the location $8i$, where $i = 0, 1, 2 \dots, 1023$ (i.e. 0, 8, 6000 are allowed, 12 is not allowed).
- 3) In mirror mode, the first pixel of each AOI (AOI right edge) must have the location $8i + 7$, where $i = 0, 1, 2 \dots, 1023$ (i.e. 7, 15, 4095 are allowed, 8 is not allowed).

Deca RGBG Mode

- 1) The total number of pixels within each AOI must be a multiple of 10 and must be greater than or equal to 40.
1. 2) In normal mode, the first pixel of each AOI (red left edge pixel) must have the location $10i$, where $i = 0, 1, 2 \dots, 815$ (i.e. 0, 40, 6000 are allowed, 8 is not allowed).
- 2) In mirror mode, the first pixel of each AOI (blue right edge pixel) must have the location $10i + 9$, where $i = 2, 3, 4 \dots, 818$ (i.e. 19, 5199 are allowed, 7, 8191 are not allowed).

Pixel Format Selection




Figure 11. Pixel Format Selection

The output pixel format can be selected between an RGB or BGR output using the `spf ASCII` command or by using `Pixel Format` in the `GENCP`.

The camera link output modes are the same except the red and blue positions are swapped.

Camera Link cable quality and length

The maximum allowable Camera Link cable length depends on the quality of the cable used and the Camera Link strobe frequency. Cable quality degrades over time as the cable is flexed. In addition, as the Camera Link strobe frequency is increased the maximum allowable cable length will decrease.

The Piranha4 cameras are capable of driving cables 10 metres or less in length. We do not guarantee good imaging performance with low quality cables of *any* length. In general, we recommend the use of high quality cables for any cable length.

Input Signals, Camera Link

The camera accepts control inputs through the Camera Link MDR26F connector. The camera ships in internal sync, and internally programmed integration.

EXSYNC (Line Readout Trigger)

Line rate can be set internally using the GenICam features. The external control signal EXSYNC is optional and enabled through the user interface. This camera uses the falling edge of EXSYNC to trigger pixel readout.

The EXSYNC signal tells the camera when to integrate and readout the image. It can be either an internally generated signal by the camera, or it can be supplied externally via the serial interface. Depending upon the mode of operation the high time of the EXSYNC signal can represent the integration period.

Note: The EXSYNC signal is measured at CC1 and will give a “true” measurement (i.e. within the measurement resolution of 25 ns) even though the camera will only trigger at a maximum of 50 KHz.

Output Signals, Camera Link Clocking Signals

These signals indicate when data is valid, allowing you to clock the data from the camera to your acquisition system. These signals are part of the Camera Link configuration and you should refer to the Camera Link Implementation Road Map, available at our [Knowledge Center](#), for the standard location of these signals.

Clocking Signal	Indicates
LVAL (high)	Outputting valid line
DVAL	Not used
STROBE (rising edge)	Valid data
FVAL	Not used

Power Connector



WARNING: It is extremely important that you apply the appropriate voltages to your camera. Incorrect voltages may damage the camera. Input voltage requirement: +12 VDC to +24 VDC, 2 Amps. Before connecting power to the camera, test all power supplies.

Hirose 6-pin Circular Male



Mating Part: HIROSE
HR10A-7P-6S

Figure 12: 6-pin Hirose Circular Male Power Plug—Power Connector

Table 5. Power Plug Pinout

Pin	Description	Pin	Description
1	+12 V to +24 V DC	4	GND
2	+12 V to +24 V DC	5	GND
3	+12 V to +24 V DC	6	GND

The camera requires a single voltage input +12 VDC to +24 VDC. The camera meets all performance specifications using standard switching power supplies, although well-regulated linear supplies provide optimum performance.

WARNING: When setting up the camera's power supplies follow these guidelines:



- Apply the appropriate voltages.
- Protect the camera with a 2 amp slow-blow fuse between the power supply and the camera.
- Do not use the shield on a multi-conductor cable for ground.
- Keep leads as short as possible in order to reduce voltage drop.
- Use high-quality supplies in order to minimize noise.

Note: If your power supply does not meet these requirements, then the camera performance specifications are not guaranteed.

LEDs

The camera is equipped with an LED on the back to display the operational status of the camera. The table below summarizes the operating states of the camera and the corresponding LED states. When more than one condition is active, the LED indicates the condition with the highest priority.

Color of Status LED	Meaning
Off	No power, or hardware malfunction.
Dark Blue	In boot-loader. Completing firmware upgrade.
Light Blue	Busy. For example, powering up or performing a calibration.
Green	Ready.
Red	Error. Check BiST register, in the list of GenICam commands , for the specific error.

Step 3. Establish Communication with the Camera

Power on the camera

Turn on the camera's power supply. You may have to wait while the camera readies itself for operation. The camera must boot fully before it will be recognized by the GUI—the LED shines green once the camera is ready.

Connect to the frame grabber

1. Start Sapera CamExpert (or equivalent Camera Link compliant interface) by double clicking the desktop icon created during the software installation.
2. CamExpert will search for installed Sapera devices. In the Devices list area on the left side, the connected frame grabber will be shown.
3. Select the frame grabber device by clicking on the name.

Connect to the camera

1. Start a new Sapera CamExpert application (or equivalent Camera Link compliant interface) by double clicking the desktop icon created during the software installation.
2. In the Devices list area on the left side, select the COM port below the Camera Link label.



Figure 13. CamExpert Icon, created during software installation




Figure 14. CamExpert GUI showing connected camera

Check LED Status

If the camera is operating correctly at this point, the diagnostic LED will shine green.

Software Interface

All the camera features can be controlled through the CamExpert interface. For example, under the Sensor Control menu in the camera window you can control the line rate and exposure times.

Note: the camera uses two CamExpert windows to send commands and display the results. One window controls the camera and the other is used for image acquisition and display.






Figure 15. Two CamExpert window shown. One connected to the frame grabber and one to the camera.

At this point your host and camera system should be setup and you can verify the camera's operation by retrieving a test pattern and setting the camera's trigger and exposure time.

Using Sapera CamExpert with Piranha4 Cameras

CamExpert is the camera interfacing tool supported by the Sapera library. When used with a Piranha4 camera, CamExpert allows a user to test all camera operating modes. Additionally CamExpert saves the camera user settings configuration to the camera or saves multiple configurations as individual camera parameter files on the host system (*.ccf). CamExpert can also be used to upgrade the camera's software.

An important component of CamExpert is its live acquisition display window which allows immediate verification of timing or control parameters without the need to run a separate acquisition program.

For context sensitive help, click on the  button then click on a camera configuration parameter. A short description of the configuration parameter will be shown in a popup. Click on the  button to open the help file for more descriptive information on CamExpert.

The central section of CamExpert provides access to the camera features and parameters.

Note: The availability of the features is dependent on the CamExpert user setting.

CamExpert Panes




Figure 16. CamExpert's Camera Control Window









Figure 17. CamExpert's Image Acquisition Window

The CamExpert application uses panes to simplify choosing and configuring camera files or acquisition parameters for the installed device.

- **Device Selector pane:** View and select from any installed Sopera acquisition device. Once a device is selected CamExpert will only present acquisition parameters applicable to that device. Optionally select a camera file included with the Sopera installation or saved by the user.
- **Parameters pane:** Allows viewing or changing all acquisition parameters supported by the acquisition device. CamExpert displays parameters only if those parameters are supported by the installed device. This avoids confusion by eliminating parameter choices when they do not apply to the hardware in use.
- **Display pane:** Provides a live or single frame acquisition display. Frame buffer parameters are shown in an information bar above the image window.
- **Control Buttons:** The Display pane includes CamExpert control buttons. These are:



 Snap	Single frame grab: Click to acquire one frame from device.
 Trigger	Software trigger button: With the I/ O control parameters set to Trigger Enabled / Software Trigger type, click to send a single software trigger command.
	CamExpert display controls: (these do not modify the frame buffer data) Stretch image to fit, set image display to original size, or zoom the image to any size and ratio.
	Histogram / Profile tool: Select to view a histogram or line/ column profile during live acquisition or in a still image.



- **Output Message pane:** Displays messages from CamExpert or the device driver.

Review a Test Image


The camera is now ready to retrieve a test pattern. Select **Image Format Control > Test Pattern** and choose one of the following available test images.

0. Off: Sensor Video

1. Grey Ramp



2. Ramp



Pixels: {1, 2, 3...}
Red Value: {0, 1, 2...}
Green Value: {102, 103, 104...}
Blue Value: {204, 205, 206...}
Values roll over at 255.

At this point you are ready to start operating the camera in order to acquire images, set camera functions, and save settings.

4. Camera Operation

Factory Settings

The camera ships and powers up for the first time with the following factory settings:

- Camera Link Medium, 8 bit pixels, 85 MHz
- Internal trigger, line rate 10 kHz
- Internal exposure control, exposure time 50 μ s
- Flat field disabled
- User coefficients set to 1x
- Offset 0, System Gain 1x
- White balanced gains all set to 1x
- Color correction disabled
- Corrected using an 80 mm lens and a magnification of 0.8

Check Camera and Sensor Information

Camera and sensor information can be retrieved via a controlling application—for example, the CamExpert GUI shown in the following examples. Parameters such as camera model, firmware version, sensor characteristics, etc. are read to uniquely identify the connected device.

The camera information parameters are grouped together as members of the Camera Information set.

Category	Parameter	Value
Camera Information	Model	P4_CC_08K050_00_R
Camera Control	Vendor	Teledyne_DALSA
Flat Field	Serial Number	14013769
Image Format	Microcode Version	03-081-20270-01
Transport Layer	CCI Version	03-110-20256-01
Acquisition and Transfer Control	FPGA Version	03-056-20412-01
Serial Port	Power-on Status	Good
File Access Control	LED Colour	Green
	Temperature	58.400
	Refresh Temperature	Press...
	Input Voltage	14.300
	Refresh Voltage	Press...
	Power-up Configuration	Setting...

Figure 18. CamExpert's Camera Information Window

Verify Temperature and Voltage

To determine the voltage and temperature at the camera, use the **Refresh Voltage and Refresh Temperature** features found in the **Camera Information** set.

The temperature returned is the internal temperature in degrees Celsius. For proper operation, this value should not exceed 75 °C. If the camera exceeds the designated temperature it will stop imaging and the LED will turn red. Once you have diagnosed and remedied the issue use the **reset camera** function.

The voltage displayed is the camera's input voltage.

Note: The voltage measurement feature of the camera provides only approximate results (typically within 10% and dependent on the voltage drop in the cable). The measurement should not be used to set the applied voltage to the camera, but only used as a test to isolate gross problems with the supply voltage.

Saving and Restoring Camera Settings

The parameters used to select, load and save user sets are grouped together under the Camera Information set of features. There are 8 user sets available and one factory set.

Camera Information	
Parameter	Choices
User Set Default Selector	Select the camera parameters to load when the camera is reset or powered up as the Factory set, or as User Set 1 to 8. Selecting the set from the list automatically saves it as the default set.
User Set Selector	Select the Factory or User set to Save or Load. -Factory Set -User Set 1 to 8.
User Set Load	Load the set specified by User Set Selector to the camera and make it the active / current set.
User Set Save	Save the current set as selected user set.

Description of the Camera Settings

The camera operates in one of three settings:

1. Current session.
2. User setting.
3. Factory setting (read-only).
4. Default setting.

The current settings can be saved (thereby becoming the user setting) using the User Set Save parameter. A previously saved user setting (User Set 1 to 8) or the factory settings can be restored using the User Set Selector and User Set Load parameters.

Either the Factory or one of the User settings can be saved as the Default Setting by selecting the set in the User Set Default Selector. The chosen set automatically saves as the default setting and is the set loaded when the camera is reset or powered up.

The relationship between these three settings is illustrated in Figure 19. Relationship between the Camera Settings:




Figure 19. Relationship between the Camera Settings

Active Settings for Current Session

The active setting for the current session is the set of configurations that are operating while the camera is currently running, including all unsaved changes you have made to the settings before saving them.

These active settings are stored in the camera's *volatile* memory and will be lost and cannot be restored if the camera resets or if the camera is powered down or loses power.

To save these settings for reuse the next time you power up or reset the camera, or to protect against losing them in the case of power loss, you must save the current settings using the **User Set Save** parameter. Once saved, the current settings become the selected **User Set**.

User Setting

The user setting is the saved set of camera configurations that you can customize, resave, and restore. By default the user settings are shipped with the same settings as the factory set.

The command **User Set Save** saves the current settings to non-volatile memory as a **User Set**. The camera automatically restores the last saved user settings when it powers up.

To restore the last saved user settings, select the **User Set** parameter you want to restore and then select the **User Set Load** parameter.

Factory Settings

The factory setting is the camera settings that were shipped with the camera and which loaded during the camera's first power-up. To load or restore the original factory settings, at any time, select the **Factory Setting** parameter and then select the **User Set Load** parameter.

Note: By default, the user settings are set to the factory settings.

Default Setting

Either the Factory or one of the User settings can be used as the Default Setting by selecting the set in the User Set Default Selector. The chosen set automatically becomes the default setting and is the set loaded when the camera is reset or powered up.

Camera Link Configuration

Name	Taps	SPF*	Cables
Base	3	RGB8, BGR8	1
Medium	6	RGB8, BGR8	2
Full (Green Only)	8	G8	2
Deca	10	RBG8, BGR8, RGBG8	2

*Set Pixel Format (number of bits per pixel)

Trigger Modes

The camera's image exposures are initiated by a trigger event. The trigger event is either a programmable internal signal used in free running mode, an external input used for synchronizing exposures to external triggers, or a programmed function call message by the controlling computer. These triggering modes are described below.

- **Internal trigger (trigger disabled):** The camera free-running mode has a programmable internal timer for line rate and a programmable exposure period.
- **External trigger (trigger enabled):** Exposures are controlled by an external trigger signal. The external trigger signal is the Camera Link control line CC1.

Exposure Controls

Exposure Control modes define the method and timing of how to control the sensor integration period. The integration period is the amount of time the sensor is exposed to incoming light before the video frame data is transmitted to the controlling computer.

- Exposure control is defined as the start of exposure and exposure duration.
- The start of exposure can be an internal timer signal (free-running mode) or an external trigger signal.
- The exposure duration can be programmable (such as the case of an internal timer) or controlled by the external trigger pulse width.

The camera can grab images in one of three ways. You determine the three imaging modes using a combination of the Exposure Mode parameters (including I/ O parameters), Exposure Time and Line Rate parameters.

Description	Line Rate	Exposure Time	Trigger Source (Sync)
Internal line rate and exposure time	Internal, programmable	Internal programmable	Internal
External line rate and exposure time	Controlled by EXSYNC pulse	External (EXSYNC)	External
EXSYNC pulse controlling the line rate. Programmed exposure time.	Controlled by EXSYNC pulse	Internal programmable	External

Figure 20. Exposure controls

The parameters used to select the imaging modes—trigger sources (sync), exposure time, and line rate—are grouped together as the Camera Controls.

Camera Controls	
Parameter	Description
Line Rate (in Hz)	Camera line rate in Hz. Only available when the start line trigger parameter is disabled (Trigger Mode off).
Exposure Mode	Set the operation mode for the camera's exposure. Trigger Width or Timed. Trigger Width is only available when Trigger Mode is enabled.
	Trigger Width Uses the width of the current line trigger signal pulse to control the exposure duration.
	Timed The exposure duration time is set using the Exposure Time feature and the exposure starts with the Line Start event.
Exposure Time	Sets the exposure time (in microseconds). Exposure Mode feature must be set to Timed

Exposure Modes in Detail

1. Internally Programmable Line rate and Internally Programmable Exposure Time (Default)

Line rate is the dominant factor when adjusting the line rate or exposure time. When setting the line rate, exposure time will decrease, if necessary, to accommodate the new line rate. When adjusting the exposure time the range is limited by the line rate.

Note: The camera will not set line periods shorter than the readout period.

GenICam parameters to set:
I / O Controls > Trigger Mode > Off

2. External Line Rate and External Exposure Time (Trigger Width)

In this mode, EXSYNC sets both the line period and the exposure time. The rising edge of EXSYNC marks the beginning of the exposure and the falling edge initiates readout. Note:

$$\text{maximum line rate} = \frac{1}{(\text{exposure time} + \text{low time}^*)}$$

*Exposure time must be greater than 6 μs and low time greater than 1,500 ns

GenICam parameters to set:

- **I / O Controls > Trigger Mode > On**
- **Sensor Control > Exposure Mode > Trigger Width**

Warning! When running external line rate and external exposure time, the line rate must not exceed $1 / (\text{exposure time} + 1,500 \text{ ns})$. Under these conditions the exposure time will become indeterminate and result in image artefacts. This is not the case when running internal exposure control.


3. External Line Rate, Programmable Exposure Time

In this mode, the line rate is set externally with the falling edge of EXSYNC generating the rising edge of a programmable exposure time.


GenICam parameters to set:

- **I / O Controls > Trigger Mode > On**
- **Sensor Control > Exposure Mode > Timed**


1. External Trigger Off, Internal Exposure Control
Free running, not synchronized to an external signal



2. External Trigger On, Internal Exposure Control
CC1 Falling edge triggers start of internal exposure³




3. External Trigger On, External Exposure Control
CC1 Falling edge triggers start of exposure
CC1 high duration sets the exposure time



Notes:

1. Exposure time > 7 micro-seconds
2. Sensor Readout time = 14 micro-seconds
3. One additional falling edge during exposure is latched

Figure 21. Exposure Modes



th min	6 μ s
tl min	1.5 μ s

Figure 22. External Trigger Minimum High and Low Times

Set Line Rate

To set the camera's line rate use the line rate parameter, part of the Sensor Controls set. This feature can only be used when the camera is in Internal mode—that is, when the start line trigger is disabled (Trigger Mode Off).

$$\text{maximum line rate} = \frac{1}{(\text{exposure time} + \text{low time}^*)}$$

*Exposure time must be greater than 6 μ s and low time greater than 1,500 ns

Note: Line rate > (Exposure time + 1,500 ns) will return an error (“Invalid Parameter”) if this condition is not met. You must adjust these two parameters in the correct sequence to maintain this condition.

If the external line rate exceeds 50 kHz the camera will continue to output data at its maximum line rate of 50 kHz. Though no image artefacts associated with over-speed will occur, you may notice that under over-speed conditions the image will appear compressed and the apparent distance travelled will be reduced.

Camera Control	
Parameter	Description
Line Rate (in Hz)	Camera line rate in a range from 1 Hz to 50 KHz. This feature is only available when the camera is in Internal Mode—line trigger is disabled (Trigger Mode off).

Line Rates	
Camera Link Configuration	Maximum Line Rate
Base	10 kHz, Base RGB8
Medium	20 kHz
Deca	50 kHz (Deca RGBG8) / 34 kHz (Deca RGB8)

Table 6: Line Rates vs AOI

CL Clock Rate	Number of AOI	CL Configuration	Line Rate Formula (Hz)
85 MHz	1	Base RGB8	Max: 70KHz $Rate = \frac{85000000}{AOIwidth1}$
		Medium RGB8	Max: 70KHz $Rate = \frac{85000000}{0.5 \times AOIwidth1}$
		Full RGB8	Max: 70KHz $Rate = \frac{85000000}{0.3 \times AOIwidth1}$
		Deca RGB8	Max: 70KHz $Rate = \frac{85000000}{0.2(AOIwidth1)}$
85 MHz	2	Base RGB8	Max: 70KHz $Rate = \frac{85000000}{(AOIwidth1 + AOIwidth2)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{85000000}{0.5 \times (AOIwidth1 + AOIwidth2)}$
		Full RGB8	Max: 70KHz $Rate = \frac{85000000}{0.3 \times (AOIwidth1 + AOIwidth2)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{85000000}{0.2(AOIwidth1 + AOIwidth2)}$
85 MHz	3	Base RGB8	Max: 70KHz $Rate = \frac{85000000}{(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{85000000}{0.5 \times (AOIwidth1 + AOIwidth2 + AOIwidth3)}$

CL Clock Rate	Number of AOI	CL Configuration	Line Rate Formula (Hz)
		Full RGB8	Max: 70KHz $Rate = \frac{85000000}{0.3 \times (AOIwidth1 + AOIwidth2 + AOIwidth3)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{85000000}{0.2(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
85 MHz	4	Base RGB8	Max: 70KHz $Rate = \frac{85000000}{(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{85000000}{0.5 \times (AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$
		Full RGB8	Max: 70KHz $Rate = \frac{85000000}{0.3 \times (AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{85000000}{0.2(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$

CL Clock Rate	Number of AOI	CL Configuration	Line Rate Formula (Hz)
42.5 MHz	1	Base RGB8	Max: 70KHz $Rate = \frac{42500000}{(AOIwidth1)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{42500000}{0.5(AOIwidth1)}$
		Full RGB8	Max: 70KHz $Rate = \frac{42500000}{0.3(AOIwidth1)}$

CL Clock Rate	Number of AOI	CL Configuration	Line Rate Formula (Hz)
		Deca RGB8	Max: 70KHz $Rate = \frac{42500000}{0.2(AOIwidth1)}$
42.5 MHz	2	Base RGB8	Max: 70KHz $Rate = \frac{42500000}{(AOIwidth1 + AOIwidth2)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{42500000}{0.5(AOIwidth1 + AOIwidth2)}$
		Full RGB8	Max: 70KHz $Rate = \frac{42500000}{0.3(AOIwidth1 + AOIwidth2)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{42500000}{0.2(AOIwidth1 + AOIwidth2)}$
42.5 MHz	3	Base RGB8	Max: 70KHz $Rate = \frac{42500000}{(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{42500000}{0.5(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
		Full RGB8	Max: 70KHz $Rate = \frac{42500000}{0.3(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{42500000}{0.2(AOIwidth1 + AOIwidth2 + AOIwidth3)}$
42.5 MHz	4	Base RGB8	Max: 70KHz $Rate = \frac{42500000}{(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$
		Medium RGB8	Max: 70KHz $Rate = \frac{42500000}{0.5(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$

CL Clock Rate	Number of AOI	CL Configuration	Line Rate Formula (Hz)
		Full RGB8	Max: 70KHz $Rate = \frac{42500000}{0.3(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$
		Deca RGB8	Max: 70KHz $Rate = \frac{42500000}{0.2(AOIwidth1 + AOIwidth2 + AOIwidth3 + AOIwidth4)}$

Set Exposure Time

To set the camera's exposure time, use the **Exposure Time** parameter—a member of the Sensor Controls set. This feature is only available when the **Exposure Mode** parameter is set to **Timed**. The allowable exposure range is from 8 μs to 3,000 μs, dependent on the value of the internal line rate.

GenICam parameters:

Sensor Controls > Exposure Time (Timed Exposure Mode) > 8 μs to 3,000 μs.

Control Gain and Black Level

The cameras provide gain and black level adjustments in the digital domain for the CMOS sensor. The gain and black level controls can make small compensations to the acquisition in situations where lighting varies and the lens iris cannot be easily adjusted. The user can evaluate gain and black level by using CamExpert.

The parameters that control gain and black level are grouped together in the Sensor Controls set.

Sensor Controls	
Black Level	Apply a digital addition after an FPN correction: ± 1/ 8 of the available range of -32 to +31.
Gain	Set the gain as an amplification factor applied to the video signal across all pixels: 1x to 10x.

Set Image Size

To set the height of the image, and therefore the number of lines to scan, use the parameters grouped under the Image Format Control set.

Image Format Control	
Control the size of the transmitted image	
Width	Width of the image.
Height	Height of the image in lines.

Pixel Format	8 bit depth to Camera Link.
Test Image Selector	Select an internal test image: Off Color Ramp Grey Ramp

Set Baud Rate

The baud rate sets the speed (in bits per second—bps) of the serial communication port and is available as part of the Serial Port Control parameters.

Serial Port Control		
Action	Parameter	Options
Control the baud rate used by the camera's serial port	Baud Rate	9600 (factory default) 19200 57600 115200 230400* 460800* 921600* Note: During connection CamExpert automatically sets the camera to maximum allowable baud. *Your system requires a Px8 frame grabber to achieve these baud rates.
Number of bits per character used in the serial port	Data Size	8
Parity of the serial port	Parity	None
Number of stop bits per character used in the serial port	Number of Stop Bits	1

Pixel Format

Use the Pixel Format feature, found in the **Image Format Control** set, to select the format of the pixel to use during image acquisition.

Image Format Control	
Parameter	Description
Pixel Format	RGB8 / G8 / RGBG8 / BGR8

Camera Direction Control

Found in the **I / O Control > Direction Control** set of features.

Note: This feature is available when in high sensitivity mode only (TDI stage 2).

Direction Control	
Parameter	Description
Sensor Scan Direction	When in TDI stages 2, this command lets you select the Internal or external direction control . Use this feature to accommodate object direction change on a web and to mount the camera "upside down."
Scan Direction	Read the current direction.

Pixel Readout Direction (Mirroring Mode)

Set the tap readout from left to right or from right to left. This feature is especially useful if you want to mount the camera "upside down."

Image Format Control	
Parameter	Description
ReverseX	Off: All pixels are read out from left to right. On: All pixels are read out from right to left.

Resetting the Camera

The feature **Camera Reset**, part of the **Transport Layer** set, resets the camera. The camera resets with the default settings, including a baud rate of 9600.

Camera Information	
Parameter	Description
Camera Reset	Resets the camera and puts in the default settings, including a 9600 baud rate.

Calibrating the Camera

Important Note: to ensure best results, the conditions under which you calibrate the camera (e.g. temperature and illumination) should be as close to the actual operating conditions as possible.

Category	Parameter	Value
Camera Information	Mode	On
Camera Control	Scan Direction Reverse Set	Not Enabled
Flat Field	Calibration Algorithm	Basic
Image Format	Calibration Target	200
Transport Layer	Calibration Sample Size	4096
Acquisition and Transfer Control	ROI Offset X	1
Serial Port	ROI Width	8192
File Access Control	Calibrate FPN	Press...
	Calibrate PRNU	Press...
	Balance White Auto	Press...

Figure 23: Flat Field Calibration in CamExpert

Overview

The following diagram and accompanying description explain the camera's signal processing chain. Each element shown, with the exception of color interpolation, is user programmable.




Figure 24: Camera Calibration Process.

Digital Processing

1. Fixed pattern noise (FPN) calibration is used to subtract any residual dark level that may occur in the application.
2. Photo response non uniformity (PRNU) calibration is used to correct for variations in the illumination intensity and / or lens vignetting. When performed, this calibration will cause the camera to have a flat response to a white target in the field of view. The output target value for PRNU calibration can be set by the user.
3. The white balancing gains are used set the red, green and blue response to equal values with a white target in the field of view. The white balance gains can be individually set by the user, but will be overridden by the camera when the camera performs PRNU calibration or white balancing commands.
4. The sensor has 4K red and 4k blue alternating pixels. To create 8K red and 8k blue pixels, the blue pixels located at the red position are determined by averaging the two adjacent blue pixels. The

same process is used for the red pixels. This is the only interpolation algorithm provided by the camera.

5. Color correction is available for those users that need to compensate for the spectral transmission characteristics of the sensors color filters and the customers light source. This can be achieved by imaging a MacBeth Chart© illuminated by the application's light source and processing the image using a color correction demonstration tool provided as part of Teledyne DALSA's Sopera Processing software. This tool will generate the desired color correction file that can be downloaded to the camera.

Note: Prior to imaging the MacBeth Chart©, the camera should have been calibrated with a white reference in place of the MacBeth Chart© and color correction must be turned off. The calibration process will ensure the camera output is uniform and white balanced.

6. The introduction of offsets has limited value in color applications as it will cause color distortion. However, the camera has the ability to add either a positive or negative offset as required by a specific application. This offset can be useful when trying to measure dark noise where black level clipping will cause an error in the result.
7. A single overall system gain is applied equally to all three colors. It will therefore not cause color distortion when changed.
8. A factory setting for white LED color correction can be applied, if needed.

Calibration

The goal of calibration is to produce a uniform, white balanced and, if required, color corrected image at the desired level out of the camera when it is imaging a uniform white object, using the optical setup of the user's application.

The user should configure the camera to use the EXSYNC and exposure timing they desire plus adjust the light level for normal operation. The lens should be at the desired magnification, aperture and be in focus. As the white reference located at the object plane will be in focus, any features on its surface (e.g. dust, scratches) will end up in the calibration profile of the camera. To avoid this, use a clean white plastic or ceramic material, not paper. Ideally, the white object should move during the calibration process as the averaging process of the camera will diminish the effects on any small variation in the white reference.

The user may wish to start the calibration process by evaluating the characteristics of their setup with no calibration enabled. This can be readily achieved by disabling FPN, PRNU & color correction coefficients, setting white balance red, green and blue gains to one, and the system gain to one.

Begin by adjusting the system gain until the peak intensity of the three colors is at the desired DN level. You may want to use the white balance gains to adjust the peak of each color to be a similar DN value, but this is not necessary. Before proceeding any further, it is desirable to complete an FPN calibration. This is best performed using a lens cap to ensure no light gets into the camera. Once complete, a PRNU calibration can be performed using a target value you want all the pixels to achieve. This target value can be higher or lower than the peak values you observed while initially setting up the camera. Once PRNU calibration is complete, it will take several seconds, all three colors should be at the target value, white balance gains will have been adjusted to suit the cameras optimum setup for a balanced white output, and the correction coefficient will be enabled. The system gain will remain as originally set. The coefficient and gain parameters, timing and control configuration etc can be stored in any one of eight user sets and automatically retrieved at power up or by user selection. If a color correction matrix is desired, the user can download and save a color correction file derived from the process described above. **Note:** For the color correction to be affective, the camera should have a white balanced output when color correction is off.

1. Flat Field

This Flat Field set contains a number of features that are used to correct image distortion due to lens vignetting and uneven illumination. .

Note:

1. Flat field coefficients consist of an offset and gain for each pixel.
2. These are the first user corrections applied to the image.
3. The flat field coefficients are saved and loaded with the user set.

Parameter	Description
flatfieldCorrectionMode	<ol style="list-style-type: none"> 1. Off – Flat field correction coefficients are not applied. 2. On – Flat field correction coefficients are applied. 3. Initialize – Sending this value will reset all current coefficients (offsets to 0 and gains to 1x).
flatfieldCorrectionAlgorithm	<ol style="list-style-type: none"> 1. Basic – Direct calculation of coefficients based on current average line values and target. 2. LowPass – A low pass filter is first applied to the current average line values before calculating the coefficients. Use this algorithm if the calibration target is not uniform white or it is not possible to defocus the image. Because of the low pass filter this algorithm is not able to correct pixel-to-pixel variations and so it is preferable to use the “Basic” algorithm if possible.
flatfieldCalibrationTarget	<ol style="list-style-type: none"> 1. After calibration all pixels will be scaled to output this level <ul style="list-style-type: none"> • Range: 8 bit, 0 to 255 DN
flatfieldCalibrationSampleSize	<ol style="list-style-type: none"> 1. Number of lines to average when calibrating 2. 2048 or 4096
flatfieldCalibrationROIOffsetX	<ol style="list-style-type: none"> 1. Together with “flatfieldCalibrationROIWidth” specifies the range of pixels to be calibrated. Pixel coefficients outside this range are not changed. It is possible to calibrate different regions sequentially.
flatfieldCalibrationROIWidth	
flatfieldCalibrationFPN	<ol style="list-style-type: none"> 1. Save average line (of “flatfieldCalibrationSampleSize” rows). This is the first user correction applied – it is subtracted from each line. 2. This feature may not be of use to many users as the camera already subtracts true “dark current”, but it may be useful for some to provide a per pixel offset correction. 3. Range 0 to 31 DN, 8 bit 4. Default value is 0 DN for each pixel
flatfieldCalibrationPRNU	<ol style="list-style-type: none"> 1. Use “flatfieldCorrectionAlgorithm” to calculate the per pixel gain to achieve the specified target output. 2. Max 15.9998x 3. Default 1x

2. Contrast Enhancement

The offset and gain features can be used to maximize the use of the output dynamic range. Typical use is to subtract the minimum pixel value expected and then gain up to the maximum pixel value to approach full scale. This process may be useful for applications that process the RGB colors individually.

Offset

1. Single value added to each pixel
2. Range -32 to +31 DN
3. Positive values may be used to measure dark noise

Gain

1. Floating point digital multiplier applied to each pixel
2. Range 1x to 10x

Appendix A: GenICam Commands

This appendix lists the available GenICam camera features. Access these features using the CamExpert interface.

Features listed in the description table but tagged as *Invisible* are typically reserved for Teledyne DALSA Support or third party software usage, and not typically required by end user applications.

A note on the CamExpert examples shown here: The examples shown for illustrative purposes and may not entirely reflect the features and parameters available from the camera model used in your application.

Camera Information Category

Camera information can be retrieved via a controlling application. Parameters such as camera model, firmware version, etc. are read to uniquely identify the connected P4 device. These features are typically read-only.

The Camera Information Category groups information specific to the individual camera. In this category the number of features shown is identical whether the view is Beginner, Expert, or Guru.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

Category	Parameter	Value
Camera Information	Model	P4_CC_08K050_00_R
Camera Control	Vendor	Teledyne_DALSA
Flat Field	Serial Number	14013769
Image Format	Microcode Version	03-081-20292-02
Transport Layer	CCI Version	03-110-20291-02
Acquisition and Transfer Control	FPGA Version	03-056-20412-02
Serial Port	Power-on Status	Good
File Access Control	LED Colour	Green
	Temperature	26.400
	Refresh Temperature	Press...
	Input Voltage	10.400
	Refresh Voltage	Press...
	License Key	7F0CBF4C-00000000
	Power-up Configuration	Setting...
	<< Less	

Camera Information Feature Descriptions

The following table describes these parameters along with their view attributes and in which version of the device the feature was introduced. Additionally the Device Version column will indicate which parameter is a member of the DALSA Features Naming Convention (using the tag **DFNC**), versus the GenICam Standard Features Naming Convention (SFNC not shown).


The Device Version number represents the camera software functional group, not a firmware revision number.

Display Name	Feature	Description	Device Version & View
Vendor Name	DeviceVendorName	Displays the device vendor name. (RO)	1.00 Beginner
Model Name	DeviceModelName	Displays the device model name. (RO)	1.00 Beginner
Device Version	DeviceVersion	Displays the device version. This tag will also highlight if the firmware is a beta or custom design. (RO)	1.00 Beginner
Manufacturer Info	DeviceManufacturerInfo	This feature provides extended manufacturer information about the device. (RO)	1.00 Beginner
Firmware Version	DeviceFirmwareVersion	Displays the currently loaded firmware version number. Firmware files have a unique number and have the .cbf file extension. (RO)	1.00 Beginner
Serial Number	DeviceID	Displays the device's factory set camera serial number. (RO)	1.00 Beginner
Device User ID	DeviceUserID	Feature to store user-programmable identifier of up to 15 characters. The default factory setting is the camera serial number. (RW)	1.00 Beginner
Power-up Configuration Selector	UserSetDefaultSelector	Selects the camera configuration set to load and make active on camera power-up or reset. The camera configuration sets are stored in camera non-volatile memory. (RW)	1.00 Beginner
Factory Setting	Default	Load factory default feature settings	
UserSet1	UserSet1	Select the user defined configuration UserSet 1 as the Power-up Configuration.	
UserSet2	UserSet2	Select the user defined configuration UserSet 2 as the Power-up Configuration	
UserSet3	UserSet3	Select the user defined configuration UserSet 3 as the Power-up Configuration	
UserSet4	UserSet4	Select the user defined configuration UserSet 4 as the Power-up Configuration.	
UserSet5	UserSet5	Select the user defined configuration UserSet 5 as the Power-up Configuration.	
UserSet6	UserSet6	Select the user defined configuration UserSet 6 as the Power-up Configuration.	

UserSet7	UserSet7	Select the user defined configuration UserSet 7 as the Power-up Configuration.	
UserSet8	UserSet8	Select the user defined configuration UserSet 8 as the Power-up Configuration.	
User Set Selector	UserSetSelector	Selects the camera configuration set to load feature settings from or save current feature settings to. The Factory set contains default camera feature settings. (RW)	1.00 Beginner
Factory Setting	Default	Select the default camera feature settings saved by the factory	
UserSet 1	UserSet1	Select the User-defined Configuration space UserSet1 to save to or load from features settings previously saved by the user.	
UserSet 2	UserSet2	Select the User-defined Configuration space UserSet2 to save to or load from features settings previously saved by the user.	
UserSet3	UserSet3	Select the User-defined Configuration space UserSet3 to save to or load from features settings previously saved by the user.	
UserSet4	UserSet4	Select the User-defined Configuration space UserSet4 to save to or load from features settings previously saved by the user.	
UserSet5	UserSet5	Select the User-defined Configuration space UserSet5 to save to or load from features settings previously saved by the user.	
UserSet6	UserSet6	Select the User-defined Configuration space UserSet6 to save to or load from features settings previously saved by the user.	
UserSet7	UserSet7	Select the User-defined Configuration space UserSet7 to save to or load from features settings previously saved by the user.	
UserSet8	UserSet8	Select the User-defined Configuration space UserSet8 to save to or load from features settings previously saved by the user.	
Power-on User Set	UserSetDefaultSelector	Allows the user to select between the factory set and 1 to 8 usersets to be loaded at power up	1.00 Beginner
Current User Set	UserSetSelector	Points to which user set (1-8) or factory set that is loaded or saved when the UserSetLoad or UserSetSave command is used	1.00 Beginner
Load Configuration	UserSetLoad	Loads the camera configuration set specified by the User Set Selector feature, to the camera and makes it active. (W)	1.00 Beginner
Save Configuration	UserSetSave	Saves the current camera configuration to the user set specified by the User Set Selector feature. The user sets are located on the camera in non-volatile memory. (W)	1.00 Beginner
Device Built-In Self Test Status	deviceBISTStatus	Determine the status of the device using the 'Built-In Self Test'. Possible return values are device-specific. (RO)	1.00 DFNC Beginner

LED Color	deviceLEDColorControl	Displays the status of the LED on the back of the camera. (RO)	1.00 DFNC Beginner
Temperature	DeviceTemperature	Displays the internal operating temperature of the camera. (RO)	1.00 DFNC Beginner
Refresh Temperature	refreshTemperature	Press to display the current internal operating temperature of the camera.	1.00 DFNC Beginner
Input Voltage	deviceInputVoltage	Displays the input voltage to the camera at the power connector (RO)	1.00 DFNC Beginner
Refresh Voltage	refreshVoltage	Press to display the current input voltage of the camera at the power connector	1.00 DFNC Beginner
License Key	securityUpgrade		1.00 DFNC Guru

Camera Configuration Selection Dialog



CamExpert provides a dialog box which combines the features to select the camera power up state and for the user to save or load a camera state from Genie memory.

Camera Power-up Configuration

The first drop list selects the camera configuration state to load on power-up (see feature *UserSetDefaultSelector*). The user chooses from one factory data set or one of two possible user saved states.

User Set Configuration Management

The second drop list allows the user to change the camera configuration anytime after a power-up (see feature *UserSetSelector*). To reset the camera to the factory configuration, select *Factory Setting* and click Load. To save a current camera configuration, select User Set 1 to 8 and click Save. Select a saved user set and click Load to restore a saved configuration.

Camera Control Category

The P4 camera controls, as shown by CamExpert, groups sensor specific parameters. This group includes controls for line rate, exposure time, scan direction, and gain. Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Category	Parameter	Value
Camera Information	Sensor ColorType	CFA_RBGG
Camera Control	Internal Line Rate	Not Enabled
I/O Controls	Measured Line Rate	0
Flat Field	Refresh Measured Line Rate	Press...
Image Format	Exposure Time Source	Trigger Width
Transport Layer	Exposure Time	50
Acquisition and Transfer Control	Measured Exposure Time	25.043
Serial Port	Refresh Measured Exposure Time	Press...
File Access Control	Direction Source	Internal
	Internal Direction	Forward
	Offset	0
	Gain Selector	SystemGain
	Gain	3
	Color Transformation Matrix Selector	NoCorrectionFactorySet
	Color Transformation Value Selector	Gain00
	Color Transformation Value	1
	Line Spatial Correction	0
	<< Less	

Camera Control Feature Descriptions

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

The Device Version number represents the camera software functional group, not a firmware revision number.

Display Name	Feature	Description	Device Version & View
Sensor Color Type	sensorColorType CFA_RGB CFA_RGBG	Defines the camera sensor color type. (RO) Sensor color type is RGB	1.00 DFNC Beginner
Internal Line Rate	AcquisitionLineRate	Specifies the camera internal line rate, in Hz when Trigger mode set to internal. Note that any user entered value is automatically adjusted to a valid camera value.	1.00 Beginner
Measured Line Rate	measureLineRate	Specifies the line rate provided to the camera by either internal or external source (RO)	1.00 Beginner
Refresh measured line rate	refreshMeasureLineRate	Press to show the current line rate provided to the camera by either internal or external sources	1.00 Beginner
Exposure Time Source	ExposureMode	Sets the operation mode for the camera's exposure (or shutter). (RO)	1.00 Beginner
Timed	Timed	The exposure duration time is set using the Exposure Time feature and the exposure starts with a LineStart event.	
Trigger Width	TriggerWidth	Uses the width of the trigger signal pulse to control the exposure duration.	
Exposure Time	ExposureTime	Sets the exposure time (in microseconds) when the Exposure Mode feature is set to Timed.	1.00 Beginner
Measured Exposure Time	measureExposureTime	Specifies the exposure time provided to the camera by either internal or external source (RO)	1.00 Beginner
Refreshed measured exposure time	refreshMeasureExposureTime	Press to display the current exposure time provided to the camera.	1.00 Beginner
Direction Source	sensorScanDirectionSource Internal External	Direction determined by value of SensorScanDirection Direction control determined by value on CC3	1.00 Beginner
Internal Direction	sensorScanDirection Forward Reverse	When ScanDirectionSource set to Internal, determines the direction of the scan	1.00 Beginner
Gain Selector	GainSelector	Selects which gain is controlled when adjusting gain features.	1.00 Beginner

	SystemGain	Apply a digital gain adjustment to the entire image	
	Red	Apply a digital gain adjustment to the red channel only	
	Green	Apply a digital gain adjustment to the red channel only	
	Blue	Apply a digital gain adjustment to the red channel only	
		Apply a digital gain adjustment to the red channel only	
Gain	Gain	Sets the selected gain as an amplification factor applied to the image.	1.00 Beginner
Offset	BlackLevel	Controls the black level as an absolute physical value. This represents a DC offset applied to the video signal, in DN (digital number) units.	1.00 Beginner
Color Transformation Selector	colorTransformationSelector	Allows the user to select between two factory programmed matrixes or two user loaded sets	1.00 Beginner
	WhiteLEDFactorySet	Color Correction Matrix for a white LED	
	NoCorrectionFactorySet	No correction	
	MatrixUserSet1	User programmable/ loaded correction matrix	
	MatrixUserSet2	User programmable/ loaded correction matrix	
Color Transformation Value Selector	ColorTransformationValueSelector	Allows the user to manually adjust correction value in the matrix	1.00 Beginner
	Gain00		
	Gain01		
	Gain02		
	Gain10		
	Gain11		
	Gain12		
	Gain20		
	Gain21		
	Gain22		
	Offset1		
	Offset2		
	Offset3		
Color Transformation Value	ColorTransformationValue	Value entered as pointed to by ColorTransformationValueSelector, $-32 < \text{value} < 32$	1.00 Beginner
Line Spatial Correction	sensorLineSpatialCorrection	Set the number of rows between imaging lines	1.00 Beginner

	Red	Green	Blue	Offset
Red	Gain00	Gain01	Gain02	Offset1
Green	Gain10	Gain11	Gain12	Offset2
Blue	Gain30	Gain31	Gain32	Offset3

Digital I/O Control Feature Descriptions

The P4 Digital I/O controls, as shown by CamExpert, groups sensor specific parameters. This group includes controls for line rate, exposure time, scan direction, and gain. Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Category	Parameter	Value
Camera Information	Trigger Source	CC1
Camera Control	Trigger Selector	LineStart
I/O Controls	Trigger Mode	On
Flat Field	<< Less	
Image Format		
Transport Layer		
Acquisition and Transfer Control		
Serial Port		
File Access Control		

Digital I/O Control Feature Descriptions

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

The Device Version number represents the camera software functional group, not a firmware revision number.

Display Name	Feature	Description	Device Version & View
Trigger Source	Trigger Source	Defines the source of external trigger (RO)	1.00 DFNC Beginner
Trigger Selector	Trigger Selector	Defines what the trigger initiates (RO)	1.00 DFNC Beginner
Trigger Mode	Trigger Mode	Determines the source of trigger to the camera, internal or external (CC1)	1.00 DFNC Beginner

Flat Field Category

The P4 Flat Field controls, as shown by CamExpert, group parameters used to configure camera pixel format, and image cropping. Additionally a feature control to select and output an internal test image simplifies the process of setting up a camera without a lens.

Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

Category	Parameter	Value
Camera Information	Mode	On
Camera Control	Scan Direction Reverse Set	Not Enabled
I/O Controls	Calibration Algorithm	Basic
Flat Field	Calibration Target	100
Image Format	Calibration Sample Size	4096
Transport Layer	ROI Offset X	1
Acquisition and Transfer Control	ROI Width	8192
Serial Port	Calibrate FPN	Press...
File Access Control	Calibrate PRNU	Press...
	Calibrate PRNU Status	Good
	Balance White Auto	Press...
	<< Less	

Flat Field Control Feature Description

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

The Device Version number represents the camera software functional group, not a firm ware revision number.

Display Name	Feature	Description	Device Version & View
Mode	flatfieldCorrectionMode		1.00
Off	Off	FPN and flat field coefficients disabled.	Beginner
On	On	FPN and flat field coefficients enabled.	DFNC
Initialize	Initialize	Reset all FPN to 0 and all flat field coefficients to 1.	

ScanDirectionControlled	ScanDirectionControlled	Different user set loaded depending on direction.	
Select flatfield Correction Scan Direction Reverse Set	flatfieldScanDirectionReverseSet	When flatfieldCorrectionMode is set to ScanDirectionControlled this feature selects the UserSet (1 to8) which will be used for the reverse scan direction.	1.00 Beginner DFNC
Calibration Algorithm Basic LowPass	flatfieldCorrectionAlgorithm Basic LowPass	Selection between two different flat field algorithms. Direct calculation of coefficients based on average line values and target. First each color is flat fielded to its peak value and then the color gains are used to achieve the target. A low pass filter is first applied to the average line values before calculating the coefficients. Use this algorithm if the calibration target is not uniformly white or it is not possible to defocus the image. Because of the low pass filter this algorithm is not able to correct pixel-to-pixel variations and so it is preferable to use the "Basic" algorithm.	1.00 Beginner DFNC
Calibration Target	flatfieldCalibrationTarget	Set a value between 0 and 255 to which the flat field algorithm will target the image to.	1.00 Beginner DFNC
Calibration Sample Size Lines_2048 Lines_4096	flatfieldCalibrationSampleSize Lines_2048 Lines_4096	Sets the number of lines to be averaged during a flat field calibration	1.00 Beginner DFNC
ROI Offset X	flatfieldCalibrationROIOffsetX	Set the starting point of a region of interest where a flat field calibration will be performed	1.00 Beginner DFNC
ROI Width	flatfieldCalibrationROIWidth	Sets the width of the region on interest where a flat field calibration will be performed	1.00 Beginner DFNC
Calibrate FPN	flatfieldCalibrationFPN	Initiates the FPN calibration process	1.00 Beginner DFNC
Calibrate PRNU	flatfieldCalibrationPRNU	Initiates the PRNU or Flatfield process	1.00 Beginner DFNC

Balance White Auto	BalanceWhiteAuto	Initiates the process of balancing the colors to produce a white balance	1.00 Beginner DFNC
--------------------	------------------	--	--------------------------

Region of Interest (ROI)

The ROI feature is related to flat field calibration. It is important to specify an ROI when the object being imaged has areas that have black, non illuminated areas such as beyond the edge of a film that is front illuminated, or is saturated, again beyond the edge of a film but in this case bright field back illuminated. The ROI feature allows from one to four specific regions of the pixel line to be specified where flat field calibration will take place. Pixel data outside the ROI will not be used when performing flat field calibration.

Image Format Control Category

The P4 Image Format controls, as shown by CamExpert, groups parameters used to configure camera pixel format, image cropping, and the test pattern.

Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

The screenshot shows a window titled "Parameters" with a close button (X) in the top right corner. The window is divided into two main sections: a left-hand navigation pane and a right-hand main content area. The navigation pane has a tree view with categories: "Board", "Camera - CameraLink_1", and "Image Format". The "Image Format" category is selected and highlighted. The main content area displays a table of parameters for the selected category. The table has three columns: "Parameter", "Value", and "Value". The parameters listed are: Test Pattern (Color_Ramp), Line Mirroring (Off), Pixel Format (RGB8), Pixel Coding (Color), Pixel Color Filter (None), Width (4096), WidthMax (4096), Height (1), Multiple AOI Mode (Off), AOI Count (1), AOI Selector (1), AOI Offset X (1), and AOI Width (4096). Below the table, there is a button labeled "<< Less".

Category	Parameter	Value
Image Format	Test Pattern	Color_Ramp
	Line Mirroring	Off
	Pixel Format	RGB8
	Pixel Coding	Color
	Pixel Color Filter	None
	Width	4096
	WidthMax	4096
	Height	1
	Multiple AOI Mode	Off
	AOI Count	1
	AOI Selector	1
	AOI Offset X	1
	AOI Width	4096
	<< Less	

Image Format Control Feature Description

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

The Device Version number represents the camera software functional group, not a firmware revision number.

Display Name	Feature	Description	Device Version & View
Test Pattern	TestImageSelector	Selects the type of test image that is sent by the camera. Choices are either as defined by SNFC and/ or as provided by the device manufacturer.	1.00 Beginner DFNC
Off	Off	Selects sensor video to be output from sensor	
Ramp	Ramp	Selects a grey scale	
Color_Ramp	Color_Ramp	Selects a color ramp	
Line Mirroring	ReverseX		1.00
Off	Off	Video output in normal order	Beginner
On	On	Video output in a reverse order	DFNC
Pixel Format	Pixel Format	Output image pixel coding format of the sensor.	1.00 Beginner DFNC
RGB8	RGB8	RGB8	
BGR8	BGR8	BGR8	
RGBG8	RGBG8	RGBG8	
G8	G8	G8	
Pixel Color Filter	PixelColorFilter	Indicates the type of color filter applied to the image. (RO)	1.00 Beginner DFNC
Pixel Coding	PixelCoding	(RO)	1.00 Beginner DFNC
Width	Width	Width of the Image provided by the device (in pixels).(RO)	1.00 Beginner
Max Width	WidthMax	The maximum image horizontal dimension of the image. (RO)	1.00 Beginner
Height	Height	Height of the Image provided by the device (in lines). (RO)	1.00 Beginner
Multiple AOI Mode	multipleAOIMode	Turns on an output Area of Interest	1.00
Off	Off	Area of interest is off	Beginner
Active	Active	Area of interest is on	DFNC
Multiple AOI Count	multipleAOICount	Set the number of output area of interest	1.00
		1-4	Beginner DFNC

Multiple AOI Selector	multipleAOISelector	Selects the area of interest to be setup	1.00 Beginner DFNC
AOI Offset X	multipleAOIOffsetX	Set the start of area of interest (pixels)	1.00 Beginner
AOI Width	multipleAOIWidth	Set the width of area of interest (pixels)	1.00 Beginner DFNC

Area of Interest (AOI) Setup

The Area of Interest (AOI) feature can be used to reduce the amount of image-data output from the camera. Use this feature when there are areas in the image that contain unneeded information.

An example where you would use this feature is in an application that is inspecting several separated lanes of objects with one camera and the image between the lanes can be ignored.

The AOI feature allows from one to four specific areas of the pixel line to be specified where image data will be output. Since the AOI feature reduces the amount of data output, this has the additional benefit of allowing the cameras to operate at higher EXSYNC rates when using base, medium, or full camera link modes.

For example, if the total number of pixels for the specified AOI's is less than 1 K when using base Camera Link mode at 85 MHz, the maximum EXSYNC rate can be 70 KHz; versus 10 KHz if all 8 K pixels were output.

Note: The setup of AOI is always with respect to the sensor. Therefore, if you are using the mirroring mode with AOI, be aware that pixel one will be on the right side of the displayed image.

In order to set up an AOI for the camera:

1. The AOI mode must first be in the off position.
2. Use the AOI Count to select the total number of AOIs desired to a max of 4.
3. To set up each AOI individual use the AOI Selector to point to the AOI to be set up.
4. AOI Offset X is used indicate the starting pixel of the AOI.
5. AOI Width is used to indicate the width of the that AOI.

Category	Parameter	Value
Camera Information	Pixel Color Filter	None
Camera Control	Pixel Coding	Color
I/O Controls	Test Pattern	Off
Flat Field	Line	Off
Image Format	Pixel Format	RGB8
Transpo	Width	8192
Acquisition and trans	MaxWidth	8192
Serial Port	Height	1
File Access Control	Multiple AOI Mode	Off
	AOI Count	3
	AOI Selector	1
	AOI Offset X	0
	AOI Width	1000
	<< Less	

The screenshot shows a configuration window with a left-hand menu and a main table of parameters. Five callout boxes provide instructions:

- 1. Must be off to set up the AOI. (Points to Multiple AOI Mode)
- 2. Set up the number of AOI desired to max of 4. (Points to AOI Count)
- 3. Select area to set up. (Points to AOI Selector)
- 4. Select beginning of selected area (Points to AOI Offset X)
- 5. Set up width of selected area (Points to AOI Width)

In order to initiate operation of the AOI once setup:

1. The AOI mode must be changed to Active.
2. Be sure to set the frame grabber image width to the sum of all AOI widths set up in the camera.

Category	Parameter	Value
Camera Information	Pixel Color Filter	None
Camera Control	Pixel Coding	Color
I/O Controls	Test Pattern	Off
Flat Field	Line Mirroring	Off
Image Format	Pixel Format	RGB8
Transport Layer	Width	8192
Acquisition and Transfer Control	MaxWidth	8192
Serial Port	Height	1
File Access Control	Multiple AOI Mode	Active
	AOI Count	3
	AOI Selector	1
	AOI Offset X	0
	AOI Width	1000
	<< Less	

Once all AOI are set up change to active.

Instructions on using the camera scan direction to control camera parameters


The camera is capable of adjusting camera parameters on-the-fly based on the scan direction of the camera. These parameters include gain, flat field coefficients, white balance and exposure time.

1. The first step is to put the camera in the reverse direction. This can be done using a reverse signal through CC3 and the Direction Source set to external or by having the Direction Source set to Internal and the Internal Direction set to reverse.
2. Set up all the desired parameters, including flat field corrections.

Category	Parameter	Value
Camera Information	Sensor ColorType	CFA_RBGG
Camera Control	Internal Line Rate	Not Enabled
I/O Controls	Measured Line Rate	0
Flat Field	Refresh Measured Line Rate	Press...
Image Format	Exposure Time Source	Trigger Width
Transport Layer	Exposure Time	50
Acquisition and Transfer Control	Measured Exposure Time	25.043
Serial Port	Refresh Measured Exposure Time	Press...
File Access Control	Direction Source	Internal
	Internal Direction	Reverse
	Offset	0
	Gain Selector	SystemGain
	Gain	3
	Color Transformation Matrix Selector	NoCorrectionFactorySet
	Color Transformation Value Selector	Gain00
	Color Transformation Value	1
	Line Spatial Correction	0
	<< Less	

First, setup parameters for reverse direction.

3. Save the camera parameters to a User set other than the default user set.



4. The next step is to put the camera in the forward direction. This can be done using a forward signal through CC3 and the Direction Source set to external or by having the Direction Source set to Internal and the Internal Direction set to forward .
5. Set up all the desired parameters including doing a flat field.

Category	Parameter	Value
Camera Information	Sensor ColorType	CFA_RBGG
Camera Control	Internal Line Rate	Not Enabled
I/O Controls	Measured Line Rate	0
Flat Field	Refresh Measured Line Rate	Press...
Image Format	Exposure Time Source	Trigger Width
Transport Layer	Exposure Time	50
Acquisition and Transfer Control	Measured Exposure Time	25.043
Serial Port	Refresh Measured Exposure Time	Press...
File Access Control	Direction Source	Internal
	Internal Direction	Forward
	Offset	0
	Gain Selector	SystemGain
	Gain	3
	Color Transformation Matrix Selector	NoCorrectionFactorySet
	Color Transformation Value Selector	Gain00
	Color Transformation Value	1
	Line Spatial Correction	0

<< Less

6. Save the camera set to User Set other than the saved to for the reverse direction. The forward direction user set and the default user set must be the same.

7. In the Flat Field area change the mode to Scan Direction Controlled.

Category	Parameter	Value
<u>Camera Information</u>	Mode	Scan Direction Controlled
Camera Control	Scan Direction Reverse Set	User Set 2
I/O Controls	Calibration Algorithm	Basic
Flat Field	Calibration Target	100
	Calibration Sample Size	4096
Image Format	ROI Offset X	1
Transport Layer	ROI Width	8192
Acquisition and Transfer Control	Calibrate FPN	Press...
Serial Port	Calibrate PRNU	Press...
File Access Control	Calibrate PRNU Status	Good
	Balance White Auto	Press...
<< Less		

A Note on External Direction, Direction Source, and User Sets

If using external direction control through CC3 ensure that the Direction Source is both set to external and saved in the user set. Also ensure that the polarity on CC3 is set appropriately for the desired direction.

Transport Layer Control Category

Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

Category	Parameter	Value
Camera Information	Camera Link Configuration	Medium
Camera Control	Camera Link Clock Frequency	CL85MHz
I/O Controls	Tap Geometry	Geometry_1X6
Flat Field	Restart Camera	Press...
Image Format	XML Major Version	0
	XML Minor Version	2
Transport Layer	Refresh GenCP Status	Press...
Acquisition and Transfer Control	Last GenCP Status	3
Serial Port	<< Less	
File Access Control		

Transport Layer Feature Descriptions

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

Display Name	Feature	Description	Device Version & View
Restart Camera	DeviceReset	Used to restart the camera, warm reset	1.00 Beginner DFNC
XML Major Version	DeviceManifestXMLMajorVersion	Together with DeviceManifestXMLMinorVersion specifies the GenICam™ feature description XML file version (RO)	1.00 Beginner DFNC
XML Minor Version	DeviceManifestXMLMinorVersion	Together with DeviceManifestXMLMajorVersion specifies the GenICam™ feature description XML file version (RO)	1.00 Beginner DFNC
Last GenCP Status	genCPStatus	If a feature read or write fails then Sopera only returns that it fails – read this feature to get the actual reason for the failure Returns the last error Reading this feature clears it	1.00 Beginner DFNC
Refresh GenCP Status	refreshGenCPStatus	Press to return the current status of the GenCP	1.00 Beginner
Camera Link Configuration	ClConfiguration Base Medium Deca	Camera Link Output configuration	1.00 Beginner
Camera Link Configuration	clDeviceClockFrequency CL85MHz CL 42.5MHz	Set the camera link clock rate	1.00 Beginner
Tap Geometry	DeviceTapGeometry	(RO)	1.00 Beginner

Acquisition and Transfer Control Category

The P4 Acquisition and Transfer controls, as shown by CamExpert, groups parameters used to configure the optional acquisition modes of the device. Parameters in gray are read only, either always or due to another parameter being disabled. Parameters in black are user set in CamExpert or programmable via an imaging application.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

Category	Parameter	Value
Camera Information	Device Registers Streaming Start	Press...
Camera Control	Device Registers Streaming End	Press...
I/O Controls	Check Stream Validity	Press...
Flat Field	Registers Valid	Valid
Image Format	<< Less	
Transport Layer		
Acquisition and Transfer Control		
Serial Port		
File Access Control		

Acquisition and Transfer Control Feature Descriptions

The following table describes these parameters along with their view attribute and minimum camera firmware version required. Additionally the firmware column will indicate which parameter is a member of the DALSA Features Naming Convention (DFNC), versus the GenICam Standard Features Naming Convention (SFNC not shown).

Display Name	Feature	Description	Device Version & View
Device Registers Streaming Start	DeviceRegistersStreamingStart	Announces the start of registers streaming without immediate checking for consistency.	1.00 Beginner DFNC
Device Registers Streaming End	DeviceRegistersStreamingEnd	Announces end of registers streaming and performs validation for registers consistency before activating them.	1.00 Beginner DFNC
Check Stream Validity	DeviceRegistersCheck	Press to check the validity of the current register set.	1.00 Beginner DFNC
Registers Valid	DeviceRegistersValid	States if the current register set is valid and consistent.	1.00 Beginner DFNC

Serial Port Control Category

The Serial Port control in CamExpert allows the user to select an available camera serial port and review its settings. This section also describes the Genie TS Framework Virtual Serial Port Driver and the use of the Genie TS serial port as an interface from an Ethernet network to a serial port control system for other devices.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

Category	Parameter	Value
Camera Information	Baud Rate	Baud_115200
Camera Control	Data Size	Eight_bits
I/O Controls	Parity	None
Flat Field	Stop Bits	One
Image Format	<< Less	
Transport Layer		
Acquisition and Transfer Control		
Serial Port		
File Access Control		

Serial Port Control Feature Descriptions

The Device Version number represents the camera software functional group, not a firm ware revision number.

Display Name	Feature	Description	View
Baud Rate	DeviceSerialPortBaudRate	Sets the baud rate used by the selected device's serial port. Available baud rates are device-specific.	1.00 Beginner DFNC
Baud 9600	Baud 9600	Baud rate is 9600	
Baud 19200	Baud 19200	Baud rate is 19200	
Baud 57600	Baud 57600	Baud rate is 57600	
Baud 115200	Baud 115200	Baud rate is 115200	
Baud 230400	Baud 230400	Baud rate is 230400	
Baud 460800	Baud 460800	Baud rate is 460800	
Baud 921600	Baud 921600	Baud rate is 921600	
Serial Port Parity	deviceSerialPortParity	Sets the parity checking type on the selected serial port.(RO)	1.00 Beginner
None	None	Parity checking is disabled	DFNC
Data Size	deviceSerialPortDataSize	Sets the bits per character (bpc) to use (RO).	1.00
Eight Bits	bpc8	Use 8 bits per character	Beginner DFNC
Stop Bits	deviceSerialPortNumberOf	Sets the number of stop bits to use.	1.00
Stopbits1	StopBits Stopbits1	Use 1 stop bit	Beginner DFNC

File Access Control Category

The File Access control in CamExpert allows the user to quickly upload various data files to the connected P4. The supported data files are for P4 firmware updates, Flat Field coefficients, LUT data tables, and a custom image for use as an internal test pattern.

Features listed in the description table but tagged as *Invisible* are usually for Teledyne DALSA or third party software usage—not typically needed by end user applications.

The screenshot shows a 'Parameters' dialog box with a tree view on the left and a table on the right. The tree view has two main categories: 'Board' and 'Camera - CameraLink_1'. Under 'Camera - CameraLink_1', 'File Access Control' is selected. The table on the right shows the 'Upload/Download File' parameter with a value of 'Setting...'. A '<< Less' button is visible below the table.

Category	Parameter	Value
Board	Upload/Download File	Setting...
	<< Less	


File Access Control Feature Descriptions

Display Name	Feature	Description	View
File Selector	FileSelector	Selects the file to access. The file types which are accessible are device-dependent.	1.00 Beginner
FPGA Code	Firm ware1	Upload new FPGA to the camera which will execute on the next camera reboot cycle.	DFNC
Micro Code		Upload new micro code to the camera which will execute on the next camera reboot cycle.	
CCI		Upload new CCI to the camera which will execute on the next camera reboot cycle.	
XML		Upload new XML to the camera which will execute on the next camera reboot cycle.	
User Set		Use UserSetSelector to specify which user set to access.	
Factory FlatField coefficients		Use UserSetSelector to specify which user flatfield to access.	
User FPN		Use UserSetSelector to specify which user FPN to access.	
ColorCorrectionMatrix		Upload new color correction matrix to the camera.	
CameraData		Download camera information and send for customer support.	
File Operation Selector	FileOperationSelector	Selects the target operation for the selected file in the device. This operation is executed when the File Operation Execute feature is called.	1.00 Guru
Open	Open	Select the Open operation - executed by FileOperationExecute.	
Close	Close	Select the Close operation - executed by FileOperationExecute.	
Read	Read	Select the Read operation - executed by FileOperationExecute.	
Write	Write	Select the Write operation - executed by FileOperationExecute.	
Delete	Delete	Select the Delete operation - executed by FileOperationExecute.	
File Operation Execute	FileOperationExecute	Executes the operation selected by File Operation Selector on the selected file.	1.00 Guru
File Open Mode	FileOpenMode	Selects the access mode used to open a file on the device.	1.00 Guru
Read	Read	Select READ only open mode	
Write	Write	Select WRITE only open mode	
File Access Buffer	FileAccessBuffer	Defines the intermediate access buffer that allows the exchange of data between the device file storage and the application.	1.00 Guru
File Access Offset	FileAccessOffset	Controls the mapping offset between the device file storage and the file access buffer.	1.00 Guru
File Access Length	FileAccessLength	Controls the mapping length between the device file storage and the file access buffer.	1.00 Guru

File Operation Status	FileOperationStatus	Displays the file operation execution status. (RO).	1.00 Guru
Success	Success	The last file operation has completed successfully.	
Failure	Failure	The last file operation has completed unsuccessfully for an unknown reason.	
File Unavailable	FileUnavailable	The last file operation has completed unsuccessfully because the file is currently unavailable.	
File Invalid	FileInvalid	The last file operation has completed unsuccessfully because the selected file is not present in this camera model.	
File Operation Result	FileOperationResult	Displays the file operation result. For Read or Write operations, the number of successfully read/ written bytes is returned. (RO)	1.00 Guru
File Size	FileSize	Represents the size of the selected file in bytes.	1.00 Guru

File Access via the CamExpert Tool

1. Click on the “Setting...” button to show the file selection menu.




2. From the Type drop menu, select the file type that will be uploaded to the camera.

3. From the File Selector drop menu, select the camera memory location for the uploaded data. This menu presents only the applicable data locations for the selected file type.
4. Click the Browse button to open a typical Windows Explorer window.
5. Select the specific file from the system drive or from a network location.
6. Click the Upload button to execute the file transfer to the camera.
7. Note that firmware changes require a device reset command from the Camera Information Controls and, additionally, CamExpert should be shutdown and restarted following a reset.

Download a List of Camera Parameters

For diagnostic purposes you may want to download a list of all the parameters and values associated with the camera.

1. Go to File Access Control
2. Click on Settings
3. In the “Type” drop down box select “Miscellaneous.”
4. In the “File selector” drop down box select “CameraData.”



5. Hit “Download”
6. Save the text file and send the file to Teledyne DALSA customer support.

Appendix B: ASCII Commands

The following commands can be used to control the Teledyne DALSA Piranha4 cameras.

Accessing the Three Letter Commands (TLC)

To access the TLC an ASCII-based communications interface application, such as HyperTerminal.

Additionally it is possible to use the functions of `clserxxx.dll` or `clallserial.dll` as defined in the Camera Link Specification.




Figure 25: Serial DLL hierarchy as mentioned in the Camera Link Specification

1. Cycle power to the camera: by either a) issuing the reset camera command (rc), or b) powering the camera OFF and then ON.
2. Load the ASCII interface using:
 - 9600 baud
 - 8 data bits
 - no parity
 - 1 stop bit
 - no flow control
 - local echo
 - (carriage return / linefeed)
3. Wait for a stable status LED color (green or red) before proceeding. Note that all entries in HyperTerminal will be ignored until a stable LED color is obtained.
4. In case of HyperTerminal, press the <Esc> key.
5. Once <Esc> has been entered the help screen appears.

Notes on Using Alternatives to HyperTerminal

- If you are using interfaces other than HyperTerminal, the ASCII character, Esc, is decimal 27 and needs to be issued. From the command line insert Esc by using ALT+2+7 of the activated Num-Pad. In some cases this needs to be followed by a carriage return or a linefeed to send this to the camera.
- In ASCII the Esc character may look like this: “←”.

ASCII to GenCP

To switch from the ASCII-command interface to the GenCP interface, the camera must be either reset (RC) or the power must be cycled. Note that GenCP and ASCII commands cannot be accessed simultaneously.

Note that the HyperTerminal application is not available on the Windows 7 OS.

Alternatives to HyperTerminal

The following alternative ASCII-interfaces have been tested and shown to work with this camera: PuTTY and TeraTerm. Note that PuTTY does not have Xmodem capability while TeraTerm does. Xmodem is required to update code in the camera.

TeraTerm <http://logmett.com/index.php?/download/tera-term-473-freeware.html>

PuTTY <http://putty.en.softonic.com/>

The camera responds to a simple ASCII-based protocol. A carriage return <CR> ends each command.

Example: to return the current detector settings

```
gcp <CR>
```

A complete list of the available detector commands, their format and parameters can be displayed by sending the help (**h**) command.

Port Configuration

```
Baud:          9,600
Bits:          8
Parity:        None
Stop bits:     1
Flow Control:  None
```

Echo typed characters locally.

Rules

- The interface is not case sensitive
- One command and argument(s) per line
- To enter a floating point number prefix it with a “F” – for example “ssg 0 f1.5”
- Error codes returned are the same as the GenICam™ interface – see Diagnostics | Error Codes
- Follow each command with the carriage return character – 0x0D

Disabling Esc Key for Direct Access to ASCII Commands

By default the Esc key is enabled and an Esc key sequence has to be issued in order to access the ASCII commands. Using the DEK 1 command the need to issue an Esc key is disabled and access to the ASCII commands are available immediately upon camera boot up. Note: access to GENCP is no longer available with the Esc key disabled unless a DEK 0 command is issued and the camera re-booted.

Commands

Full Name	Balance White Auto	
Mnemonic	BWA	
Argument(s)		
Description	Perform automatic white balance	
Notes	<ul style="list-style-type: none"> Gain each color such that the average of each is at the same level as the average of the most responsive. 	

Full Name	Calibrate User FPN	
Mnemonic	CCF	
Argument(s)	# of lines to average	<ul style="list-style-type: none"> 2048 4096
Description	Calibrate user FPN dark flat field coefficients	

Full Name	Camera Link Speed	
Mnemonic	CLS	
Argument(s)	Frequency	<ul style="list-style-type: none"> 0. 85 MHz 1. 42.5 MHz
Description	Camera Link clock frequency	

Full Name	Camera Link Mode	
Mnemonic	CLM	
Argument(s)	Mode	<ul style="list-style-type: none"> 0. Base 1. Medium 2. Full 3. Deca
Description	Camera Link Mode	

Full Name	Color Matrix Selector	
Mnemonic	CMS	
Argument(s)	Device	0. Factory 1. User
	# of lines to average	0 or 1, when factory selected above then 0. White LED 1. No correction (unity matrix)
Description	Color matrix selector	

Full Name	Calibrate Flatfield	
Mnemonic	CPA	
Argument(s)	Algorithm	0. Basic 1. Low-pass filter
	# of lines to average	<ul style="list-style-type: none"> • 2048 • 4096*
	Target	0 to 255
Description	Calibrate user PRNU flat field coefficients	
Notes	<ul style="list-style-type: none"> • Coefficients are saved and loaded with user set (e.g. USS / USL) • Basic algorithm flattens each color and then uses color gains to achieve target • Whereas low-pass filter algorithm does not adjust color gains • 	

Full Name	Color Transformation Value	
Mnemonic	CTV	
Argument(s)	Selector	0. c_{rr} gain 1. c_{rg} gain 2. c_{rb} gain 3. c_{gr} gain 4. c_{gg} gain 5. c_{gb} gain 6. c_{br} gain 7. c_{bg} gain 8. c_{bb} gain 9. k_r offset 10. k_g offset 11. k_b offset
	Floating Point Value	<ul style="list-style-type: none"> • Gains: -16 to +16 • Offsets: 0 to 255
Description	Color Transformation Matrix	
Notes	<ul style="list-style-type: none"> • Value must be immediately preceded with a "F" (e.g. <code>ctv 0 f1.5</code>) 	

Full Name	Disable Esc Key	
Mnemonic	DEK	
Argument(s)	Mode	<ul style="list-style-type: none"> 0. Esc key is enabled 1. Esc key is disabled
Description	Allow the use of the Esc key to be disabled so that upon boot-up the camera will directly enter the ASCII command mode. With the Esc key disabled the GENCP cannot be accessed.	
Notes	To access the GenCP, you have to first issue the DEK 0 command in order to enable the Esc key. Then reboot the camera.	

Full Name		
Mnemonic	FCS	
Argument(s)	File selector	<ul style="list-style-type: none"> 0. User Set 1. User PRNU 3. FPGA 4. Microcode 5. CCI 6. XML 15. User FPN 16. Color correction matrix
Description	<ul style="list-style-type: none"> • Upload file to camera using Xmodem protocol (HyperTerminal) • User set, PRNU, FPN, and color correction matrix are saved in the currently active set • Location to save color correction matrix is specified with CMS command 	
Notes	<ol style="list-style-type: none"> 1. Enter "FCS <#>" command from HyperTerminal 2. Click on "Transfer" 3. Browse and find file 4. Select "Xmodem" protocol 5. Click "Send" 6. When it indicates that it is done click "Close" 7. Upload all files and then reset camera 	

Full Name	Flatfield Mode	
Mnemonic	FFM	
Argument(s)	Mode	<ul style="list-style-type: none"> 0. Disable use of user FPN and PRNU flat field correction coefficients 1. Enable use of user FPN and PRNU flat field correction coefficients 2. Reset user FPN coefficients to zero and user PRNU coefficients to one 3. Scan direction controlled user set loading
Description	Set flat field mode	
Notes		

Full Name	Set Flatfield Scan Direction Reverse Set	
Mnemonic	FRS	
Argument(s)	User Set Number	1 to 8
Description	Set scan direction controlled reverse set	
Notes		

Full Name	Display Camera Configuration	
Mnemonic	GCP	
Argument(s)		
Description	Display current value of camera configuration parameters	
Notes	<pre> USER>gcp Model P4_CC_08K050_00_R Microcode 03_081_20292_02 CCI 03-110-20291-02 FPGA 03-056-20412-02 Serial # 14013769 UserID # 123456 BiST: Good DefaultSet 0 Ext Trig Off Line Rate 10000 [Hz] Meas L.R. 10003 [Hz] Max L.R. 19417 [Hz] Exp. Mode Timed Exp. Time 50000 [ns] Meas E.T. 49993 [ns] Max E.T. 98500 [ns] Test Pat. 0:Off Direction Internal, Forward Line Delay 1.00 Flat Field On Color Plane Selector: All Gain 1.00 Red Gain 1.00 Green Gain 1.00 Blue Gain 1.00 Color Matrix Selector: Factory 2 Color Correction Matrix: 1.000000, 0.000000, 0.000000, 0 0.000000, 1.000000, 0.000000, 0 0.000000, 0.000000, 1.000000, 0 Offset 0 Mirror Off AOI Mode Off CL Speed 85MHz CL Config Medium Pixel Fmt RGB8 CPA ROI 1-8192 USER> </pre>	

Full Name	Get Value
Mnemonic	GET
Argument(s)	<'parameter'>

Description	The “get” command displays the current value(s) of the feature specified in the string parameter. Note that the parameter is preceded by a single quote “”. Using this command will be easier for control software than parsing the output from the “gcp” command.
Notes	<pre>User>get `ssf 10000 Short Full Name Displayed Value and Description bwa Balance white auto No value returned ccf Calibrate User FPN No value returned cls Camera Link Speed 0: 85MHz or 1:1 - 42.5 MHz clm Camera Link Mode 0: Base 1: Med 2: Full 3: Deca cms Color matrix 0: Factory1, 1: Factory2, 2: User1, 3: User2 cpa Calibrate Flatfield No value returned ctv Color Transformation Value 12 lines, floating point values Gain 00 Gain 01 Gain 02 Gain 10 Gain 11 Gain 12 Gain 20 Gain 21 Gain 22 Offset 1 Offset 2 Offset 3 ffm Flat Field Mode 0: Off, 1: On, 3: Scan direction controlled frs Flat Field Reverse Set Set number 0-8 gcp Camera Configuration No value returned h Help No value returned rc Reset Camera No value returned roi Region of Interest Start pixel and end pixel numbers rpc Reset Pixel Coefficients No value returned sac Set AOI Count Number of AOI's 1-4 sad Last AOI Set AOI 1 Offset AOI 1 Width AOI 2 Offset AOI 2 Width ... sam Set AOI Mode 0: Disabled, 1: Enabled sbr Set Baud Rate No value returned scd Scan Direction 0: Internal, 1: External (CC3) control 0: Forward, 1: Reverse sem Exposure Mode 0: Internal, 1: External set Exposure Time ns smm Mirroring Mode 0: Enabled, 1:Disabled spf Pixel Format 0: RGB8, 2: G8, 3: RGBG8, 4: BGR8 ssa Set Spatial Alignment 0 to 3 ssb Offset -32 to 31 8-bit DN ssf Internal Line Rate Hz ssg Gain (four lines) 0: System, 1: Red, 2: Green, 3: Blue, floating point numbers stm Trigger Mode 0: Internal, 1: External svm Test Pattern 0: sensor video, 1: mono ramp, 2: color ramp usd Default User Set Set number 0-8 usl Load User Set Last set loaded 0-8 uss Save User Set Last set saved 0-8 vt Temperature No value returned</pre>

	vv	Input Voltage	No value returned
--	----	---------------	-------------------

Full Name	Help
Mnemonic	H
Argument(s)	
Description	Display list of three letter commands
Notes	<pre> USER>h P4 (03-081-20292-02): Command Line Interpreter May 28 2013, 12:10:55 bwa - Balance white auto ccf - Calibrate User FPN <2048 4096> cls - Camera Link Speed <0 - 85MHz, 1 - 42.5MHz> clm - Camera Link Mode <0:Base 1:Med 2:Full 3:Deca> cms - Color matrix selector <device 0-Factory, 1-User> <Selector 1-2> cpa - Calibrate Flatfield <0:basic 1:filter><2048 4096><DN target> ctv - Color transformation value <0-Gain00/1-Gain01/2-Gain02/3- Gain10/.../8-Gain22/9-Offset1/10-Offset2/11-Offset3> f<value> dek - disEsc Esc key <0/1> ffm - Flat Field Mode <0:Off 1:On 2:Initiliaz 3:Scan direction controlled> frs - Set Flatfield Scan Direction Reverse Set <set 1-8> gcp - Display Camera Configuration lpc - Load Pixel Coefficients <set 0-8> h - Help rc - Reset Camera roi - Set Flatfield ROI <1st pixel> <last pixel> rpc - Reset Flatfield Coefficients sac - Set AOI Count <value 1-4> sad - Set AOI Selector, Offset and Width <selector 1-AOI Count> <1st pixel> <width >= 40> sam - Set Aoi Mode AOI <1-enable, 0-disable> sbr - Set Baud Rate <9600 57600 115200> scd - Direction <0:Fwd, 1:Rev 2:Ext> sem - Exposure Mode <0:Int 1:Ext> set - Exposure Time <ns> smm - Mirroring <0:Off 1:On> spf - Pixel Format <0:RGB8 2:G8 3:RGBG8 4:BGR8> ssa - Set Spatial Alignment f<0-3> ssb - Offset <DN> ssf - Internal Line Rate <Hz> ssg - Gain <0-System/1-Red/2-Green/3-Blue> f<gain> stm - External Trigger <0:Off 1:On> svm - Test Pattern <0-2> usd - Default User Set <0-8> usl - Load User Set <0-8> uss - Save User Set <1-8> vt - Temperature vv - Input Voltage USER> </pre>

Full Name	Load Pixel Coefficients	
Mnemonic	LPC	
Argument(s)	Set selector	0. Factory set 1-8. User sets
Description	Load user set	
Notes	<ul style="list-style-type: none"> Loads FPN coefficients and PRNU coefficients from a user set (only coefficeints, no other camera parameters) 	

Full Name	Reset Camera	
Mnemonic	RC	
Argument(s)		
Description	Resets the camera to the saved user default settings. These settings are saved using the usd command.	
Notes		

Full Name	Set Flatfield ROI	
Mnemonic	ROI	
Argument(s)	First pixel	1 to 8192*
	Last pixel	1 to 8192*
Description	Flat field region of interest	
Notes	<ul style="list-style-type: none"> Specifies the pixels that CCF and CPA will calibrate <ul style="list-style-type: none"> Pixel coefficients outside this region are not changed Last pixel must be greater than or equal to first pixel 	

Full Name	Reset Flatfield Coefficients	
Mnemonic	RPC	
Argument(s)		
Description	Reset all user FPN values to zero and all user PRNU coefficients to one	
Notes		

Full Name	Set AOI Count	
Mnemonic	SAC	
Argument(s)	Number of AOI's	1 to 4
Description	Set AOI Counter	
Notes		

Full Name	Set AOI Selector	
Mnemonic	SAD	
Argument(s)	Selector	1 to 4
	Offset	1 to 8192*, multiple of eight
	Width	40 to 8192*
Description	Define an AOI	
Notes	<ul style="list-style-type: none"> • Must not overlap with an already existing AOI • 	

Full Name	Set AOI Mode	
Mnemonic	SAM	
Argument(s)	Mode	0. "Off" 1. "Active"
	Description	
Set AOI mode		
Notes		

Full Name	Set Baud Rate	
Mnemonic	SBR	
Argument(s)	Baud rate	9600 57600 115200
	Description	
	Set baud rate	
Notes	<ul style="list-style-type: none"> • Send command and then change speed of HyperTerminal 	

Full Name	Direction	
Mnemonic	SCD	
Argument(s)	Direction	0. Forward 1. Reverse 2. External – controlled by CC3 signal
	Description	
	Set sensor scan direction	
Notes		

Full Name	Select Exposure Time Color Selector	
Mnemonic	SCL	
Argument(s)	Color Selector	0. All 1. Red 2. Green 3. Blue
	Description	
	Select the color to apply an exposure time value to.	
	Notes	

Full Name	Exposure Mode	
Mnemonic	SEM	
Argument(s)	Mode	0. Internal 1. External
Description	Set exposure time mode	
Notes	<ul style="list-style-type: none"> • In internal mode the exposure time is controlled by the SET command • In external mode the sensor is exposed while CC1 signal is high • External mode is only available when the trigger mode is also external (STM 1) • SEM 1 overrides internally generated independent exposure times 	

Full Name	Exposure Time	
Mnemonic	SET	
Argument(s)	Exposure time	8 000 to 3000000 [ns]
Description	Set internal exposure time	
Notes	<ul style="list-style-type: none"> • Line time > (Exposure time + 1,500 ns) 	

Full Name	Mirroring	
Mnemonic	SMM	
Argument(s)	Mode	0. Off 1. Image is flipped on the vertical axis
Description	Set mirroring mode	
Notes		

Full Name	Pixel Format	
Mnemonic	SPF	
Argument(s)	Selector	0:RGB8 2:G8 3:RGBG8 4:BGR8
Description	Set pixel format	
Notes		

Full Name	Set Line Delay	
Mnemonic	SSA	
Argument(s)	# of lines	0 to 3
Description	Sets the number of lines of delay between colors that are read out from the sensor (default 1).	
Notes	If your line rate matches the speed of the object, then the value of the line delay will be 1. Adjust the ssa value until you remove the red and blue halos above and below a black on white horizontal line in order to set the line delay. Values entered must be between 0 and 3. Decimal places are valid for sub-pixel correction.	

Full Name	Offset		
Mnemonic	SSB		
Argument(s)	Offset	8 bit	-32 to 31
Description	Set offset		
Notes	<ul style="list-style-type: none"> Range changes depending on pixel format (SPF) 		

Full Name	Internal Line Rate		
Mnemonic	SSF		
Argument(s)	Line rate	1 to 70,000 [Hz]	
Description	Set internal line rate		
Notes	<ul style="list-style-type: none"> Line time > (Exposure time + 1,500 ns) 		

Full Name	Gain		
Mnemonic	SSG		
Argument(s)	Selector	0. System 1. Red 2. Green 3. Blue	
	Gain	1 to 10	
Description	Set gain		
Notes	<ul style="list-style-type: none"> Multiplier must be immediately preceded with a "F" (e.g. ssg 0 f1.5) 		

Full Name	External Trigger		
Mnemonic	STM		
Argument(s)	Mode	0. Internal 1. External	
Description	Set trigger mode		
Notes	<ul style="list-style-type: none"> In internal mode line rate is controlled by SSF command In external mode readout starts on falling edge of CC1 signal 		

Full Name	Test Pattern		
Mnemonic	SVM		
Argument(s)	Mode	0. Off – sensor video 1. Ramp 2. Color Ramp	
	Description		
Notes	<ul style="list-style-type: none"> When a test pattern is selected all digital processing (e.g. flat field, gain) is disabled – it is re-enabled when sensor video is selected 		

Full Name	Default User Set	
Mnemonic	USD	
Argument(s)	Set selector	0. Factory set 1-8. User sets
Description	Select user set to load when camera is reset	
Notes	<ul style="list-style-type: none"> The settings include all those listed by the GCP command plus the user FPN coefficients, user PRNU coefficients, and color correction matrix 	

Full Name	Load User Set	
Mnemonic	USL	
Argument(s)	Set selector	0. Factory set 1-8. User sets
Description	Load user set	
Notes	<ul style="list-style-type: none"> Loads and makes current all the settings listed by the GCP command plus the user FPN coefficients, user PRNU coefficients, and color correction matrix 	

Full Name	Save User Set	
Mnemonic	USS	
Argument(s)	Set selector	1 to 8
Description	Save user set	
Notes	<ul style="list-style-type: none"> Saves all the current settings listed by the GCP command plus the user FPN coefficients, user PRNU coefficients, and color correction matrix 	

Full Name	Temperature	
Mnemonic	VT	
Argument(s)	0	
Description	Display internal temperature in degrees Celsius	
Notes		

Full Name	Voltage	
Mnemonic	VV	
Argument(s)		
Description	Display supply voltage	
Notes		

Appendix C: Quick Setup and Image Acquisition

If you are familiar with the operation of Camera Link cameras and have an understanding of imaging fundamentals, the following steps will show you how to quickly set up this camera and begin acquiring images.

1. On Power Up

The P4-8K color camera has been calibrated and configured at the factory to be ready for your evaluation when first powered up. The default conditions are set as follows:

- System gain is set to the lowest value of one.
- Flat field calibration is *not* active as this feature is dependent on your light source and lens.
- Line rate and exposure time are set to for internal generation by the camera.
- White balance is set for white LEDs.
- Camera Link mode is set to the standard RGB medium mode which allows operation of up to 20 KHz line rate. The camera will run at up to a 34 KHz line rate using Camera Link Deca mode, but it may be easier to start your evaluation using the medium mode. Set your Camera Link frame grabber up to receive the standard RGB medium mode.

2. Communicating with the Camera

- The P4-8K color camera is designed to power up with a GenIcam-compliant interface.
- CamExpert provides an easy-to-use GUI that can be used to set up and evaluate the camera.
- The camera also comes with Teledyne DALSA's three letter command (TLC) interface option, which can be accessed using a suitable terminal program such as HyperTerminal™.
- If you want to use the TLC interface, press the 'Esc' key while using a terminal program and after the LED indicator on the camera turns green. Note that the camera defaults to 9.6 KBaud when first powered up.
- On receiving the 'Esc' character, the camera will output a list of the available TLC commands. You can then proceed to enter TLC commands as required.
- Enter 'h' at any time to get the list of commands from the camera.
- Enter the 'gcp' command at any time to get the current setup conditions of the camera.

3. Setting Up Your Optical Configuration

Typically, the first thing you want to do is to evaluate the camera's image quality under operating conditions similar to those that you are likely to use in your application. In order to do this, take the following steps:

- The illumination, lens magnification, and focus should be set up as per your application.
- Getting the magnification right is best accomplished by setting the object-to-sensor distance. Use the formula $\text{lens focal length} \times (2 + 1/\text{magnification} + \text{magnification})$ to calculate this distance. Magnification equals the sensor pixel size (7.05 μm) / (your object pixel size in μm).
- The approximate location of the sensor position is at the first groove in the side of the case, back from the front face.

4. Camera Timing & Control

It is easiest and quickest to evaluate the camera using the internal timing setups for line rate and exposure time.

- Since we recommend starting with Camera Link medium mode, set a suitable line rate less than 20 KHz, using the 'ssf' command.
- If this line rate is too slow for your application, you will get a compressed image in the scan direction. This should not be a problem for a basic evaluation.
- You can set the exposure time using the 'set' command. Ensure that the exposure time period is not greater than the period of the line rate minus 1.5 μsec .
- The camera will indicate an error if you select an exposure time that is too long. The minimum exposure time is 8 μsec .
- Set your camera direction using the 'scd' command. Refer to the [Camera Direction Control](#) diagram in this manual for a definition of 'forward' and 'reverse'.

5. Acquiring an Image

You can now begin imaging. Unless you have an application employing lots of light, the image is likely to be too dark.

- Use the system gain to adjust the camera output to achieve the desired response. The system gain range is from 1x to 10x.
- Once you have a suitable response, you can now focus the lens.
- If you are using white LEDs, your image will have reasonable color reproduction.
- The image may be darker at the edges due to lens vignetting, but this will be improved once the camera is calibrated.
- Calibration is performed using a white reference where your object is normally located.
 - Use a white material that has no texture, such as a non glossy plastic.

- If you must use white paper, make sure it is moving during the calibration process. If you do not do this, your image will have vertical stripes.
- Calibration is easily performed using the TLC 'cpa' command.
- The cpa command has two parameters.
 - The first is the number of lines you want to average over. Use a value of 8192 to achieve the best average.
 - The second is the eight bit target value you want for all three colors after calibration.
- The cpa command takes several seconds to complete. The slower the line rate, the longer it will take.
- On completion of the 'cpa' command, you should see an image from the camera that is white balanced with all three colors at the target level you set.

You are now ready to evaluate the image quality of the P4 color camera under your operating conditions.

6. Improving Your Color Image

The color response of the P4 color camera is quite good even when using white LED's and even without color correction. The camera has a factory set white LED color correction matrix that can be selected to improve color response for those using white LED's. If you are using a different light source, a suitable color correction matrix can be downloaded to the camera. A software tool to generate this is available with the Sopera processing applications, which can be downloaded from the Teledyne DALSA web site (60 day free trial). You will require a MacBeth© chart with 4 x 6 color elements that you can scan past the camera to complete the generation of the matrix.

Contact Teledyne DALSA's technical support for further details.


Appendix D: The Sensor Window

Cleaning and Protecting Against Dust, Oil, and Scratches

The sensor window is part of the optical path and should be handled like other optical components, with extreme care. Dust can obscure pixels, producing dark patches on the sensor response. Dust is most visible when the illumination is collimated. The dark patches shift position as the angle of illumination changes. Dust is normally not visible when the sensor is positioned at the exit port of an integrating sphere, where the illumination is diffuse. Dust can normally be removed by blowing the window surface using an ionized air gun. Oil is usually introduced during handling. Touching the surface of the window barehanded will leave oily residues. Using rubber fingercots and rubber gloves can prevent contamination. However, the friction between rubber and the window may produce electrostatic charge that may damage the sensor. To avoid ESD damage and to avoid introducing oily residues, avoid touching the sensor. Scratches diffract incident illumination. When exposed to uniform illumination, a sensor with a scratched window will normally have brighter pixels adjacent to darker pixels. The location of these pixels will change with the angle of illumination.

An important note on window blemishes:

When flat field correction is performed, window cleanliness is paramount. The figure below shows an example of what can happen if a blemish is present on the sensor window when flat field correction is performed. The blemish will cast a shadow on the wafer. FFC will compensate for this shadow by increasing the gain. Essentially FFC will create a white spot to compensate for the dark spot (shadow). As long as the angle of the incident light remains unchanged then FFC works well. However when the angle of incidence changes significantly (i.e. when a lens is added) then the shadow will shift and FFC will make things worse by not correcting the new shadow (dark spot) and overcorrecting where the shadow used to be (white spot). While the dark spot can be potentially cleaned, the white spot is an FFC artifact that can only be corrected by another FFC calibration.



Cleaning the Sensor Window

Recommended Equipment

- Glass cleaning station with microscope within clean room.
- 3M ionized air gun 980
(http://solutions.3mcanada.ca/wps/portal/3M/en_CA/WW2/Country/)
- Ionized air flood system, foot operated.
- Swab (HUBY-340CA-003)
(<http://www.cleancross.net/modules/xfsection/article.php?articleid=24>)
- Single drop bottle (FD-2-ESD)
- E2 (Eclipse optic cleaning system (www.photosol.com))

Procedure

- Use localized ionized air flow on to the glass during sensor cleaning.
- Blow off mobile contamination using an ionized air gun.
- Place the sensor under the microscope at a magnification of 5x to determine the location of any remaining contamination.
- Clean the contamination on the sensor using one drop of E2 on a swab.
- Wipe the swab from left to right (or right to left but only in one direction). Do this in an overlapping pattern, turning the swab after the first wipe and with each subsequent wipe. Avoid swiping back and forth with the same swab in order to ensure that particles are removed and not simply transferred to a new location on the sensor window. This procedure requires you to use multiple swabs.
- Discard the swab after both sides of the swab have been used once.
- Repeat until there is no visible contamination present.

EMC Declaration of Conformity

We, TELEDYNE DALSA
605 McMurray Road
Waterloo, Ontario
CANADA N2V 2E9

Declare under sole responsibility that the cameras:
Brand Name: Piranha4

Models: P4-CC-08K050-00-R

Which are components to be integrated into larger systems, were evaluated according to the CE Mark, FCC Part 15, VCCI, Israel, Korea, and Industry Canada ICES-003 Evaluation and satisfy the requirements of the following standards:

EN 55011 (2009)
EN 61326-1 (2006)
EN 55024 (2010)
ICES-003
CISPR-11
FCC Part 15

Place of issue: Waterloo, Ontario, Canada

Date of Issue: December 22, 2011

Hank Helmond
Director of Quality, TELEDYNE DALSA Corp.



Revision History

Revision	Change Description	Revision Date
00	Initial release.	03 August 2012
01	-New camera image added to cover. -Operating Range values revised. -Revised AOI rules. -Low and High timing diagram added. -Pixel format values revised.	03 July 2013
02	-Recommended Sopera LT imaging driver revised from v7.20 to v7.30. - X and Y alignment tolerance value in the specifications table changed from $\pm 50 \mu\text{m}$ to $\pm 80 \mu\text{m}$ to match the mechanical drawing.	04 December 2013

Index

B

baud rate, 49
black level
control, 48

C

calibration, 51
flat field, 53
process chain, 51
camera control signals, 22
camera information, 37
camera interfacing tool, 33
Camera Link
cables, 27
configurations, 40
input signals, 28
outputs, 28
Camera Link connector, 20
CamExpert, 34
certifications, 8
cleaning
sensor window, 98
clock signals, 28
compliance, 8
connectors, 20
Camera Link, 20
power, 29

D

data bus, 28
direction
sensor shift, 14
web movement, 14
direction control, 50

E

exposure
control, 40
external frame rate,
programmable exposure time,
42
externally controlled, 42
internally controlled, 41
exposure modes
descriptions of, 40
exposure time
set, 48

F

EXSYNC, 28

factory settings, 37

G

Gain
control, 48
grounding instructions, 20
GUI
CamExpert, 34
overview, 32

I

image acquisition, 40
input/ output, 20
interface
mechanical, 7

L

LED
definitions, 29

M

mechanical
camera, 15
specifications, 7
models, 7

P

performance specifications, 7
pixel format, 49
power
connector, 29
connectors, 29
guidelines, 29
pinout, 29
precautions, 5

Q

quantum efficiency
graph, 9

R

rebooting, 50
 requirements
 PC, 18
 responsivity
 graph, 9
 revision history, 100

S

safety, 5
 Sopera, 33
 sensor controls, 59, 62, 65, 75
 settings
 current, 39
 default, 40
 factory, 37, 40
 loading, 38
 saving, 38
 user, 39
 setup

T

overview, 18
 shift direction, 14
 size
 image, 48
 software
 required, 7
 specifications
 mechanical, 7
 performance, 7

V

temperature
 verify, 38
 test patterns, 36
 trigger modes, 40

voltage
 verify, 38